

USER'S HANDBOOK

4200

datron
INSTRUMENTS

AUTO CAL AC STANDARD

USER'S HANDBOOK
for
THE DATRON 4200
AUTOCAL STANDARD

850051

Issue 1 (JULY 1987)

For any assistance contact your nearest Datron Sales and Service center.
Addresses can be found at the back of this handbook.

Due to our policy of continuously updating our products, this handbook may contain minor differences in specification, components and circuit design to the instrument actually supplied. Amendment sheets precisely matched to your instrument serial number are available on request.



DANGER

HIGH VOLTAGE



**THIS INSTRUMENT IS CAPABLE
OF DELIVERING
A LETHAL ELECTRIC SHOCK!**



FRONT or REAR
terminals carry the
Full Output Voltage.

THIS CAN KILL!



Guard terminal is
sensitive to over-
voltage

**It can damage
your instrument!**

Unless **you** are **sure** that
it is **safe** to do so,
DO NOT TOUCH the
I+ I- Hi or **Lo** leads
and **terminals**

DANGER

CONTENTS

	Page
SECTION 1 THE DATRON 4200 AUTOCAL AC STANDARD	1-1
Introduction	1-1
Standard Facilities	1-1
SAFETY	1-2
Optional Facilities	1-3
Accessories	1-3
Additional Documentation	1-3
Principles of Operation	1-4
Option 30 Current Output	1-5
SECTION 2 INSTALLATION	2-1
Unpacking and Inspection	2-1
Preparation for Operation	2-1
Bench Mounting	2-2
Rack Mounting	2-2
Connectors and Pin Designations	2-3
SECTION 3 OPERATING CONTROLS	3-1
Front Panel	3-1
Front Panel Keys	3-1
Power Switch	3-1
OUTPUT Switching	3-2
FUNCTION Keys	3-3
OUTPUT RANGE Keys	3-3
OUTPUT Display and $\uparrow\downarrow$ Keys	3-4
Frequency	3-5
MODE Selection Keys	3-8
I+, I-, Hi, Lo, Guard and Ground Terminals	3-9
Rear Panel	3-10
SECTION 4 USING THE DATRON 4200	4-1
Preliminaries	4-1
Limiting Characteristics	4-1
SAFETY	4-1
Interconnections	4-2
Typical Lead Connections	4-4
General Sequence of Operations	4-6
Operating Routines	4-7
AC Voltage Outputs	4-7
AC Current Outputs	4-8
Additional Facilities	4-9
Change of Output Display Resolution	4-9
Frequency Store	4-10
Spot Frequency	4-11
'Spec' Mode	4-12
'Error' Mode	4-14
Test Key	4-17
Test Sequence	4-17
Warnings and Messages	4-20

SECTION 5 SYSTEMS APPLICATION VIA THE IEEE 488 INTERFACE	5-1
Introduction	5-1
Interface Capability	5-1
Bus Addresses	5-2
Interconnections	5-2
Typical System	5-3
Using the 4200 in a System	5-4
Programming Instructions	5-5
Programming of Operational Functions	5-8
Programming of Bus Transmissions	5-10
Activation of Commands	5-14
Multiple Commands	5-14
Operational Sequence Guidelines	5-15
 SECTION 6 SPECIFICATIONS	 6-1
General	6-1
AC Voltage	6-2
Voltage/Frequency Constraints	6-4
Capacitive Loading Constraints	6-5
AC Current	6-6
 SECTION 7 SPECIFICATION VERIFICATION	 7-1
Introduction	7-1
Summary of Equipment Requirements	7-2
Summary of Verification Procedures	7-3
Specification Verification Procedures	7-4
Preparation	7-4
Index of Recommended Procedures using Adjustable Standards	7-4
Index of Alternative Procedures	7-4
AC Voltage Verification Procedure	7-5
Millivolts (LF) Verification Procedure	7-6
Millivolts (HF) Verification Procedure	7-7
Current Verification Procedure	7-8
Verification Report Sheet RS1	7-9
 APPENDICES TO SECTION 7:	
Verification Procedures For Users with Fixed DC Voltage Standards	Appendix 1
AC Voltage Verification Procedure	7-A1-1
Millivolt (LF) Verification Procedure	7-A1-2
Millivolt (HF) Verification Procedure	7-A1-3
Current Verification Procedure	7-A1-4
Verification Report Sheet RS2	7-A1-5
Alternate Millivolt Verification using Wideband IVD	Appendix 2
Alternate Current Verification Procedure using Calibrated Standard AC Shunts	Appendix 3
Total Tolerance Limit Calculations	Appendix 4
Uncertainty and Traceability	Appendix 5
General Procedural Information	Appendix 6
Harmonic Distortion Measurement	Appendix 7

SECTION 8 ROUTINE AUTOCALIBRATION	8-1
The 4200 Autocal Feature	
'Wideband' calibration	8-2
SET Calibration	
SPOT Calibration	
STANDARD Calibration	
Calibration Sequence	8-3
Introduction	
General Procedure	
General Notes	8-4
Preparation	
AC Voltage Full Range Calibration (1V - 1000V)	8-5
Millivolts (LF) Full Range Calibration (1mV - 100mV)	
Millivolts (HF) Full Range Calibration (1mV - 100mV)	
Current Full Range Calibration (1mA - 1A)	

APPENDIX TO SECTION 8:

Current Full Range Calibration using Calibrated Standard AC Shunts	Appendix 1
--	------------

DATRON SALES AND SERVICE REPRESENTATIVES WORLDWIDE	Inside Rear Cover
---	-------------------

Note to Readers

This handbook has been designed for you to get the best use from your 4200. The sections are put together in a sequence flowing logically from one subject to another, so that understanding increases as the text is read naturally from front to rear. Here is an alternative (explanatory!) version of the Section Titles:

Sect 1. Introduction and a brief account of the internal design.

Sect 2. Physical connections and mounting - getting it installed.

Sect 3. A brief scan of the available controls - where they are and what they do.

Sect 4. The correct procedures for making the 4200 perform **for you**.

Sect 5. How your 4200 can operate within an IEEE 488 system - the device dependent codes you will need to use.


Sect 6. Specifications - what accuracy you can expect to get from your instrument.

Sect 7. Verification that your 4200 matches the high specification it had when it left the factory.

Sect 8. How to restore your 4200 to its original specification after it has suffered the ravages of time and temperature.

We are confident that your 4200 will give you many years of accurate and reliable service, and hope that you will use this handbook to obtain maximum benefit from its many facilities.

SECTION 1 THE DATRON 4200 AC AUTOCAL STANDARD



General View of Datron 4200 Autocal AC Standard

Introduction

The Datron 4200 Autocal AC Standard is a high-precision AC calibrator which features exceptionally high stability and full systems capability. It is characterized by a wide-range coverage of AC Voltage and AC Current functions in a single unit.

The 4200 incorporates a reference module containing precision temperature-compensation elements, maintaining a high accuracy specification over the ambient temperature range of $23^{\circ}\text{C} \pm 5^{\circ}\text{C}$. A high level of stability is achieved by use of super-selected reference components and ultra-stable gain-defining resistors. The 'Autocal' feature ensures that its 24-hour specifications are usable; not merely figures of merit.

The 4200 uses a microprocessor for control management, simplifying its use in complex manual operations, such as calibration of high-quality digital multimeters. The IEEE 488 interface provides a comprehensive remote programming capability, allowing programmed calibration of the 4200 itself.

Standard Facilities

AC Voltage Ranges

The basic instrument provides AC Voltage calibration facilities in seven decade ranges from 1mV to 1000V. 100% overrange is available on all but the 1000V Range (see Section 3 page 3-6).

Resolution and Accuracy

The resolution is $6\frac{1}{2}$ digits (100nV, 100pA), with a unique facility for displaying the specified accuracy of any output voltage. The 4200 specifications are in Section 6.

Frequency

The output frequency of the 4200 extends from 10Hz to 1MHz in five overlapping decade ranges, at a resolution of 1% of nominal Frequency Range. Any five frequency values within the range of the instrument can be stored in volatile memory. For higher accuracy, five 'Spot Calibrated' frequency values per Output Range can be recalled from non-volatile memory storage.

Autocal

All Datron AUTOCAL instruments are designed to make the removal of the covers for calibration unnecessary, as full routine calibration of all ranges and functions can be carried out from the front panel or over the IEEE-488 bus.

Accidental or unauthorised use of the calibration routine is prevented by a key-operated switch on the instrument rear panel. The procedure for calibrating this instrument is contained in Section 8.

Output Deviation

A user may deviate the output voltage from the output display value by introducing a gain 'Error' within the range $\pm 9.9999\%$.

Remote Sense

The specified output voltage may be sensed at the load, using 4-wire connections. Remote or Local Sense is selectable from the front panel.

Remote Guard

This facility allows the instrument's internal guard shields to be externally connected.

Self-test

On power-up, the internal calibration memory is automatically checked. At any time when the output is off, a user may conduct a sequenced test of the displays, keyboard, safety circuitry and Safety Reset function.

Message Readout

Messages to the user are presented on the MODE display;

The two main groups are:

Fail

An internal fault condition has been detected.

Error

A user has selected a task which is outside the instrument's capability.

Systems Use

The instrument can form part of a system by means of the IEEE 488 standard digital interface. The method of connecting to the system controller and the command codes are described in Section 5.

SAFETY

For protection of the user, safety trip circuits are incorporated to switch the OUTPUT OFF, in the event of instrument failures which might generate dangerous output voltages.

UNDER NO CIRCUMSTANCES SHOULD USERS TOUCH ANY OF THE OUTPUT, SENSE OR GUARD TERMINALS UNLESS THEY ARE FIRST SATISFIED THAT NO DANGEROUS VOLTAGE IS PRESENT.

Optional Facilities

The capability of the 4200 may be extended by the addition of one or more of the following options;

Option 30:
AC current Calibrator (maximum output 2 Amps).

Option 41:
Rear Output (as a factory-wired alternative to front panel output).

The Rear Output option is not recommended for best performance in calibrating high bandwidth, low level instruments.

Accessories

The instrument is supplied with the following accessories:

Description	Part Number
Power Cable	920012
Set of Calibration keys	700068
User's Handbook	850051
Calibration and Servicing Handbook	850056


In addition the following accessories are available for use with the 4200 instrument:

Description	Part Number
RMK Rack mounting kit (Option 90)	440094
Special Lead kit	440070

Additional Documentation

The Calibration and Servicing Handbook contains information required to adjust and service the 4200 instrument. It contains detailed descriptions of the circuits, trouble-shooting and calibration procedures, parts lists, layout drawings and circuit diagrams.

Principles of Operation



Simplified Functional Diagram. This shows the division and flow of functions within the 4200.

Inputs

The 6802 microprocessor controls the output in response to three main inputs:

- Front panel keys.
- IEEE 488 bus messages in 'Remote' operation.
- Corrections placed in non-volatile memory during 'Autocalibration'. These modify the values which control the RMS output.

After processing, the computing system changes the output of the instrument to respond to the input instructions.

Reference Voltages

A 20V DC 'Master' Voltage Reference establishes the fundamental accuracy of the instrument. From this 20V, a precision divider derives an adjustable 'Working' reference voltage between 0.1V and 2V, whose value depends on digital inputs from front panel keys and calibration memory.

Precision Divider

In the out-guard section the selected output value, including calibration corrections, is set into a digital comparator as a 25-bit number. This is counted out by a crystal-

controlled binary counter, resulting in a 125Hz square wave whose mark:period ratio accurately represents the output value selection. When transferred into guard, it chops the Master Reference voltage. A 7-pole active low-pass filter integrates the chopped reference, to generate the ripple-free DC Working Reference Voltage.

Quasi-Sinewave Reference Generator

The higher accuracy of AC/AC comparison (over AC/DC), is exploited by converting the 0.1V-2V DC Working Reference into a stepped waveform whose characteristics match those of a sinewave. The amplitude of this 'Quasi-sinewave' is precisely controlled by the DC Working Reference value.

Sinewave Source

Frequency Synthesizer

From the frequency value set into the MODE/FREQUENCY display, the processor controls the synthesizer using an encoded 9-bit command. The synthesizer translates the command into a pulse train at a crystal-derived frequency between 240kHz and 4MHz, to be divided down for use as phase-reference for the quadrature oscillator.

Quadrature Oscillator

The oscillator's output frequency is set close to any demand, between 10Hz and 1MHz, by selecting the RC time constants of its dual integrators; and then by correcting to the actual demand by phase-comparison with the output from the synthesizer. The output sinewave purity and constant amplitude are precisely defined by a sophisticated control loop, and the RMS value of the sinewave is adjusted to be roughly proportional to the demanded output voltage or current. Timing data is output from the source to synchronize the actions of the Quasi-sinewave Reference Generator and AC transfer comparator.

Voltage-Controlled Error Amplifier (VCA)

This has variable gain, amplifying the output from the Sinewave Source and providing a buffered drive to the output circuits. Its gain is determined by the measured difference between the RMS values of the sensed calibrator output and the reference quasi-sinewave; so the VCA provides the correcting fine adjustment for the output amplitude loop.

Output Range Switching and Amplification

IV Range

This is the basic voltage range of the 4200. As the quasi-sinewave working reference is variable between 0.1V and 2V RMS, it is compared in 1:1 ratio with the sensed output. The IV Buffer output is thus passed directly to the output I+ and I- terminals.

100mV, 10mV and 1mV Ranges

The IV Buffer output is reduced by precision attenuators before being connected to the terminals, the level being sensed before attenuation.

10V, 100V and 1000V Ranges

The IV Buffer output is amplified on each of these ranges. A separate amplifier is provided for the 10V range, the output sense signal being obtained at the terminals and attenuated before comparison with the reference. A common power amplifier is used for both 100V and 1000V ranges. On the 100V Range the output is fed directly to the terminals, on the 1000V Range the output is stepped up by a transformer. On both ranges, the sensed terminal voltage is reduced to the reference level by precision attenuators.

Output Sensing

On the IV range and above, the output is sensed at the front panel Hi and Lo terminals. With Remote Sense selected, these are isolated from I+ and I-, but in Local Sense Hi is internally connected to I+, and Lo to I-. As described above, the 10V, 100V and 1000V ranges' sense signal is attenuated before comparison with the reference.

AC Transfer Comparator

The comparator generates an error voltage proportional to the difference between the RMS values of the quasi-sinewave reference and the sensed output. It alternately samples a number of cycles from its 'Ref' and 'Sense' inputs, computes and integrates the squares of their instantaneous values, and uses a 'Sample and Hold' technique to subtract one from the other this being the 'error' voltage to control the VCA. The loop thus controls the 4200 output so that the RMS value of the comparator's sense input equates to that of its reference input.

Autocalibration

By setting the CAL ENABLE security keyswitch on the rear panel to ENABLE, the 4200 can be calibrated. (Refer to Section 8). The output RMS value is measured and the microprocessor is activated, to add any new corrections to factors already retained in non-volatile memory. The updated correction factors are applied in the normal RUN mode.

Processor

A 6802-series microprocessor controls the internal performance of the instrument, employing 24k bytes of program memory.


1k bytes of memory are used for stack and work space, and 1k bytes are made non-volatile by a battery-powered back-up supply, storing calibration correction factors.

With the exception of the Power ON/OFF switch and Safety Reset key, each front and rear panel control provides an input to the microprocessor system, which translates the information to command the 4200 analog and calibration functions.

The processor also controls the display, the IEEE 488 Interface Bus, and the operation of the restart and error circuitry.

Option 30 Current Output

An AC Current output is produced using a voltage to current converter. The 100 μ A and 1A ranges are driven directly from the basic 1V range, and the others from the 10V range. Range selection is achieved by switching internal shunts. Output protection against over-voltage is provided, and the output lines are fused. The OUTPUT display legend is altered to μ A, mA or A.



DANGER
HIGH VOLTAGE



**THIS INSTRUMENT IS CAPABLE
OF DELIVERING
A LETHAL ELECTRIC SHOCK!**



FRONT or REAR
terminals carry the
Full Output Voltage.

THIS CAN KILL!



Guard terminal is
sensitive to over-
voltage

**It can damage
your instrument!**

Unless **you** are **sure** that
it is **safe** to do so,
DO NOT TOUCH the
I+ I- Hi or **Lo leads**
and **terminals**

DANGER

Power Fuse

The fuse rating is:

3.15A for 220/240V line supply

6.25A for 100/120V line supply

It is located behind the window in the **POWER INPUT** module on the rear panel, and should be of the anti-surge or SLO BLO type.

WARNING

MAKE SURE THAT ONLY FUSES WITH THE REQUIRED RATED CURRENT AND OF THE SPECIFIED TYPE ARE USED FOR REPLACEMENT. THE USE OF MENDED FUSES AND THE SHORT CIRCUITING OF FUSE-HOLDERS SHALL BE AVOIDED, AND RENDERS THE WARRANTY VOID.

Bench Mounting

The instrument is fitted with six plastic feet. It is intended to stand flat on a bench, positioned so that the cooling-air inlet and exhaust apertures are not obstructed. It is recommended that at least 30cms (12 inches) of free space is at the rear.

Rack Mounting

Option 90 permits the instrument to be mounted in a standard 19 inch cabinet.

To Fit Option 90

CAUTION

Note that the 4200 is designed to be supported at front and rear. AT NO TIME should the 4200 be supported only by the front brackets. On no account should the upper and lower covers be removed.

Remove the two rear spacers from the case sides by releasing six screws. Fit the two rack-mounting slides to the rear of the case sides and secure using six of the shorter screws in the option kit.

N.B. The slides may be reversed to give rearward extension.

Fit the two rear rack-mounting ears to the rear of the cabinet, with tongues facing forward. In shallow cabinets it may be necessary to trim the tongue.

CAUTION

Assistance is required to fit the 4200 into the cabinet.


Lift the 4200 into position in the cabinet, locate the tongues in the slides, and carefully slide backwards until the front ears butt up against the cabinet front. Secure the front ears to the cabinet. Also clear ventilation for fan cooling to operate properly.

SUITABLE RACK DEPTHS

DEPTH		NOTES
mm	ins	
<635	<25	SHORTEN REAR RACK MOUNTING EARS
635-735	25-29	FIT AS SHOWN BY DRAWING
735-800	29-31	REVERSE RACK MOUNTING SLIDES TO EXTEND PAST REAR PANEL


① REMOVE

2 OFF 450300 REARSPACERS
6 OFF 611038 M4×12mm SOCKET HD CSK SCREWS



② FIT AS INSTRUCTED

2 OFF 450312 RACK MOUNTING EAR FRONT
2 OFF 450313 RACK MOUNTING EAR REAR
2 OFF 450314 RACK MOUNTING SLIDE
12 OFF 611062 M4×8mm SOCKET HD CSK SCREWS



Rack Mounting - Fitting of Option 90

SECTION 2 INSTALLATION

This section contains information and instructions for unpacking and installing the Datron 4200.

Unpacking and Inspection

Every care is taken in the choice of packing materials to ensure that your equipment will reach you in perfect condition.

If the equipment has been subject to excessive mishandling in transit, the fact will probably be visible as external damage to the shipping carton. In the event of damage, the shipping container and cushioning material should be kept for the carrier's inspection.

Unpack the equipment and check for external damage to the case, sockets, keys etc. If damage is found notify the carrier and your sales representative immediately.

Standard accessories supplied with the instrument are as described in Section 1.

Preparation for Operation

DANGER


THIS INSTRUMENT IS CAPABLE OF DELIVERING A LETHAL ELECTRIC SHOCK. THE I+, I-, Hi and Lo TERMINALS ARE MARKED WITH  SYMBOL TO WARN USERS OF THIS DANGER.

UNDER NO CIRCUMSTANCES SHOULD USERS TOUCH ANY OF THE FRONT TERMINALS UNLESS THEY ARE FIRST SATISFIED THAT NO DANGEROUS VOLTAGE IS PRESENT.

Power Input

The recessed POWER INPUT plug, POWER FUSE and Line Voltage Selector are contained in an integral filtered module at the centre of the rear panel.

The protective window allows the fuse rating and line voltage selection to be inspected with the power socket connected. This window slides to the left once the socket has been disconnected, for access to the fuse and voltage selector printed circuit board.





Power cable

The detachable supply cable, comprising two metres of 3-core PVC sheath cable permanently moulded to a fully-shrouded 3-pin socket, fits in the POWER INPUT plug recess, and should be pushed firmly home.

The supply lead should be connected to a grounded outlet ensuring that the ground lead is connected. Connect Black lead to Line, White lead to Neutral and Green lead to Ground. (European: Brown lead to Line, Blue lead to Neutral, and Green/Yellow lead to Ground).

Line voltage

The 4200 is operative within the line voltage ranges 100/115/120/220/230/240 $\pm 10\%$, 50 or 60Hz. To accommodate the ranges, a small PC selector board is housed beneath the POWER FUSE.



Operating Voltage Selection

FIRST ensure the POWER CABLE is removed. Slide the window to the left to reveal the fuse and PC selector board.

Draw the fuse-extractor to the left and remove the fuse. Remove the PC selector board and rotate until the desired voltage is on the left side of the upper surface.

Reinsert the selector board firmly into the module slot. The desired voltage is visible in the cutout below the fuse. Return the fuse extractor to the normal position.

Insert the appropriate POWER FUSE (see over). Slide the window to the right and insert the POWER CABLE.

Connectors and Pin Designations

IEEE 488 Input/Output Socket J27.

The IEEE input/output is a 24-way connector that is directly compatible with the IEEE 488 interface and the IEC 625 Bus.

Pin Layout



Pin Designations

J27 Pin No	Name	Description
1	DIO 1	Data Input Output Line 1
2	DIO 2	Data Input Output Line 2
3	DIO 3	Data Input Output Line 3
4	DIO 4	Data Input Output Line 4
5	EOI	End or Identify
6	DAV	Data Valid
7	NRFD	Not ready for Data
8	NDAC	Not Data Accepted
9	IFC	Interface Clear
10	SRQ	Service Request
11	ATN	Attention
12	SHIELD	Screening on cable (connected to 4200 Safety Ground)
13	DIO 5	Data Input Output Line 5
14	DIO 6	Data Input Output Line 6
15	DIO 7	Data Input Output Line 7
16	DIO 8	Data Input Output Line 8
17	REN	Remote Enable
18	GND 6	Gnd wire of twisted pair with DAV
19	GND 7	Gnd wire of twisted pair with NRFD
20	GND 8	Gnd wire of twisted pair with NDAC
21	GND 9	Gnd wire of twisted pair with IFC
22	GND 10	Gnd wire of twisted pair with SRQ
23	GND 11	Gnd wire of twisted pair with ATN
24	GND	4200 Logic Ground (Internally connected to 4200 Safety Ground)


Rear Output Terminals

The 4200 is fitted with either six front panel output terminals or six rear output terminals. The Rear Output alternative is fitted at the customer's request only at manufacture.

Socket J53 External Reset

This D-type plastic socket is located next to the cooling air intake filter. It may be used to input an external reset to restore the 4200 to its power-up state of ACV, 10V range etc. if required.


Pin Layout



Pin Designation

J53 Pin No	SIGNAL
1	Not used
2	Reset Common
3	Reset line
4-9	Not used

External Reset Switch Wiring



The function of the six terminals are identical to those normally fitted on the front panel, and the external leads are connected in the same way (See Section 4 for details).



DANGER
HIGH VOLTAGE




**THIS INSTRUMENT IS CAPABLE
OF DELIVERING
A LETHAL ELECTRIC SHOCK!**



FRONT or REAR
terminals carry the
Full Output Voltage.

THIS CAN KILL!



Guard terminal is
sensitive to over-
voltage

**It can damage
your instrument!**


Unless **you** are **sure** that
it is **safe** to do so,
DO NOT TOUCH the
I+ I- Hi or Lo leads
and **terminals**

DANGER

SECTION 3 OPERATING CONTROLS

This section summarizes the main operating features of the 4200. For detailed operating procedures refer to Section 4.

Front Panel Power-up state



The controls are outlined in blocks, left and right, associated with the appropriate display. The right-hand blocks generally deal with function and output definition, whereas the left-hand blocks are concerned with frequency, mode and terminal configurations.

Front Panel Keys

All user commands from front panel keys (except **Safety Reset**) are executed through main program firmware. A Key LED lit signifies that conditions are valid for the selected operation, and not merely that the key has made contact.

At any time, the instrument status is described by the combination of LED states, display values and display messages.

Generally, if an invalid condition is selected, either the nearest valid condition is activated, or the command is ignored and the 4200 remains in its previous state.

Power Switch

WARNING


THE POWER SWITCH SHOULD NOT BE SET TO ON UNTIL THE LINE VOLTAGE AND POWER FUSE RATING HAVE BEEN SELECTED AS DETAILED IN SECTION 2 (INSTALLATION)

When set to the  OFF position, the 2-pole **Power** switch isolates the instrument from the supply.

When switched to  ON, the instrument powers up, runs a self-test program and is configured into the following state:

OUTPUT	OFF
FUNCTION	V
OUTPUT RANGE	10
OUTPUT DISPLAY	1.000,00V
FREQUENCY RANGE	1kHz
MODE/FREQUENCY	
DISPLAY	1.00 k
MODES	Not selected
Guard	Local connection
Sense	Local connection
Key LEDs Lit	OUTPUT OFF, V, 10, 1k

Output Switching



OUTPUT ON/OFF

The 4200 should normally be connected and set up with its **output off**. This isolates the **I+**, **I-**, **Hi** and **Lo** terminals from their internal circuitry regardless of **RANGE**, **FUNCTION**, **FREQUENCY** or **MODE** selections. The **OUTPUT OFF** LED is lit.

Pressing the **OUTPUT ON** key connects the **I+**, **I-**, **Hi** and **Lo** terminals to their energised internal circuits.

OUTPUT OFF Default

Certain instrument states are prohibited, and some transfers between states are restricted by program firmware. For safety reasons some of these transfers result in the output being switched **off**. Refer to Section 4, Operating Routines.

OUTPUT OFF Trip – Fail 5 Message.

Under certain abnormal conditions which might compromise safety the 4200 output will trip off, accompanied by a **Fail 5** message on the **MODE** display. Control is removed from the front panel keys.

If the **Fail 5** message is present, there is **no** automatic recovery from the tripped state whether internal conditions have or have not returned to normal.


Safety Reset Key

The **Safety Reset** key allows a user to reset the safety trip to test whether conditions have returned to normal. If they have; the **Fail** message will disappear, the previous instrument state will be restored but with **output off**, and front panel control will be returned to the user. If conditions are still abnormal the **Fail** state will persist, and a further attempt may be made after a suitable interval. The **Safety Reset** LED is inoperative except in 'Test' mode.

Other Messages

A full list of 4200 messages appears in Section 4. The fault conditions which generate Fail messages are analyzed in the Calibration and Servicing Handbook.

FUNCTION Keys



Selected Function	Specified Output
V	AC Voltage
I	AC Current


When changing from one function to another the output is automatically set to OFF, and frequency defaults to 1kHz.

If the corresponding **OUTPUT RANGE** is not available on the new function, the 4200 selects the closest to it.

The numeric value of output is translated into the corresponding value on the new function and range.

e.g.: If set to 135μA on 100μA Range when V is pressed, an output value of 1.35mV on the 1mV Range will be selected.

OUTPUT RANGE Keys




Each **OUTPUT RANGE** key scales the output as selected by the user, setting the legend and decimal point on the **OUTPUT** display to match. Full range values are marked above the keys.

AC Voltage Ranges are selectable from 1mV to 1000V RMS, and AC Current from 100μA to 1A RMS, the actual output value being selected by use of the **OUTPUT** display ↑↓ keys.

If **OUTPUT** is **ON** when changing ranges, it remains on unless the change is to 1000V range, or ranging-up to more than 75V on 100V range. In these cases **OUTPUT** defaults to **OFF**. Any range selection which would exceed the internally defined voltage-frequency limit is automatically inhibited. These limits are described on page 3-6.

Key Selections	100μ	1m	10m	100m	1	10	100	1000
Voltage Ranges	(1mV)	1mV	10mV	100mV	1V	10V	100V	1000V
Current Ranges	100μA	1mA	10mA	100mA	1A	(1A)	(1A)	(1A)

OUTPUT Display and $\uparrow\downarrow$ Keys



Output Resolution

The AC Output and display are resolved as follows:

Ranges:	100 μ	1m	10m	100m	1	10	100	1000
V	–	4 $\frac{1}{2}$	5 $\frac{1}{2}$	6 $\frac{1}{2}$	6 $\frac{1}{2}$	6 $\frac{1}{2}$	6 $\frac{1}{2}$	6 $\frac{1}{2}$
I	6 $\frac{1}{2}$	6 $\frac{1}{2}$	6 $\frac{1}{2}$	6 $\frac{1}{2}$	6 $\frac{1}{2}$	–	–	–

The **OUTPUT** display is supplemented by legends, which always indicate the correct units for the Range and Function selected.

Output and Display Control

Each vertical pair of $\uparrow\downarrow$ keys is assigned to the display digit above it. Thus the value registered on the display may be set within the range permitted by the function selected. Each momentary press of the $\uparrow$ key adds 1 to its digit; pressing the $\downarrow$ key subtracts 1. If **OUTPUT** is **ON**, the Output terminal value is also changed by the same increments as the display (subject to the instrument interlocks).

Auto-Increment/Decrement

When an $\uparrow\downarrow$ key is pressed for more than $\frac{1}{2}$ second, its digit is increased or decreased at a rate of approximately 3 digits per second until the key is released.

Overflow and Underflow

As a digit is stepped from 9 to 0, the value of the next higher-order digit is increased by 1. Stepping from 0 to 9 decreases the value by 1. The whole display therefore acts as a counter, with full 'carry' and 'borrow' action.

Range of Adjustment

The $\uparrow\downarrow$ keys adjust the reading between a minimum of 0090000 (9% of Nominal Range), and maximum of 1999999 Full Scale on 100mV – 100V and Current Ranges. The 1000V Range has a Full Scale of 1100.000; the 1mV and 10mV ranges are truncated.

Leading Zeroes

For fractional readings, a leading zero is presented to the left of the decimal point to emphasise its position, except for **OUTPUT RANGE** selections 1m and 1.

Full Range key

When the **Full Range** key is pressed, the display reverts to the nominal value of the range selected. If **OUTPUT** is already **ON**, the terminal value follows the display value unless:

1. The combination of output voltage and frequency would exceed the instrument's internally defined limits. (refer to Section 6).
2. **Error Mode** is selected: The user-input gain error is not cancelled from the output.

Zero key

This reduces the display value to zero. If **OUTPUT** is **ON**, the terminal value is also set to zero:

Voltage – an internal short circuit is connected across the **Hi**, **Lo**, **I+** and **I–** terminals.

Current – output terminals are open-circuited.

Deselection of Zero

The size of the characters on the '**Zero**' display is significant. A half-size 'o' above any $\uparrow\downarrow$ key indicates that it cannot be used to deselect Zero, because it increments values which are less than 10% of nominal range. Any $\uparrow$ key with a full-size '0' above it (and any key to its left) deselects Zero and adds its increment.

Lower-order Digit Suppression

Unless **Error Mode** is selected, the user may reduce the resolution of the display by removing unwanted lower-order digits using one $\uparrow$ key and the **Zero Key**. The method is described in Section 4.

Selection of High Voltage Outputs


The 4200 is capable of delivering **LETHAL** output voltages so program interlocks are used to ensure that users do not inadvertently select outputs in excess of 75VRMS.

Details of the High Voltage selection procedure are given in Section 4.

Frequency

The output of the 4200 extends from 10Hz to 1MHz in five overlapping decade ranges, at a resolution of 1% of nominal Frequency Range. Any five frequency values within the range of the instrument can be stored in volatile memory. Also, five 'Spot Calibration' frequency values for each Voltage and Current Output Range may be stored in non-volatile memory during calibration, with associated high-accuracy calibration constants.

FREQUENCY RANGE keys




Decade Ranging

Generally, selection of a new range changes the frequency by a whole number of decades; but ranging-up from a frequency between 10Hz and 30Hz selects the lowest frequency in the new range. Also, ranging-up to the 1MHz range defaults to the range-maximum of 1MHz if the decade frequency would have been higher.

Selection of Nominal Range Value

Once a Frequency Range has been selected, it can be set to its nominal value by re-pressing its key.

FREQUENCY DISPLAY



Resolution

The output frequency is adjustable in steps of 1% of the selected **FREQUENCY RANGE** nominal value, matching the display resolution. Legends are appended on the display as appropriate, and a leading zero is presented to the left of the decimal point for fractional values.

FREQUENCY Control Keys

Each vertical pair of  keys is assigned to the display digit above it. The frequency registered on the display is adjusted by manipulation of these keys. Each momentary press of the  key adds 1 to its digit, and each  key subtracts 1. If **OUTPUT** is **ON**, the output frequency is also changed by the same increments as the display (subject to the instrument interlocks). Keys below decimal points are inactive.

Auto-Increment/Decrement

When a  key is pressed for more than $\frac{1}{2}$ second its digit is increased or decreased at a rate of approximately 3 digits per second until the key is released.

Overflow and Underflow

As a digit is stepped from 9 to 0, the value of the next higher-order digit is increased by 1. Stepping from 0 to 9 decreases the value by 1. The whole display therefore acts as a counter, with full 'carry' and 'borrow' action.

Autorangeing

Stepping the frequency beyond the span of a range automatically switches range up or down, but further steps are inhibited until the  or  key is released (the key could be below a decimal point). When the range-change occurs, the alarm buzzer sounds and the **FREQUENCY** display is blanked for approx. 1 second.

When the display is reinstated, the 4200 has remembered the last frequency on the old range, and sets the new range to its next incremental frequency in the original direction. After releasing the original key, stepping can be continued to any increments of the new range.

Autorange Limits

The 4200 ignores any attempted frequency increment or decrement which would produce an invalid combination of **FUNCTION**, **OUTPUT RANGE** or **FREQUENCY**. Neither will it increment or decrement to a frequency beyond the limits of the next frequency range up or down. Refer to Page 3-6.

OUTPUT/FREQUENCY CONSTRAINTS

Voltage and Frequency

Under most conditions, the output amplitude and frequency are adjustable throughout their full scales:

Voltages - from 90 μ V to 1100V

Frequencies - from 10Hz to 1MHz.

On the 100V and 1000V Ranges, certain combinations of voltage and frequency cannot be selected.


The diagram below illustrates the boundaries.

The 10V Range span is also shown for comparison.

The 4200 refuses to select any Voltage/Frequency combination outside these constraints. The temporary message **Error 7** is displayed for 3 seconds before reverting to the original display.


Current and Frequency

Current is adjustable between 9 μ A and 2A RMS at frequencies from 10Hz to 5kHz (all Current Ranges have the same span). **Error 7** indicates an invalid Current/Frequency selection.



FREQUENCY MEMORY

This facility allows storage of up to five user-selected frequencies. Once stored, each can easily be retrieved or changed from the front panel. They are retained until power is removed from the instrument.



Store key

Only five of the **FREQUENCY RANGE** keys select ranges. The first press of the sixth key, **Store**, reassigns the other five as frequency memories. It has toggle action: a second press deselects the memory function, and the frequency defaults to 1kHz.

F1-F5 Memory keys

When the **Store** LED is ON, these keys select individual memory locations.

NB. Although the **FREQUENCY RANGE** keys double as memory selectors, this does not imply that a particular memory can only accept frequencies from its key's range. It is emphasized that any displayable frequency can be stored in any of the five locations.

Power-up Default


Because the stores are volatile, the following default frequencies are stored in the five memory locations each time the 4200 is powered-up.

F1	30Hz
F2	300Hz
F3	3kHz
F4	30kHz
F5	300kHz

Details of storage and retrieval procedures are described in Section 4.

SPOT F FREQUENCY MEMORY

When in Calibration Mode, five user-selected 'Spot' frequencies can be stored in non-volatile calibration memory, for each of the seven Output Ranges. At these frequencies the 4200 output can be specially Auto-calibrated. Each can then be subsequently recalled when in Run Mode by two key depressions.




Spot F (SPOT) key

This is used to reassign the F1-F5 memory keys so that they access the non-volatile memory.

'Recall' procedures are detailed in Section 4.

'Store' procedures are detailed in Section 8.

MODE Selection Keys




The **MODE** selection keys are located on the lower left of the front panel. The Remote Guard and Remote Sense keys are described under '**I+**, **I-**, **Hi**, **Lo**, **Guard** and **⏏**'

STD, **SET**, **SPOT** and **CAL** are calibration modes, printed in red and described in Section 8.

SPEC MODE

The **Spec** key controls the toggle-action 'Specification' function. By pressing the key, the 4200 specification tolerances are displayed on the **MODE** display, referred to its current **FUNCTION**, **OUTPUT**, **FREQUENCY** and **CALIBRATION INTERVAL** selection. A second press cancels the function. For 24 hour calibration intervals, the 'Stability' figures are displayed (valid only if the environmental conditions are identical to those at calibration), but for **90 days** and **1 year** intervals they are 'Traceable' accuracy figures which include Datron's Calibration Uncertainty.



Rear Panel CALIBRATION INTERVAL switch

While in **Spec** mode, all primary functions of the other **MODE** keys are cancelled (although the selected Guard and Sense connections remain). The keys are reassigned to their secondary functions: **+lim**, **-lim**, **%** and **ppm** become active. When **Spec** mode is initiated, the magnitude of the specification tolerance itself determines whether **ppm** or **%** is selected. The arrow $\longleftrightarrow$ above the **Spec** key shows that all four secondary modes are available.

Full details of the operation of Specification mode are given in Section 4.

ERROR MODE


This key is used to deviate the output at the terminals from the value on the **OUTPUT** display.

Error Mode NOT Selected

The terminal value is a linear function of the **OUTPUT DISPLAY** value:


$$\text{Terminal value} = (m \times \text{OUTPUT DISPLAY value}) + c$$

where $m = 1$ and $c = 0$.



Error mode selected

In **Error** mode, the slope (m) can be adjusted within 10% of the displayed value (see the figure below). To increase resolution, **ppm** may be selected for deviations below 0.1%.



Full details of the operation of Error mode are given in Section 4.

SPOT F AND TEST MODES

Spot F mode selected


A description of **Spot F** mode is given on page 3-7. Full operating details appear in Section 4.

Test mode selected

Full details of the operations in **Test** mode are given in Section 4.

I+, I-, Hi, Lo, Guard and $\perp$ (Ground) Terminals

Local and Remote Switching



These terminals are located on the lower left of the Front Panel.

I+ and I- Terminals

The output from the internal power circuits is delivered to the **I+** terminal, **I-** being its Return Analog Common.

Hi and Lo Terminals

These terminals provide a differential input to the amplitude sensing circuitry. To obtain specified RMS outputs, the sense loop must always be completed.

Remote Sense

The **Remote Sense** key has 'toggle' action. Successive presses alternate between **ON** and **OFF**.

N.B. Sense connections can only be switched with OUTPUT OFF.

The specified RMS voltage output of the 4200 may be produced either at its output terminals (Local Sense for high impedance loads) or at the load terminals (Remote Sense for cases in which lead resistance and load impedance produce a significant effect).

With Remote Sense OFF, the **I+** terminal is isolated, and the voltage output is fed to the **Hi** terminal.

With remote Sense ON, the output voltage is fed across the **I+** and **I-** terminals only, and must be sensed externally, using leads connected to the **Hi** and **Lo** terminals.

Remote Sense is not available on 1mV – 100mV ranges. It is not applicable to Current outputs.

Guard Terminal

The Guard terminal is permanently connected to the internal guard shields:

Remote Guard

The Remote Guard key has 'toggle' action. Successive presses alternate between **ON** and **OFF**.

With Remote Guard OFF, Guard is internally connected to the **I-** terminal.

With Remote Guard ON, the internal link to **I-** is removed. The Guard terminal can then be connected externally to reduce common mode interference.

Ground Terminal

The $\perp$ (Ground) terminal connects directly to the 4200 internal Ground shields and to Safety Ground via the power-cable.


Output Connections

Connections to the output terminals may be made either with leads or via a shrouded connector.

For Voltage outputs in local sense the two leads should be attached to the **Hi** and **Lo** terminals.

Various configurations of 4200 load connections are detailed in Section 4.

Rear Panel (Shown with alternative Rear Output terminals).



POWER INPUT

The recessed power input plug, power fuse and line voltage selector are located in the centre of the rear panel, contained within a single moulded unit. Details of connections, selection of line voltage and fuse are given in Section 2.

REAR OUTPUT ALTERNATIVE

This can be incorporated at manufacture, to provide six output terminals on the rear panel instead of the six on the front. Their functions and connections are identical.

SOCKET J53 (External Reset)


This D type plastic socket is located next to the cooling air intake filter. It may be used to input an external reset to restore the 4200 to its power-up state of ACV, 10V Range etc. if required. Pin Layout, Pin Designation and Switch Wiring details are given in Section 2.

SOCKET J27 (IEEE 488 Input/Output)

The IEEE 488 Input/Output (D-type) socket J27 is a 24-way micro-ribbon connector that is directly compatible with the IEEE 488 interface and the IEC-defined system.

J27 is located at the top of the rear panel, outlined with the IEEE 488 address switch. The pin layout and designations appear in Sections 2 and 5.

IEEE 488 ADDRESS SWITCH




The 4200 may be addressed for use on the IEEE 488 interface bus. The address settings are given in Section 5.



DANGER
HIGH VOLTAGE



**THIS INSTRUMENT IS CAPABLE
OF DELIVERING
A LETHAL ELECTRIC SHOCK!**



FRONT or REAR
terminals carry the
Full Output Voltage.

THIS CAN KILL!



Guard terminal is
sensitive to over-
voltage

**It can damage
your instrument!**

Unless **you** are **sure** that
it is **safe** to do so,
DO NOT TOUCH the
I+ I- Hi or Lo leads
and **terminals**

DANGER

SECTION 4 USING THE DATRON 4200

Preliminaries

Before using the instrument it is important that it has been correctly installed as detailed in Section 2.

Limiting Characteristics

The following details are given in Section 6.

Function	Characteristics
All functions	Peak terminal voltages
AC Voltage	Output resistance and current limit; capacitive loading limits
AC Current	Maximum load resistance and maximum compliance

SAFETY

The 4200 is designed to be Class 1 equipment as defined in IEC Publication 348 and UL 1244, concerning safety requirements.

Protection is provided by a direct connection via the power cable from ground to exposed metal parts and internal ground screens.

The line connection must only be inserted in a socket outlet provided with a protective ground contact, and continuity of the ground conductor must be assured between the socket and the instrument.

WARNING:
ANY INTERRUPTION OF THE PROTECTIVE GROUND CONDUCTOR INSIDE OR OUTSIDE THE INSTRUMENT, OR DISCONNECTION OF THE PROTECTIVE GROUND TERMINAL MAY MAKE THE APPARATUS DANGEROUS. INTENTIONAL INTERRUPTION IS PROHIBITED.

THE TERMINALS MARKED WITH THE  SYMBOL CARRY THE OUTPUT OF THE 4200. THESE TERMINALS AND ANY OTHER CONNECTIONS TO THE LOAD UNDER TEST COULD CARRY LETHAL VOLTAGES.

UNDER NO CIRCUMSTANCES SHOULD USERS TOUCH ANY OF THE FRONT (OR REAR) PANEL TERMINALS UNLESS THEY ARE FIRST SATISFIED THAT NO DANGEROUS VOLTAGE IS PRESENT.

CAUTION:
THE  SYMBOL IS USED TO REMIND THE USER OF SPECIAL PRECAUTIONS DETAILED IN THIS HANDBOOK AND IS PLACED ADJACENT TO TERMINALS THAT ARE SENSITIVE TO OVERVOLTAGE CONDITIONS.

REFER TO SECTION 6.

Interconnections

IMPORTANCE OF CORRECT CONNECTIONS

The 4200 has been designed for use as an accurate source for precision calibration. To match the external circuitry to its superior specification, it is essential to take great care in making connections to the load.

SOURCES OF ERROR

Thermal EMFs

These can give rise to series (Normal) mode interference, particularly for low voltage outputs, and where large currents have a heating effect at thermo-electric junctions. Draughts can cause unbalanced cooling in an otherwise thermo-electrically balanced measuring circuit.

E-M Interference

Noisy or intense electric, magnetic and electromagnetic effects in the vicinity can disturb the measurement circuit. Some typical sources are:

- Proximity of large static electric fields.
- Fluorescent lighting.
- Inadequate screening, filtering or grounding of power lines.
- Transients from local switching.
- Induction and radiation fields of local E-M transmitters.
- Excessive common mode voltages between source and load.

The disturbances may be magnified by the user's hand capacitance. Electrical interference has greatest effect in high impedance circuits. Separation of leads and creation of loops in the circuit can intensify the disturbances.

Lead Impedance

The impedance of the connecting leads can drop significant voltages between the source and load, and generate adverse phasing effects particularly if the leads are long or the current in them is high.

Lead Insulation Leakage

This can cause significant errors in measurement circuits at high voltages. Some insulating materials suffer greater losses than others e.g. PVC has more leakage than PTFE.

AVOIDANCE TACTICS

Thermal EMFs

Screen thermal junctions from draughts.

Allow time for thermal equilibrium to be reached before taking readings.

Use conductors, joints and terminals with a good margin of current-carrying capacity.

Avoid thermoelectric junctions where possible:

e.g. Use untinned single-strand copper wire of high purity. Avoid making connections through Nickel, Tin, Brass and Aluminium. If oxidation is a problem use gold-plated copper terminals, and replace the terminals before the plating wears off. If joints must be soldered, low-thermal solders are available, but crimped joints are preferred. Use low-thermal switches and relays where they form part of the measuring circuit.

Balance one thermal EMF against another in opposition, where possible. (Switch and relay contacts, terminals etc.)

E-M Interference

Choose as 'quiet' a site as possible (a screened cage may be necessary if interference is heavy).

Suppress as many sources as possible.

Always keep interconnecting leads as short as possible, especially unscreened lengths.

Run leads together as twisted pairs in a common screen to reduce loop pick-up area, but beware of leakage problems and excessive capacitance.

Where both source and load are floating, connect **I—** to ground at the source to reduce common mode voltages.

Lead Impedance

Keep all leads as short as possible. Use conductors with a good margin of current-carrying capacity. Use Remote Sense and 4-wire connections where necessary to establish the 4200 output specification at the load.

Lead Insulation Leakage

Choose low loss insulated leads – PTFE is preferred to PVC.

When running leads together in screened pairs, avoid large voltages between leads in the same screen, especially if using PVC insulation.

Remote/Local Sense Configurations

The 4200 terminals are configured as follows:

Voltage Ranges:	
1mV, 10mV, 100mV	- Local Sense only
1V, 10V, 100V, 1000V	- User selects Local or Remote Sense.
Current Ranges:	
- Not applicable.	
The key LED indicates the true connection	- Lit = Remote
	- Unlit = Local

4200 – CONNECTIONS TO THE LOAD

General Considerations

The choice of connection method is influenced by several factors:

a. Loading Effects

4-wire connections should be used for low load impedances. For high impedance loads, 2-wire connections can be employed.

The ratio : $\frac{\text{Total Lead Resistance}}{\text{Load Resistance}}$

gives the approximate error for 2-wire connection at low frequencies.

e.g. Two $\frac{1}{2}$ -Ohm leads with a load of 100kOhms produce an error of approx. 10ppm.

At frequencies higher than about 100kHz, the error is also modified by reactive effects.

b. Noise and Output Level

Providing the E-M environment is reasonably quiet, interference due to noise pickup in the load connection is insignificant for outputs of more than about 100mV, so unscreened leads can be used. But at lower signal levels, or in noisier environments, it is advisable to use screened cable.

c. Common Mode Disturbances

When in Local Guard, the guard shields and tracks for the Sense circuitry are connected internally to 'I-', the low impedance terminal of the 4200 output power source. This classical connection effectively guards-out internal common mode disturbances. To reduce external disturbances it is advisable to make only one ground connection to the measurement circuit, and in the case of a guarded DMM, to make use of its external guard facilities. Also, where a line-powered load (such as a DMM being calibrated) has a ground connection, it should be to the same line ground as the 4200.

d. High Frequency Effects.

i. Voltage. Up to about 100kHz, for outputs above 100mV, it is possible to use pairs of unscreened wires, provided that the E-M environment is quiet. Twist or run leads together; keep length less than 1 meter.

Above 100kHz, both lead and load capacitances reduce the load impedance. Similarly, lead and load inductances combine to increase the load impedance with frequency (but heavily reactive loads should be avoided). It is therefore advisable to make leads from low-capacitance coaxial or twin-axial cable. To avoid mutual coupling, Sense and Power leads should not run together in the same screen.

ii. Current. Above about 1kHz, with low output currents, high lead capacitance can introduce shunt errors. To reduce these errors, the leads should be kept as short as possible, and be of low-capacitance.

e. DANGER.

THE 4200 OUTPUT CIRCUITS ARE NOT INTERNALLY CONNECTED TO GROUND. USERS ARE STRONGLY ADVISED TO CONNECT L₀ OR I- EXTERNALLY TO GROUND (PREFERABLY AT THEIR COMMON JUNCTION), WHEN THE 4200 IS TO BE USED ON THE 100V OR 1000V RANGE. THIS ELIMINATES THE RISK OF L₀ AND I- FLOATING TO HIGH VOLTAGE.

Setting Priorities

Because of:

- the variety of environmental conditions and loads likely to be encountered when using the 4200,
 - the extensive set of combinations of outputs from the instrument, and
 - the accuracy required;
- it is unrealistic to describe a definitive 'best' general method of connection to the load.

Combinations of the above factors can lead to conflicting requirements, and users may be faced with a choice between methods. In these cases it is sometimes necessary to arrive at a compromise solution by setting priorities.

Suggested Load Connections for the 4200

Six suggestions for connecting the 4200 to its load are illustrated in the following pages 4-4 and 4-5. Each has found use with the combination of factors described, and together they cover the majority of predicted requirements.

Typical Lead Connections

Voltage Outputs

CAUTION: All leads and cables must be proofed to at least 2kV.

Simple 2-wire Connection

Use for many applications where:

The voltage drop in the leads is insignificant

The E-M environment is 'quiet'.

External common-mode voltages are insignificant.

Use of measurements in the following ranges:


Voltage $V > 100\text{mV}$

Frequency $F < 100\text{kHz}$

Select Local Sense and Local Guard.

Keep leads as short as possible, (not longer than 1 meter – twisted pair is preferable).

Note: Refer also to reactive load specifications in Section 6.



On 100V/1000V Ranges Ground the Lo line for Safety.

Screened 2-wire Connection

Use where:

Sensitive measurements are being made.

The E-M environment is relatively 'noisy'.

External common-mode voltages are significant.


Use for measurements in the following ranges:

Voltage $V > 90\mu\text{V}$

Frequency $F < 1\text{MHz}$

Select Local Sense and Local Guard.

Keep leads as short as possible, (not longer than 1 meter).



On 100V/1000V Ranges Ground the Lo line for Safety.

Screened 4-wire Connection using Coaxial cable.

Use where:

The load resistance is low enough to cause a significant voltage drop in the output connection.

Sensitive measurements are being made.

The E-M environment is relatively noisy.

External common-mode voltages are significant.


Use for measurements in the following ranges:

Voltage $V > 90\text{mV}$

Frequency $F < 1\text{MHz}$

Select Remote Sense and Local Guard.

Keep leads as short as possible, (not longer than 1 meter).



On 100V/1000V Ranges Ground the Lo line for Safety.


Typical Lead Connections

Voltage Outputs (contd)

Screened 4-wire Connection.

Alternative using Twinaxial cable.

On 100V/1000V Ranges Ground the Lo line for Safety.



Note: Refer also to reactive load specifications in Section 6.

Current Outputs

Simple 2-wire Connection

Use for the majority of applications where:

The E-M environment is 'quiet'.

External common-mode is insignificant.

Use for measurements in the following ranges:


Current $I > 100\text{mA}$

Frequency $F < 5\text{kHz}$

Local Sense selected automatically.

Select Local Guard.

Keep leads as short as possible, (not longer than 1 meter – twisted pair is preferable).



Screened 2-wire Connection

Use where:

Sensitive measurements are being made.

The E-M environment is relatively 'noisy'.

External common-mode is significant.

Use for measurements in the following ranges:


Current $I > 9\mu\text{A}$

Frequency $F < 5\text{kHz}$


Local Sense selected automatically.

Select Local Guard.

Keep leads as short as possible, (not longer than 1 meter – Co-ax. or Twin-ax. is preferable).



General Sequence of Operations



Display Messages

(See full list at end of this section)

Error 1	: Spec. mode	- % : Uncertainty > 100%	FAIL 1	: Excessive internal temperature
		- ±lim : Off-scale limit	FAIL 2	: Over-voltage
Error 2	: Cal. mode	: Output not ON	FAIL 3	: Control data corrupted
Error 3	: Cal. mode	: Incorrect range or function for mode	FAIL 4	: Precision divider fault
			FAIL 5	: Safety circuits tripped
Error 4	: Cal. mode	: Correction exceeds store capacity	FAIL 6	: Calibration store fault
Error 5	: Error mode	: Requested output would have been off-scale	FAIL 7	: 400V power supply overload
				Automatically resets except where hard fault occurs
Error 7	: 100/1000V	: Selected output exceeds voltage/frequency constraint	FAIL 8	: 38V power supply overload
			FAIL 9	: 15V in-guard power supply overload
Error OL	: Voltage	: Output is current-limited	'B'	: Processor busy
	: Current	: Compliance limit reached		

Test mode messages:

SAFETY : Forced safety trip
RUNNING : Indicates test in progress
PASS : Calibration memory, over-voltage detector and 400V switching checked



DANGER
HIGH VOLTAGE



THIS INSTRUMENT IS CAPABLE OF DELIVERING A LETHAL ELECTRIC SHOCK !



FRONT or REAR terminals carry the Full Output Voltage.
THIS CAN KILL !



Guard terminal is sensitive to over-voltage
It can damage your instrument !

Unless **you** are **sure** that it is **safe** to do so,
DO NOT TOUCH the **I+ I- Hi** or **Lo** leads and **terminals**

DANGER

Operating Routines

The following operating routines are subdivided into two main types:

- Standard Operating Sequences
- Additional Facilities

Standard Operating Sequences

There are many common elements in the selection routines for both Voltage and Current operation. The diagram opposite shows the general sequence of operations. It should be used as the basis of any operating procedure, in conjunction with the individual selections detailed in the following pages.

AC Voltage

Zero Output

Zero Voltage output from the 4200 can be obtained only by pressing the Zero key. Internal relay contacts short **I+** to **I-**, and **Hi** to **Lo**.

Increment from Zero

The smallest output available on any range is 9% of full range, so any attempt to reduce the output below 9% is refused. Thus the smallest possible increment from Zero is to 10% of full range, using the appropriate key (any key to the right of this would attempt to increment to 1% or less, and be refused). Half-size zeros on the Zero display show which keys cannot be used to increment from Zero; full-size zeros show those which can.


When the display is correctly incremented with **OUTPUT ON**, the output terminals are internally re-connected to the voltage output circuitry.

Zero Displays

Range	Zero Display
1mV	. 0 0 0,0
10mV	0 . 0 0 0,0
100mV	0 0 . 0 0 0,0
1V	. 0 0 0,0 0 0
10V	0 . 0 0 0,0 0
100V	0 0 . 0 0 0,0
1000V	0 0 0 . 0 0 0

Output Voltage Selection

There are two overlapping voltage states. The 15V overlap allows some adjustment without changing state.



In the Low Voltage state, the output can be switched **ON** directly, but deliberate user-actions are required to transfer from Low to High Voltage state.

N.B. The 4200 switches its output voltage **OFF** each time the **1000V RANGE** is selected.

Low Voltage selections (up to 75V).
Using the general sequence:

- At operation **3** : Select **V**
- At operations **4** and **5** : No Remote Sense on 1m, 10m and 100m ranges

High voltage selections (above 75V).
Using the general sequence:

- At operation **3** : Select **V**
- At operation **9** : **OUTPUT RANGE** LED flashes for selections above 75V.
- At operation **11** : **Audible warning** – 5 pulses/sec for 3 secs.
- After 3 sec. warning** : 4200 sets **OUTPUT ON**.

While **OUTPUT** is **ON** : **Audible reminder pulses** continue at approx. 1 sec. intervals, and **RANGE** LED continues flashing.

If **OUTPUT OFF** or **ON** switching is attempted during the 3 sec. delay and 4200 reverts to **OUTPUT OFF**.

OUTPUT ON Transfers

If **OUTPUT** is already switched **ON** in Low Voltage State when an attempt is made to select a voltage in excess of 75V, the 4200 safety interlocks prevent the selection. Certain deliberate actions, detailed below, are then required by the operator to effect the selection.

Transfer from Low into High Voltage State, by manual upranging:

- 4200 switches **OUTPUT OFF**,
- Selected **RANGE** LED flashes.

Operator reselects **OUTPUT ON**:

- 3 sec **audible warning**
- 4200 switches **OUTPUT ON**
- **Audible reminder** while **OUTPUT** is **ON**
- **RANGE** LED continues flashing.
- **OUTPUT ON** LED lit continuously.

Transfer from Low into High Voltage State, by incrementing the **OUTPUT** display:

- **OUTPUT** remains **ON** at previous voltage
- **OUTPUT** display shows selected value
- **RANGE** and **OUTPUT ON** LEDs flash.

Operator reselects **OUTPUT ON**:

- 3 sec **audible warning**
- 4200 increases output voltage to the **OUTPUT** display value
- **Audible reminder** while **OUTPUT** is **ON**
- **RANGE** LED flashing.
- **OUTPUT ON** LED lit continuously.

Transfer from High into Low Voltage State, by pressing **OUTPUT OFF** key:

- **ON** LED remains lit until the output voltage has decayed (Approx. 1 sec from 1kV).

Transfer from High into Low Voltage State, by decrementing the **OUTPUT** display, or by manual downranging:

- Transfer to Low Voltage State is automatic when the Output Voltage falls below 60V.
- **RANGE** LED stops flashing – stays lit
- **OUTPUT ON** LED stays lit
- **Audible reminder** is **silent**

Changing Voltage State when in Error Mode

For safety reasons, the thresholds are always defined with respect to the voltage **at the output terminals**. When the instrument is in **Error** mode, the displayed output voltage is modified by the gain error, so the threshold indications may **not coincide exactly** with 75V and 60V on the **OUTPUT** display.

Option 30 – AC Current

Zero Output

Zero Current output from the 4200 can be obtained by pressing the **Zero** key. This causes the internal software to isolate the **I+** and **I–** terminals from the internal circuitry, physically interrupting the Output Current.

Increment from Zero

The smallest output available on any range is 9% of full range, so any attempt to reduce the output below 9% is refused. Thus the smallest possible increment from Zero is to 10% of full range, using the appropriate key (any key to the right of this would attempt to increment to 1% or less, and be refused). Half-size zeros on the Zero display show which keys cannot be used to increment from Zero; full-size zeros show those which can.

When the display is correctly incremented with **OUTPUT ON**, the **I+** and **I–** terminals are internally reconnected to the Current output circuits.

Zero Displays

Range	Zero Display
100 μ A	0 0 . 0 0 0,0
1mA	0 0 0,0 0 0
10mA	0 . 0 0 0 0 0
100mA	0 0 . 0 0 0,0
1A	. 0 0 0,0 0 0

Current Outputs

To generate output currents, use the **General Sequence**:

At operation **3** : select **I**

At operations **4** and **5** : No Remote Sense.

N.B. Maximum compliance 3V on all ranges.

Changing functions switches **OUTPUT OFF**.

Additional Facilities

Change of OUTPUT display resolution

If high resolution is not required, the unnecessary digits can be removed from the display by the procedure shown in the example. Up to three of the least significant digits can be suppressed, leaving a minimum resolution of $3\frac{1}{2}$ digits.

Truncating the Display

The example shows blanking of the last two digits when **FUNCTION V** is selected. The same method is employed for **FUNCTION I**.

Restoring Full Resolution


The procedure can be repeated to set any required resolution in the available range; so to restore full resolution, press the least significant digit $\uparrow$ key while holding the **Zero** key.

Exceptions: Error Mode and Remote Operation

Any suppressed digits are restored by transfer to Remote Operation on the IEEE-488 interface, or by selection of **Error** mode. Full resolution persists when these facilities are deselected.

Normal Truncation in Test Mode

Selection of **Test** mode does **not** restore full resolution; and when Test mode is terminated or aborted, any previously-truncated **OUTPUT** display will reappear.



Frequency Store

Store Key

This key controls the storage and recall of five user-selected frequencies. The memories are volatile in that their contents are lost when the 4200 is powered-down. At power-up, the following five decade frequencies are stored automatically.

F1	30Hz
F2	300Hz
F3	3kHz
F4	30kHz
F5	300kHz

ACCESS TO STORED FREQUENCIES

Recall a Stored Frequency

To set the 4200 to one of the five stored frequencies, simply:

Press and release the **Store** key.

- Its green LED lights.

Press and release the desired **F1-F5** key.

- Its LED lights.
- The **Store** LED remains lit.
- The stored frequency is presented on the **FREQUENCY** display, accompanied by its store location (see illustration).

Recall from a Different Memory

To switch to a different stored frequency:

Press and release the desired **F1-F5** key.

- The displayed indications change as appropriate.

Deselect Store

To revert to normal frequency facility:

Press the **Store** key again.

- Its LED goes out.
- The **F1-F5** LED goes out.
- Frequency defaults to 1kHz (the **1kHz FREQUENCY RANGE** LED lights).
- The stored frequency remains unchanged.

Re-program a Frequency Memory Store

To Change the Frequency of a Memory Store, the following procedure stores any displayable frequency in any of the five locations:

Select the required **FREQUENCY RANGE**.

Use the **FREQUENCY** display $\uparrow\downarrow$ keys to set the new frequency on display.

Press and hold the **Store** key.

- Its green LED lights.

Press and release the desired **F1-F5** key.

- Its LED lights.

- The store location is also presented on the display.

Release the **Store** key.


- Its LED remains lit.

If desired, deselect **Store** as above.

STORE KEY - SUMMARY

Press and Release: Access **F1-F5** stored-frequency retrieval.

Press and Hold: Allows displayed frequency to be stored in **F1-F5** memories.



Spot Frequency

This facility exists to provide rapid access to five user-selected spot frequencies on each output Voltage and Current range. As there are seven Voltage ranges, and five Current ranges, this makes a total of sixty spots in all.

Selecting a new **OUTPUT RANGE** also calls up its five spot frequencies, ready for selection.


The 4200 output can be calibrated at each spot frequency, thus achieving ultra-high accuracy by eliminating the 'Flatness' component.

By using non-volatile memory, these frequencies and their associated calibration constants are retained in store, even when the 4200 is powered-down.

In order to change the frequency setting of a spot and recalibrate at the new frequency, it is necessary to enter 'cal' mode (with the rear panel **CALIBRATION** key-switch set to 'ENABLE').

The output level span available for calibration of Spot frequencies is restricted to within 10% of nominal full range.

The calibration procedure is described, together with the other routine calibrations, in Section 8.



Spot F key

This reassigns the use of the **F1-F5** keys, to provide read-access to the non-volatile memory.

Recall

To set the 4200 to one of the existing spot frequencies, with output as previously calibrated, simply:

Press and release the **Spot F** key.

- Its LED lights.
- The **Store** LED lights.

Press and release the desired **F1-F5** key.

- Its LED lights.
- The **Store** and **Spot F** LEDs remain lit.
- The spot frequency is presented on the **FREQUENCY** display, accompanied by its store location (see illustration).

Recall from a Different Memory

To switch to a different spot frequency.

Press and release the desired **F1-F5** key.

- The displayed indications change as appropriate.

If the spot has not previously been calibrated, the message '**SFX----**' is displayed (**X** is the store number). The most recent frequency setting is retained.

Output and Frequency Constraints

If the combination of voltage and frequency, or current and frequency, is outside the defined constraints, the command to change spot, output range or output value will be ignored.

Deselect Spot Frequency

To revert to normal frequency facility:

Press either **Spot F** or **Store**.

- **Spot F** LED goes out.
- **Store** LED goes out.
- The selected **F1-F5** LED goes out.
- **1k FREQUENCY RANGE** LED lights
- **FREQUENCY** display reverts to 1kHz.
- 4200 frequency reverts to 1kHz.
- The stored spot frequency remains unchanged.

Re-program a Frequency Memory Store

To change the frequency of a memory store, the 4200 must be placed into 'cal' mode. This procedure is detailed in Section 8.

'Spec' Mode

Spec Key

This key allows a user to avoid constantly referring to the data sheet specifications, when it is necessary to determine the uncertainty for any set value.

Uncertainty Data Selection


The range of 4200 specification uncertainties is held in internal memory. **Spec** mode selects the stored data appropriate to the current settings of **Function**, **Range**, **Output Value**, **Frequency** and **Calibration Interval**; then calculates and displays the overall uncertainty.

Initiation

To transfer into **Spec** mode:

Select the required Calibration Interval
(Rear Panel switch).

Then follow the sequence in the diagram:



On pressing the Spec key the uncertainty appears on the **MODE** display, displacing the Frequency readout (except for Spot F and Store, Frequency cannot be changed when in 'Spec' mode). Initially the presentation is as shown in the following table:

Uncertainty	Display Units
< 1,999ppm of set value	ppm
> 1,999ppm of set value	%
Not displayable or > 100%	Error 1

Secondary Spec Modes

Once the **Spec** key has been pressed, the other **MODE** keys become reassigned to give a choice of four display modes:

ppm, %, +lim, -lim.

ppm or % Uncertainty (of displayed value).

From 1ppm to 1999ppm, the uncertainty can be displayed in **ppm**. From 0.001% to 100%, it can be displayed in **%**. When the uncertainty is not defined, the message **Error 1** is displayed.

Example of Error 1 Condition (Any Cal Interval)

Output range	1V
Setting	Zero key pressed
Frequency	Any frequency.
Uncertainty	Not defined at Zero.
Mode display is	Error 1 .

NB. The Zero Voltage output from the 4200 is a hard-wired short-circuit.

+Lim or -Lim

To obtain a reading of an absolute limit of uncertainty:

Press the **+Lim** or **-Lim** key.

The **MODE** display will switch to the same resolution as the **OUTPUT** display and its reading will be the positive or negative absolute limit of uncertainty (i.e. the **OUTPUT** reading plus or minus the absolute uncertainty error limit for that output).

As the reading approaches full scale, its positive limit may exceed full scale. If **+lim** is selected, **Error 1** is displayed.

Example of Error 1 Condition (24hr Cal Interval)

Output Range	1V
Setting	1.999600V
Frequency	400kHz
Uncertainty	260μV
Mode display is	1.999860V
Change setting to	1.999900V
Mode display is Error 1	(uncertainty not displayable).

FUNCTION and RANGE Control in Spec Mode

The **FUNCTION**, **OUTPUT RANGE** and **OUTPUT** $\uparrow\downarrow$ keys can be operated normally. The 4200 will adjust its **MODE** display to the uncertainty figure appropriate to each new selection.

FREQUENCY Selection in Spec Mode

The **MODE/FREQUENCY** display is assigned to its 'Uncertainty' presentation, and the **Spot F** key is assigned to %. Consequently the use of the **FREQUENCY RANGE**, **FREQUENCY** $\uparrow\downarrow$, **Store** and **Spot F** keys is inhibited.

Nevertheless, by pressing the **Spot F** key followed by one **F1-F5** key **BEFORE** pressing **Spec**, all sixty 'spot' frequencies can still be accessed, the output being modified by the previously calibrated correction as normal. A similar procedure using the **Store** key will access the five 'stored' frequencies.

In both of these cases the **MODE** display normally presents the appropriate uncertainty figure. But a readout of the Spot or Stored frequency can be obtained by merely pressing and releasing the **F1-F5** key whose **LED is lit**. The store location and frequency will appear for about 1 second, before changing back to the uncertainty figure.

If an uncalibrated Spot frequency is selected, the normal indication is given.

ie: '**SFX----**', where **X** is the store location.

A typical sequence using the '**Store**' facility at 10V on the 10V range is illustrated below (power up frequencies used):

Operation	MODE/FREQUENCY Display
Store - F2	F2 300
Spec	± 50 ppm
F4	± 55 ppm
F4 again	F4 30 k
After 1 sec	± 55 ppm

4200 'Spec' Data

Section 6 breaks down the specification into:

- a) Stability,
- b) Accuracy relative to Standards ($23^{\circ}\text{C} \pm 5^{\circ}\text{C}$),
- c) Datron's Calibration Uncertainty.

The **CALIBRATION INTERVAL** switch on the rear panel of both models is labelled:

24hr, 90dy, and 1yr.

The stored uncertainty data is selected from (a), (b) and (c) above, as follows:

- 24hr:** (a) Stability
- 90dy:** (b) + (c) 5°C Accuracy plus Uncertainty
- 1yr:** (b) + (c) 5°C Accuracy plus Uncertainty


Thus the accuracy figures displayed for **90dy** and **1yr** are traceable to National Standards.

In verifying the instrument's specification on receipt of a 4200, users are able to display the 90-day limits to check against the instrument's specified traceable accuracy. After recalibration, the '24 hour interval' limits should be used to verify against the same standards used for calibration under the same environmental conditions.

Refer to Section 7, Specification Verification, for further information.

'Error' Mode

The specification of a high accuracy AC DMM (and of other AC measuring equipment) relates its display readings to its input values. A perfectly calibrated DMM would have an exact 1:1 correspondence, and the specification lays down acceptable tolerances of deviation from this direct relationship. Plotted as a graph, the ideal case is a straight line at 45° through the origin. The tolerances plotted on the graph enclose an area on both sides of this line:



There are two major causes of deviation from the ideal case:

- Gain Error - the overall slope of the line is not 45°
- Linearity and Offset Error - the slope is not constant.

Either of these elements, or a combination, could cause large enough deviations to place the instrument out of tolerance. Without an easy method of discounting the gain error, a complicated analysis is necessary to determine which errors are responsible.

'Error' mode simplifies this analysis. It allows a user to identify the cause of excessive deviation, by compensating for gain errors.

Error Key

The Error key is used to initiate Error mode. The 4200 terminal value can then be deviated from the **OUTPUT** display value, by known gain factors, as entered on the **MODE** display.

Error Mode Display

Pressing the Error key changes the **MODE/FREQUENCY** display from 'Frequency' readout to 'Error Mode' readout. The initial reading is always '0.0 ppm', indicating that the terminal value has not yet been deviated.

MODE/FREQUENCY Keys

The terminal value is changed, without altering the **OUTPUT** display, by pressing the  keys beneath the **MODE/FREQUENCY** display. The gain compensation being applied is displayed as a **percentage** or **ppm** of the **OUTPUT** display value; with positive polarity for an increase of terminal value, and negative for a decrease.

The gain-compensation factor has a maximum possible resolution of ± 1 ppm of Full Range. The extreme right-hand digit of the readout (0.1 ppm) is not significant.

OUTPUT Display Truncation


The **OUTPUT** display cannot be truncated in Error Mode. Any previous truncation (see page 4-9) is cancelled, and full resolution persists when Error Mode is deselected.

Example of the Use of 'Error' Mode

To measure the linearity of an AC DMM, a user needs to compensate each input for the DMM's gain error before linearity errors can be calculated.

Using Error Mode, once the gain error has been found at, say, Full Range; the 4200 automatically calculates and applies gain compensation to all outputs on that Range and Function. Meanwhile, it displays both the nominal (uncompensated) value of output and the gain compensation. Only if the DMM response is linear, will each DMM reading agree with the corresponding 4200 **OUTPUT** display value.

In the following sequence diagram, a DMM is checked for linearity. For purposes of explanation, it is assumed that linearity is correct, but the DMM has a gain error of +100ppm.



The 4200 output has now been compensated for the gain error of the DMM. All selected output values will be compensated in the same ratio on this Range and Function until either the ratio is changed or Error mode is deselected. The Mode display presents the compensation ratio directly.

Note that the compensation sense is shown, not the error sense, therefore the true output is the sum of both displayed values - in this case:

$$10.00000\text{V} - 100\text{ppm} = 9.99900\text{V}.$$

The linearity of the DMM may now be checked by directly comparing its readings with the OUTPUT display settings.

e.g. at 5V on this range, both 4200 and DMM read 5.00000V, although the terminal voltages are 4.99950V

Other linearity check values could be:

Nominal Check Point	4200 set Value	DMM Reading	Terminal Voltages
1V	1.00000V	1.00000V	0.99990V
19V	19.00000V	19.00000V	18.99810V

Error Mode Frequencies

In **Error** mode, the **MODE/FREQUENCY** display is assigned to its 'Gain Factor' presentation, and the **Spot F** key is assigned to '%'. Consequently the use of the **FREQUENCY RANGE, FREQUENCY ↑↓**, **Store** and **Spot F** keys, is inhibited when in Error mode.

Nevertheless, by pressing the **Spot F** key followed by one **F1-F5** key **BEFORE** pressing **Error**, all sixty 'spot' frequencies can be accessed, the output being modified by the previously calibrated correction as normal. A similar procedure using the **Store** key will access the five 'stored' frequencies.

In both of these cases the **MODE** display normally presents the applied gain factor. But to obtain a readout of the **Spot** or **Store** frequency, merely press and release the **F1 – F5** key whose **LED** is **lit**. The store location and frequency will appear for about 1 second, before changing back to the gain factor.

If an uncalibrated **Spot** frequency is selected, the normal indication for this is given.

ie: '**SFX----**', where **X** is the store location.

A typical sequence using '**Store**' is shown below (power-up frequencies used).

Operation	MODE/FREQUENCY Display
Store – F2	F2 300
Error	0 ppm
MODE ↑↓	+ 10 ppm
F2 again	F2 300
After 1 second	+ 10ppm
F4	+ 10ppm
F4 again	F4 30 k
After 1 sec.	+ 10 ppm

Full Scale Limiting

The **OUTPUT** display cannot be raised to a value which sets its overrange digit to greater than 1, and the Error Mode display cannot be raised above 9.9999% (999 ppm).

Nevertheless a combination of **OUTPUT** display value and gain error could result in an off-scale value. The 4200 prevents this by rejecting any demand for an error-corrected value in excess of full scale. The user is informed by **Error 5** message on the **MODE** display with no change to the **OUTPUT** display. This message is temporarily displayed for approximately 1 second.

Either **OUTPUT ↑↓** or **MODE ↑↓** keys may be used to bring the actual output within scale; then the Error message will be replaced by the compensation ratio.

Deselection of Error Mode

Press the **Error** key.

- The **MODE** display clears.
- The green **Error** LED goes **OFF**.
- The 4200 gain factor is deselected.
- The selected frequency, spot or stored frequency, does not change.

Although the mode is normally deselected by repressing the Error key, it is also turned off by changing **FUNCTION** or **RANGE**.

After leaving Error mode, the **OUTPUT** display resolution remains at maximum for the Function and Range selected.

Test Key

Tests available

There are two stages of ‘Test’ mode. The first stage, Safety and Memory checks, cannot be omitted from any ‘Test’ sequence.

Safety and Memory Checks

On first pressing the Test key, the 4200 carries out three checks:

- 1. Operation of the Safety trip, buzzer and reset circuitry.
- 2. Calibration Memory integrity.
- 3. Over-voltage check. (High voltage when not in HV state).

Messages appear on the **MODE** display, and completion is signalled by the **Test** LED going **OFF**. The second stage Display and Key checks may be omitted by pressing any key **other than Test**.

Display and Key Checks

If the Test Key is re-pressed before pressing any other key, a visual sequence tests the front panel:

- 1. Gas discharge displays
- 2. Key LEDs
- 3. Key contacts (user-selected)

The 4200 remains in the key-contact mode until the Zero Key is pressed or test is deselected. It may then be used normally.

NOTE: At any time during the second stage, the Test sequence may be aborted by pressing Test Key again.

Test Sequence

The Front or Rear panel terminals are not energised during Test sequence.

Safety and Memory Checks

1. Initial Conditions

Ensure that **OUTPUT OFF** LED is lit, **Error** and **Spec** LEDs are unlit. Check that **Test** LED is unlit. Selftest is only accepted if some output other than zero has been selected.

2. Press Test Key:

Test LED lights as the checks begin.

3. Safety Trip Check

The 4200 tests the safety trip circuits. The **SAFETy** message appears on the **MODE** display and the buzzer will sound continuously when the trips have operated, and the **Safety Reset LED** flashes.

4. Safety Reset Check

The program ensures that a user tests the **Safety Reset** action.

Press **Safety Reset** Key:

The **SAFETY** message is replaced by the running message and the buzzer stops sounding. Relay operation can be heard during the automatic checks which follow.

5. Calibration Memory Check

This is a sum-check of the Non-Volatile RAM. If the check fails, the Message **FAIL 6** appears, otherwise no message.

6. Over-Voltage Checks

The 4200 automatically tests the over-voltage detector threshold levels in Low Voltage state.

If the check fails, the message **FAIL 2** appears, otherwise **PASS** message indicates both tests completed successfully.

7. The Test LED goes OFF

The following table summarizes the **MODE** display messages:

Message	Reason
SAFETY running	First stage of ‘test’ operative.
PASS	No failure discovered.
FAIL 6 only	Parity error in Calibration Memory check.
FAIL 2 only	High voltage can be present in Low Voltage state.

Any combination of these two **FAIL** messages can appear in sequence, replacing the running message.

8. To terminate Test before the Display and Key checks, press any key other than Test:

4200 defaults to 10V Range, 1V Output selected at 1kHz, Output OFF, Test LED OFF.

Operate 4200 normally.

Display and Key Checks

Visual Check Sequence Read this Note before pressing Test Key to start.


NOTE: After pressing Test Key, the Visual Check Sequence commences. During this sequence observe that:

- (a) No display segments or blocks are missing or incomplete.
- (b) Segments and blocks do not appear spuriously.
- (c) Inter-digit and inter-segment 'streaming' does not occur.
- (d) All LED's are lit in their correct sequence.
- (e) LEDs are not lit spuriously.

1. Press **Test** key – **Test** LED lights
 - All other LEDs unlit
 - Displays cleared momentarily,

then:

2. **MODE** Display
 - (a) Initial presentation:




nine segments and legends are presented.

- (b) Progressively, all seven-segment digits and legends are displayed segment by segment.

N.B. Commas are not presented in the MODE display sequence.

- (c) MODE display cleared.

3. **OUTPUT** Display
 - (a) Initial presentation:



nine segments and legends are presented.


- (b) Progressively, all seven-segment digits and legends are displayed segment by segment.

- (c) Final presentation: Nine commas are displayed on **OUTPUT** display then all 18 commas are displayed on **OUTPUT** and **MODE** displays.

- (d) **OUTPUT** and **MODE** displays cleared.

4. **MODE** Display


- (a) Initial presentation:



Polarity signs and overrange digit displayed.

- (b) Progressively, seven-segment digits are presented digit by digit.

- (c) Final presentation.



First, then second blocks of legends are displayed.


- (d) **MODE** display cleared.

5. **OUTPUT** display digits are presented next, in the same order as for the **MODE** display.

6. **LED** Check sequence commences:

- (a) **Test** LED stays on, and other key LEDs are lit in Left to Right sequence starting at **100** key and ending at **OFF**.

- (b) **MODE** display.



Symbol shown indicates that the keys are ready to be checked.

7. Key Checks

N.B. The **Zero** key should not be pressed until it is desired to terminate the Test Sequence.

(a) Keys

Each $\uparrow$ key should light the upper half of the digit immediately above it.



OUTPUT Display overrange digit $\uparrow$ key.



Each $\downarrow$ key should light the lower half of the digit immediately above it.



OUTPUT Display overrange digit $\downarrow$ key.



(b) **FREQUENCY RANGE, MODE, OUTPUT RANGE, FUNCTION, and OUTPUT** keys should cause their LEDs to light, except:

- (i) **Safety Reset** key, which is inoperative,
- and (ii) **Test** key, which aborts the test.

In these tests the key-press operates a latch so that the display or LED remains lit until another key is pressed. Only one key-press at a time is recognised.

(c) To Terminate the Test Sequence:

- Press **Zero** key to check its operation.
- 4200 reverts to initial conditions.
- **Test** LED goes **OFF**

(d) Operate 4200 normally.

Warnings and Messages

Audible Warning

- (a) Sounds at approx 5 pulses per second during the 3 second delay between selection of **OUTPUT ON** and the High Voltage being connected to the terminals, when the **OUTPUT TERMINAL VOLTAGE WILL EXCEED 75V**.
- (b) Sounds at approx 1 second intervals with **OUTPUT ON** in **High Voltage State**.
- (c) Sounds for 1 second with blank **FREQUENCY** display when frequency auto-ranges up or down.
- (d) Sounds continuously when **SAFETY** message is present on **MODE** display during self test.

FREQUENCY/MODE display

- | | | |
|-----------------|---|---|
| Error 1 | - Spec Mode : [%]
: [+Lim, -Lim] | - Tolerance exceeds 100%.
- The selected limit is off-scale. |
| Error 2 | - Calibrate Mode | - OUTPUT OFF . |
| Error 3 | - Calibrate Mode | - Incorrect FUNCTION , OUTPUT or FREQUENCY RANGE for this calibration mode. |
| Error 4 | - Calibrate Mode | - Correction out of limits. |
| Error 5 | - Error Mode | - Temporary message. The selected deviation would cause the output to exceed full-scale value. Activation has been prevented . |
| Error 6 | - Not used in the 4200. | |
| Error 7 | - 100V and }
1000V Ranges } | - Temporary message. The selected Voltage and Frequency exceeds the 4200 internal constraints. Activation has been prevented . |
| Error OL | - Voltage Ranges | - The output has been current-limited by an overload.
(If in 100V or 1000V range, OUTPUT is automatically switched OFF). |
| | - Current Ranges | - The terminal voltage has been compliance-limited to 3V.
(Load impedance too high) |
| FAIL 1 | - Excessive internal temperature. | FAIL 7 - 400V power supply fault - this 'trip' may reset itself if no hardware fault exists and the Fail message be temporary. |
| FAIL 2 | - Over-voltage. | |
| FAIL 3 | - Control data corrupted. | FAIL 8 - 38V power supply fault. |
| FAIL 4 | - Precision divider fault. | FAIL 9 - 15V in-guard power supply fault. |
| FAIL 5 | - Safety circuits tripped. | |
| FAIL 6 | - Calibration memory sumcheck non-parity. | |

SAFETY - Test Mode - Safety circuits tested by tripping: Press **Safety Reset** key to continue test.

running - Test Mode - Indicates test in progress.

PASS - Test Mode - **FAIL 6** did not occur during test of calibration memory parity, and **FAIL 2** did not occur during test of over-voltage thresholds.

Recalled Messages

ISSUE XX - Firmware issue number (selected by pressing **Error** then **-Lim**).

Addr XX - IEEE 488 Bus Address as set on Address switch (selected by pressing **Error** then **+Lim**).

Processor 'Busy'

The 4200 will not respond to commands while legend '**B**' is present on the **MODE** and **OUTPUT** displays except to override during safety delay.

KEY LEDs

Basic Indications:

- | | |
|--|---|
| Lit | - The labelled facility is selected and active. |
| Unlit | - The labelled facility is not selected. |
| Lit Green (Spec and Error only) | - Other MODE keys' facilities are reassigned to the secondary modes printed ABOVE their keys, as directed by the arrows. |
| Lit Green (Store only) | - FREQUENCY RANGE keys are reassigned to select F1-F5 memory stores. |

Warnings with Function V Selected:

OUTPUT RANGE 100V or 1000V LED flashing

- A voltage in **excess of 75V RMS** has been selected (**OUTPUT ON** or **OFF**).
- ON LED flashing while in Low Voltage State with OUTPUT ON**
- An attempt to select output in excess of 75V has been prevented.
- Repressing **OUTPUT ON** key will switch the **HIGH VOLTAGE ON**.

SECTION 5 SYSTEMS APPLICATION VIA THE IEEE 488 INTERFACE

Introduction

Section 5 gives the information necessary to put the 4200 into operation on the IEEE 488 bus. As some operators will be first-time users of the bus, the text is pitched at an introductory level. For more detailed information, refer to the standard specification, which appears in the publication ANSI/IEEE Std.488-1978.

Section Contents

The section is divided so as to group certain types of information together. These divisions are:

Interface Capability – the permitted options which have been implemented in the 4200.

Typical System – a brief view of a typical process using the 4200 to check a DMM calibration.

Using the 4200 in a System – implications of bus operation.

Programming Instructions – how the 4200 facilities have been transferred into remote commands.

Programming of Operational Functions – more detail about the codes which control 4200 operation.

Programming of Bus Transmissions – how to program the 4200 to obtain specific types of readout.

Service Request – why the 4200 needs the controller’s attention and how it gets it.

Activation of Commands – what the 4200 does with the commands it receives.

Operational Sequence Guidelines – a little general help with programming sequences.

INTERFACE CAPABILITY

IEEE Standard 488

The 4200 conforms to the Standard specification IEEE 488-1978 – ‘IEEE Standard Digital Interface for Programmable Instrumentation’.

It can be connected to the IEEE 488 Interface Bus and set into programmed communication with other bus-connected devices under the direction of a system controller.

Programming Options

The instrument can be programmed via the IEEE Interface, to:

- (1) Change its operational state (Range, Function, Frequency, Mode, Output, etc).
- (2) Transmit its own status data to other devices on the bus.
- (3) Request service from the system controller.

Capability Codes

To conform to the standard specification, it is not essential for a compatible device to encompass the full range of bus capabilities.

The IEEE 488 document describes and codes each of the standard bus features, so that manufacturers can provide brief coded descriptions of their own interfaces’ overall capability. A code string is often printed on the product itself.

The codes which apply to the 4200 are given in table 5.1, together with short descriptions. They also appear on the rear of the instrument next to the interface connector.

Appendix C of the IEEE 488 document contains a fuller description of each code.

Code	Interface Function
SH1	Source Handshake Capability
AH1	Acceptor Handshake Capability
T6	Talker (basic talker, serial poll, unaddressed to talk if addressed to listen)
TEØ	No Address Extension Talker Mode
L4	Listener (basic listener, unaddressed to listen if addressed to talk)
LEØ	No Address Extension Listener Mode
SR1	Service Request Capability
RL2	Remote/Local Capability (without Local Lockout)
PPØ	No Parallel Poll Capability
DC1	Device Clear Capability
DTØ	No Device Trigger Capability
CØ	No Controller Capability
E1	Open-Collector Drivers

Table 5.1 IEEE Interface Capability.

Bus Addresses

When an IEEE 488 system comprises several instruments, a unique 'Address' should be assigned to each to enable the controller to communicate with them individually.


One address is sufficient for a Datron instrument, as the controller can add information to it to define either 'talk' or 'listen'.

Interconnections

Instruments fitted with an IEEE 488 interface normally communicate through a set of interconnecting cables, specified in the IEEE 488-1978 Standard document.

The 4200's interface connector, J27, is fitted on its rear panel. It receives the specified connector, whose pin designations are also standardized and shown in Fig. 5.1 and Table 5.2.

Fig. 5.1 J27 Pin Layout



J27 Pin No	Name	Description
1	DIO 1	Data Input Output Line 1
2	DIO 2	Data Input Output Line 2
3	DIO 3	Data Input Output Line 3
4	DIO 4	Data Input Output Line 4
5	EOI	End or Identify
6	DAV	Data Valid
7	NRFD	Not ready for Data
8	NDAC	Not Data Accepted
9	IFC	Interface Clear
10	SRQ	Service Request
11	ATN	Attention
12	SHIELD	Screening on cable (connected to Safety Ground)
13	DIO 5	Data Input Output Line 5
14	DIO 6	Data Input Output Line 6
15	DIO 7	Data Input Output Line 7
16	DIO 8	Data Input Output Line 8
17	REN	Remote Enable
18	GND 6	Gnd wire of twisted pair with DAV
19	GND 7	Gnd wire of twisted pair with NRFD
20	GND 8	Gnd wire of twisted pair with NDAC
21	GND 9	Gnd wire of twisted pair with IFC
22	GND 10	Gnd wire of twisted pair with SRQ
23	GND 11	Gnd wire of twisted pair with ATN
24	GND	4200 Logic Ground (Internally connected to 4200 Safety Ground)

Table 5.2 IEEE 488-1978 Connector
- Pin Designations




Fig 5.2. Typical System

Typical System

A typical system is shown in Fig. 5.2. The system is directed by a controlling device able to:

- (a) '**Control**' (Issue commands)
- (b) '**Listen**' (Receive data)
- and (c) '**Talk**' (Transmit data)

EXAMPLE OF A SYSTEM IN OPERATION

In the system example (Fig. 5.2) the programmed task could be to check the DMM calibration against the 4200, and print out the results. The following is a typical sequence of events:

(1) The controller needs to instruct the 4200 to set its output to a calibration point for the DMM. These commands must not be received by the DMM or the printer and so the controller sends the general bus message '**Unlisten**'. When sending general messages, the controller makes all bus devices interpret any DIO-line data as configuration or data-flow commands, by holding the **ATN** line true.

(2) The controller then sends the 4200's **listen** address to force it to receive, followed by 4200 configuration commands (including the **Output Disable** message, to prevent the DMM receiving an inappropriate analog input). The instructions are passed along the **DIO** (data input-output) lines as coded messages (bytes). The code used is **ASCII** (American Std. Code for Information Interchange).

(3) Although the 4200 accepts the instructions as they are passed, their implementation takes a short time. The controller would perform other tasks during this period. In the example, it would pass configuring commands to the DMM, after 'Unlisten' and the DMM listen address have been sent.

(4) The DMM also needs time to settle into stable operation, so the controller performs other tasks while waiting, such as configuring the printer.

(5) The controller next generates 'Unlisten', addresses the 4200 as listener, and re-configures its Analog Output On by an **Output Enable** message. If the 4200 has executed its previous instructions, it sets **OUTPUT ON** immediately, otherwise the **OUTPUT** is set **ON** as soon as they have been executed. In either case, the instrument sends a message back to the controller via the **SRQ** (Service Request) management line, if programmed to do so.

(6) As the **SRQ** facility is available to all bus devices (Wired-OR function), the controller needs to discover which one sent the 'SRQ'. It therefore asks all devices one by one ('**serial poll**'), finds out that the 4200 is the **SRQ** source and that its **OUTPUT** is **ON**.

(7) It next addresses the DMM as a listener, and sends the **GET** message (Group Execute Trigger) via the **DIO** lines to initiate the reading. After a short delay for measurement, the DMM prepares output data and **SRQ**'s the controller when it is ready for transfer.

(8) The controller identifies the DMM by a serial poll. Finding that the reading is available, it sends the DMM's talk address, and printer's listen address, to activate both devices.

(9) The controller sets the **ATN** line false, thus releasing both devices to start the transfer. The DMM sends its data, byte by byte, via the **DIO** lines to the printer. This data must be in a form acceptable to the printer, and to ensure orderly transfer, each byte is transferred by '**Handshake**', using the three Transfer-Control lines.

(10) Usually the controller is also listening to this data transfer to determine when it is complete. As an aid to the controller and printer, the DMM can send another message with the last byte to be transferred (EOI-end or identify, using another bus management line).

(11) The sequence is complete, and the controller can start again at another calibration point.

The controller holds the **REN** line true when taking remote control. It can send an addressed command **GTL**, or some controllers can set **REN** false, to permit temporary manual control of a device. The **IFC** line is used at the discretion of the controller, to clear any activity off the bus.

Sequences such as this are often assembled into programs to check DMMs at many calibration points; changing functions, ranges and output levels as designed by the user. The program would also include 'display' messages to complete the printout in a recognisable form for the user's convenience. Programs must also cater for **FAIL** and **ERROR SRQ**s.

With a Datron Autocal DMM, other sequences can cause the DMM errors to be reduced until they are within specification, using its 'calibrate' mode.


Using the 4200 in a System

ADDRESSING THE 4200

Bus Address

The instrument address is set manually using a six way miniature switch near the interface connector on the rear panel. Five of the switches are used to set any address in the range 00 to 30, using a binary code.

e.g. Switch setting – ADD 11010 = ADDRESS 26



A5	A4	A3	A2	A1	Decimal Code
0	0	0	0	0	00
0	0	0	0	1	01
0	0	0	1	0	02
0	0	0	1	1	03
0	0	1	0	0	04
0	0	1	0	1	05
0	0	1	1	0	06
0	0	1	1	1	07
0	1	0	0	0	08
0	1	0	0	1	09
0	1	0	1	0	10
0	1	0	1	1	11
0	1	1	0	0	12
0	1	1	0	1	13
0	1	1	1	0	14
0	1	1	1	1	15
1	0	0	0	0	16
1	0	0	0	1	17
1	0	0	1	0	18
1	0	0	1	1	19
1	0	1	0	0	20
1	0	1	0	1	21
1	0	1	1	0	22
1	0	1	1	1	23
1	1	0	0	0	24
1	1	0	0	1	25
1	1	0	1	0	26 (e.g. above)
1	1	0	1	1	27
1	1	1	0	0	28
1	1	1	0	1	29
1	1	1	1	0	30

'ADD'

The sixth switch is provided for possible future variants. In the 4200, the position of the **ADD** switch is immaterial, as the normal bus addresses can be selected at either setting.

Addresses 0-30

With an address selected in the range 0 to 30 the instrument may be controlled manually, or remotely as part of a system on the Bus. The address selected must be the same as that used in the controller program to activate the 4200.

NB: The selected address can be temporarily displayed on the front panel when in manual control, by touching **Error** and then **Guard**.

Remote Operation

When the 4200 is operating under the direction of the controller, the legend **rem** appears on the mode display, and all front panel controls are disabled except **Power** and **Safety Reset**.

On entering remote, any earlier (manual) selection of **Error** mode is cancelled. During remote operation, the facilities of **Error** mode are excluded, as they can easily be programmed into the controller. **Spec** mode is also cancelled, but 'Spec' information can be obtained by bus command. There is no **Spec** mode display on the front panel during remote operation.

The 4200 power-up sequence is performed as for manual operation. After power-up, and on recovery from a power failure, the 4200 generates an **SRQ** and prepares an '**RQS Status Byte**' for transmission to the controller as a response to its subsequent **serial poll**.

Calibration Enable

A '**Calibration Enable**' command via the bus is required to set the instrument into its Remote Calibration mode (the **CALIBRATION ENABLE** keyswitch on the rear panel must already be set at **ENABLE**). Selection of any address 0-30 inhibits manual calibration from the front panel.

Address 31 (Illegal bus address)

This address configures manual operation only, inhibiting remote facilities. Address 31 **must** be selected (with **CAL** key set to **ENABLE**), for manual calibration to be carried out.

Table 5.3 Address Selection

Temporary Transfer to Local Operation (GTL)

The 4200 can be programmed to switch into ‘Local’ operation (Command GTL), permitting a user to take manual control from the front panel. The system controller regains ‘Remote’ control by sending the following overriding commands.

LAD with REN True

The controller addresses the 4200 as a listener with the Remote Enable management line true (Low). This returns the 4200 from local to remote control. Any commands which had been sent during the period under local control will then be executed.

SDC

Specific ‘Device Clear’ commands are sent over the bus, returning the 4200 to a predetermined state (described later in this section).


Programming Instructions

Programming Strings

From the example given earlier in this section it is evident that the 4200 requires an address code followed by a series of device-dependent messages or commands to alter its configuration.

A series of these commands can be sent together as a ‘program string’, each programming instruction being position-independent.

Each string will contain at least one programming instruction (detailed later in this section), but the 4200 must receive the string ‘terminator’ before it can activate any instructions. The required terminator for the 4200 is the ASCII character ‘=’.



To assist in eliminating incorrect programming instructions, the 4200 checks for errors in the string, and generates a service request (SRQ) if a syntax error occurs or if an option is called for but not fitted. To ensure that the programming string does not set up a prohibited state, it also checks the whole string for validity. If it finds any errors in this phase, the whole command string is ignored.

For Example:

With the 4200 set in 10mV Range, a string is received which contains an unacceptable command to switch Sense connection (‘S’ command). The user needs to set up a completely new, valid string; so the whole string is discarded.

Device-dependent commands

To give maximum scope for system programming, the bus operation of the 4200 differs in detail from manual operation, which is organized for ease of front panel use. Some functions of the 4200 firmware are deleted for bus operation, as they are easily programmed into the system controller; and extra functions have been made available to take advantage of the controller’s added computing power.

The following Alphabetic codes are used to establish the required functioning of the 4200 as a calibration source:

Full Range/Zero:	A
Safety Delay Override:	D
Output ON/OFF:	O
Function ACV, ACI:	F
Output Range in all Functions:	R
Output Value:	M
Frequency:	H
Spot Frequencies:	T
Sense:	S
Guard:	G
‘Calibrate’ trigger:	C
Calibration Mode Enable:	W

The following Alphabetic codes are used to select and configure the messages to be passed by the 4200 via the IEEE Bus:

Output string terminators:	K
Notation of output values:	L
Specification tolerances (relative: per unit):	P
Specification tolerances (absolute limits):	U
Recall/Verify (relative):	V
Service request origination:	Q
Diagnostic information:	X

Fig. 5.3 summarizes the way that front panel functions are transferred to system operation, and Table 5.4 lists the range of device-dependent command codes available.

CONTROL	CODE	DESCRIPTION
FULL RANGE ZERO	A0 A1	Zero Full Range but not if R0 set
CALIBRATION MODE	C0 C1 C2 C3	{ CAL - Calibration Trigger SET STD - See Section 8 PRECAL }
SAFETY DELAY	D0 D1	Safety delay active Safety delay override
FUNCTION	F1 F3	AC Voltage AC Current
GUARD	G0 G1	Local Guard Remote Guard
FREQUENCY	H***	Numeric value of frequency (frequency always autoranges) Default state is 1kHz
MEMORY (User's Aide Memoire)	I	Store next 16 ASCII characters, but excluding string terminator (Calibration Key set to ENABLE)
OUTPUT STRING TERMINATORS	K0 K1 K2 K3 K4 K5 K6 K7	Cr followed by Ll with EQl Cr followed by Ll Cr with EQl Cr Ll with EQl Ll EQl with last character No terminator
VALUE NOTATION (Output to bus)	L0 L1 L2 L3	Scientific plus legends Scientific with no legends Engineering plus legends Engineering with no legends
MAIN REGISTER	M***	Numeric value of Output setting Default State is 10% Full Range
OUTPUT	O0 O1	Output OFF Output ON
SPECIFICATION TOLERANCE	P0 P1 P2	24 hr 90 dy 1 yr } Output uncertainty
SERVICE REQUEST	Q0 Q1 Q2	SRQ on all specified states SRQ on Overload and Fail only No SRQ
OUTPUT RANGE	R0 R1 R2 R3 R4 R5 R6 R7 R8	Output Autorange - 100uA 1mV 1mA 10mV 10mA 100mV 100mA 1V 1A 10V 100V 1000V
SENSE	S0 S1	Local Sense Remote Sense
SPOT FREQUENCIES	T0 T1 T2 T3 T4 T5	Cancel Spot Frequency SF1 } Select Spot Frequencies SF2 } SF3 } (Frequencies depend on SF4 } Function and Output Range) SF5 }
SPECIFICATION TOLERANCE (Absolute Limits of Uncertainty)	U0 U1 U2 U3 U4 U5	24 hr 90 dy 1 yr } Output Low Limit to bus 24 hr 90 dy 1 yr } Output High Limit to bus.
RECALL/VERIFY	V0 V1 V2 V3 V4 V5 V6 V7 V8 V9	4200 Output value 4200 Frequency setting 4200 Status (command codes) Software Status (Part No - issue) F1 } Recall 'Stored' F2 } F3 } frequency value F4 } F5 } Recall previously-entered Error Mode gain factor.
CALIBRATION	W0 W1	Calibration Mode disable Calibration Mode enable (if Cal Key first set to ENABLE)
DIAGNOSTIC (Refer to Calibration and Servicing Hand- book for descrip- tion of correct process)	X0 X1 X2 X3 X4 X5 X6 X7 X8	- Not used Range gain correction string STD Cal Gain Factor Zero Offset } Reference Divider Gain Factor } corrections - Not used Corrected Reference Divider setting Gain Factor at the selected Spot Frequency Recall User-defined message




Table 5.4 4200 IEEE 488 Command Codes

DANGER

HIGH VOLTAGE



FRONT or REAR
terminals carry the
Full Output Voltage.

THIS CAN KILL !

READ THIS: For manual operation, the 4200 High Voltage Interlocks ensure that users employ deliberate actions before voltages in excess of 75V are generated at the OUTPUT terminals. In System applications, the same interlocks require the same deliberate commands to be received from the system controller. (But see Safety Delay Override command D1 in the text).

In manual operation the user who is exposed to danger from high voltages also has direct control of the 4200 output, but it is not possible to give the same degree of built-in protection to exposed users when the instrument is under remote program control. This danger is intensified by the high speed of remote programming, so it is **ESSENTIAL** that **WHENEVER THE 4200 IS BEING USED IN A SYSTEM TO GENERATE VOLTAGES IN EXCESS OF 75V, THERE MUST BE NO ACCESS TO THE 4200 FRONT PANEL OR REAR PANEL OUTPUT TERMINALS.**

Unless **you** are **sure** that
it is **safe** to do so,
DO NOT TOUCH the
I+ I- Hi or Lo leads
and **terminals**

DANGER

Programming of Operational Functions

OUTPUT ON/OFF

The analog OUTPUT is switched off by command **O0** (output disable), and switched on to the selected value by **O1**. The amplitude and frequency of the output are derived from the 'M' code and 'H' code data used to set the 'Main' (OUTPUT display), and 'Auxiliary' (MODE/FREQUENCY display) registers, respectively.

Safety Delay

The High Voltage Safety delay (3 seconds) is normally active (**D0**). It can be overridden by the command **D1**, but the use of this command sets up potentially dangerous situations. **D0** is enforced by any Function or Range change (including Autorange changes).

WARNING

DO NOT USE D1 UNLESS IT IS ESSENTIAL FOR HIGH SPEED OPERATION. TAKE SAFETY PRECAUTIONS TO PROTECT PERSONNEL IN THE VICINITY.

Function

F1 (AC Voltage) and **F3** (AC Current) configure the instrument to the required function.

Output Range

R1 through to **R8** configure the 4200 to specific ranges as shown earlier in Table 5.4. **R0** puts the instrument in auto-range function, allowing the output value to be specified as a number without setting the actual range. Ranging down occurs at 20% of range, i.e. Full Scale value of next lower range. Ranging up occurs at Full Scale. In autorange, commands **A0** and **A1** are invalid.

Output Display Value (Main Register)

In remote programming, the incremental $\uparrow\downarrow$ method of setting the output value is not used. Instead, Code **M******* is used to set the output value explicitly, either

in numeric, scientific or engineering notation (See Examples below). If the resolution is too high, the value is truncated to the correct resolution and the controller is informed by SRQ and RQS Status byte (see RQS status byte formats later in this section).

High Voltage Outputs

The change from Low to High voltage state is controlled by the same interlocks which govern the manual change-over (Refer to Section 4, page 4-7). To effect the change-over, the command string:

'M (followed by voltage) O1 = '

should be used if OUTPUT is already on and a range change is not involved. If a range change is programmed to set the output into high voltage state (for instance in **R0**) the 'O1' should be sent as a separate string.

If the M code alone is attempted (**M****... =**) with OUTPUT already enabled (**O1**), the new value is set in the Main Register (OUTPUT display); but the output voltage will not ramp to high voltage state until the enabling string '**O1 =**' is received.

If the attempt had been made with OUTPUT disabled (**O0**), then **O1** would be required in any case.

It should also be remembered that the AC output circuitry needs time to settle to its final value, especially if a range-change is incurred. Delays should be included in the controller program to allow for this.

During these processes, the front panel warnings of flashing LEDs and pulsing tones operate as for manual operation. Nevertheless, access to the front panel should be restricted because the high speed of programming in the IEEE interface adds to the safety hazard.

Examples of valid M codes:

Required Output Value	Function	Range	M Code	Output Display
153V	F1	R7	M153	153.000,0V
1.621257V	F1	R5	M1.6212574	1.621,257V (truncation to 6½ digits)
1.621257V	F1	R5	M1621257E-6	1.621,257V
1.621257V	F1	R0	M1621.257E-03	1.621,257V (Autorange to R5 = 1V)
0.002563A	F3	R0	M.002563	2.56300mA (Autorange to R3 = 10mA)

Output Resolution

The output resolution conforms to the following number of digits:

Ranges	100μ	1m	10m	100m	1	10	100	1000
Range Codes	R1	R2	R3	R4	R5	R6	R7	R8
Functions:								
AC Voltage F1	--	4 ₂ ¹	5 ₂ ¹	6 ₂ ¹	6 ₂ ¹	6 ₂ ¹	6 ₂ ¹	6 ₂ ¹
AC Current F3	6 ₂ ¹	6 ₂ ¹	6 ₂ ¹	6 ₂ ¹	6 ₂ ¹	--	--	--

Frequency Display Value (Auxiliary Register)

In remote programming, the incremental (↑↓) method of setting the frequency is not used. Instead, each auxiliary register value is input explicitly by Code **H ***...** in numeric, scientific or engineering notation.

The manual frequency 'Store' memories cannot be set via the bus, although their contents can be read using 'V' codes.

Frequency Resolution

Frequency is resolved to three significant digits (1% or 100ppm accuracy). On the display this occupies four digit spaces, to accommodate the decimal point. If the significance is greater than three digits, the value is truncated and the controller is informed by SRQ Status byte (see SRQ status byte formats later in this section).

Frequency and Voltage Constraints

On 100V and 1000V output ranges, the 4200 will refuse any command for an output which exceeds the limits defined on page 3-6. The controller is informed by 'Error 7' SRQ status byte (see SRQ status byte formats later in this section).

Spot Frequency Selection

Codes T1-T5 select the spot frequencies stored in **FS1-FS5** non-volatile memories. Sixty unique memory locations exist. Thirty-five are allocated to the seven Voltage output ranges and twenty-five to the five Current ranges: five for each range. The value of the frequency called up by any **T** command is therefore dependent on the preselected **F** and **R** codes.

With spot active, sending a new **R** code selects the corresponding spot frequency in the new range. A new **F** code, sent to change function, cancels the **T** command: the 4200 frequency reverts to 1kHz.

The controller is able to command an uncalibrated spot. The 'uncalibrated' message is displayed as in manual

operation, the 4200 frequency remaining as previously set. But in addition, the 4200 generates an SRQ to notify the controller. Code **T0** cancels any earlier spot frequency selection: the 4200 frequency reverts to 1kHz.

NB. The Spot Frequency facility is included to provide separate, ultra-accurately calibrated points in the 4200 output spectrum. Therefore, frequencies set into the 'spot frequency' memories can only be changed during the Autocal routine.

Guard and Sense

These are configured into Local or Remote by **G** and **S** codes:

- G0** - Local Guard
- G1** - Remote Guard
- S0** - Local Sense (forced when **F3** has been commanded, and when **F1** with **R2**, **R3**, or **R4** has been commanded).
- S1** - Remote Sense (available only when **F1** with **R5**, **R6**, **R7**, or **R8** has been commanded).

These bus commands are subject to the constraints of the the 4200 firmware. The instrument will reject and ignore invalid commands, such as **Remote Sense** when in **100mV** range.

Calibration Enable and Calibrate (W and C codes)

These are available for automatic calibration of the 4200, under remote control via the IEEE bus. Refer to the Calibration and Servicing Handbook.

- W0** - Calibration disable.
- W1** - Enable (only if **CALIBRATION ENABLE** keyswitch set to **ENABLE**).
- C0** - Calibration Trigger - equivalent to **CAL** key.
- C1** - As **SET** key.
- C2** - As **STD** key.

Refer to
Section 8.

Programming of Bus Transmissions

Output String Formation

The 4200 can be commanded to output 'internal' information to the system via the IEEE 488 bus, by sending one of the specified 'recall' messages.

Only one recall command should be included in a terminated string.


As well as the information it contains, the string needs to be formatted correctly for acceptance by the system. Many variations of format are available; These can be programmed for the type of system in use.

The length and construction of the string both depend upon the type of information to be transmitted, and thus upon the codes used to program the 4200. The purpose of this explanation is to describe the effects of these codes on the output string format.

Figure 5.4 illustrates the construction of a typical string, such as the 4200 output value. Notice that numerical data is reduced to a standard form, and scaled by means of an exponent in base 10. All device-dependent messages use the ASCII code.

Figure 5.4 Breakdown of a Typical Output String

(This is a general example – two specific 4200 examples appear on p5-12)



ASCII 'space'

A format character to denote the beginning of an output string – not present for recall command X8.

Polarity sign

Replaced by an ASCII space in the 4200. In instruments with DC functions, the appropriate polarity sign is presented.

Numeric sub-string

Length depends on the resolution of the information to be transmitted, and form depends on the notation programmed by 'L' code.

Exponent delimiter 'E'

Signifies that the numeric has finished and the next three bytes form the exponent.

Exponent value

The first of the three bytes is always '+' or '-'. Because the value is never greater than 9, the second byte is always 0, and the third is a single decimal digit.

Legends

Inclusion is optional, but if they are programmed in, two bytes are always present. The characters are appropriate to the programmed state of the 4200.

Terminators

Two terminating characters are available, as programmed by 'K' code. The EOI bus management line can optionally be programmed for simultaneous transmission with the last byte of the string.

Format Codes

The following pages list and describe the programming codes which determine the formation of the output string. The codes on page 5-11 select specific types of ASCII strings for retrieval.

Recall/Verify (code V).

By sending a **V** code the controller interrogates the 4200 to obtain information about its present status. Unless otherwise stated, the output strings are formatted as programmed by **K** and **L** codes. The **V** codes are as follows:

V0 – The present **Output** value.

V1 – The present **Frequency** setting.

V2 – The present **functional status**.

The response to **V2** is a standard ASCII string:

(space **R*F*O*G*S*W*Q*D*L*K*T*** terminator)

The functions are represented by the same numerics as for programming. In addition the Output Range is identified by a lower case 'r' if the 4200 is programmed in autorange.

V3 – Software status.

The software status is the part number and issue number of the internal program. This is formatted as follows, in response to command code **V3**:

(space **890052** – numeric terminator)

↑ ↑
Part No. **Issue No.**

(This status report is also available manually by pressing **Error** key then **Lim**—. The firmware issue-number is presented on the **MODE** display).

V4 to **V8** – 'Stored' Frequencies.

Codes **V4** to **V8** recall each of the five frequencies held in volatile memory locations **F1** to **F5**. These can only be set or selected manually. (Refer to page 3-7.)

V9 – Error Mode gain factor.

Error Mode cannot be programmed via the IEEE bus; but the gain factor which was produced at the most recent **Manual** use of Error Mode is still retained in volatile memory. Code **V9** can be used to recall this gain factor.

The range of legends transmitted by the 4200 is listed under 'Notations and Legends (**L** codes)'.

Specification Tolerance (Per unit – **P** codes).

The **P** commands give access to Spec mode over the bus, also setting the calibration interval:

P0 – 24 hour; **P1** – 90 day; **P2** – 1 year.

On being commanded by **P** code, the 4200 calculates the Output Uncertainty of its current state (as a 'per unit' fraction of the output value) and generates an output string formatted by **K** and **L** codes. Legends are transmitted as **pu** (per unit).

Absolute Limits of Tolerance

In this case, the **U** commands cause the 4200 to calculate the high or low limit of uncertainty of its output value against the nominated calibration interval.

U0 – Low limit 24 hour

U1 – Low limit 90 day

U2 – Low limit 1 year

U3 – High limit 24 hour

U4 – High limit 90 day

U5 – High limit 1 year

On being commanded, the calculated value is output by the 4200 in an output string formatted by **K** and **L** codes.

Diagnostic Information

The **X** commands recall the contents of certain non-volatile calibration memory locations. The values recalled are calibration constants stored at the most recent Autocalibration. They are used in the computations which establish the 4200 output level, as corrections for long-term drift in the analog circuitry.

X0 – Not used in 4200

X1 – Range gain correction string, comprising:

- a. LF gain factor
- b. HF calibration factor

X2 – 'STD' calibration gain factor

X3 – Zero offset } Reference Divider corrections

X4 – Gain factor }

X5 – Not used in 4200

X6 – Corrected Reference Divider setting

X7 – Gain factor at selected 'Spot' frequency.

X8 – Recall message which was memorized earlier by the operator using Code **I**.

Activating the Recall Transmission

The 4200 assembles the appropriate output string in its output registers in response to the **V**, **P**, **U**, or **X** command. It can subsequently be released onto the bus by addressing the 4200 as a talker.

String Formatting Commands (K and L Codes).

The output string can be formatted and terminated to adapt to user's requirements. Scientific or Engineering notation can be programmed, with or without descriptive Legends. Two examples are given below.

Codes **L0** to **L3** configure the output string notation:

L0 – Scientific notation with legends

L1 – Scientific notation, no legends

L2 – Engineering notation with legends

L3 – Engineering notation, no legends

Two sorts of terminator are available:

- a. One or two bytes can be added to the end of the string. These contain either Carriage Return (**Cr**) or Line Feed (**Lf**); or both in the order: **Cr** followed by **Lf**.
- b. The **EOI** bus management line can be programmed to set true simultaneously with the last byte of the string. **EOI** can be used even if both **Cr** and **Lf** are suppressed.

The 4200 can also be programmed to transmit strings without terminators. To accommodate these variations, the system programmer uses the **K** codes:

K0 – No suppression (**Cr**, **Lf** and **EOI** all present as terminators)

K1 – Suppress **EOI** (Terminator **Cr Lf**)

K2 – Suppress **Lf** (Terminator **Cr** with **EOI**)

K3 – Suppress **Lf** and **EOI** (Terminator **Cr**)

K4 – Suppress **Cr** (Terminator **Lf** with **EOI**)

K5 – Suppress **Cr** and **EOI** (Terminator **Lf**)

K6 – Suppress **Cr** and **Lf** (Terminator **EOI** with last character)

K7 – Suppress **Cr**, **Lf** and **EOI** (No terminators)

Examples of Typical 4200 Output Strings:

1. Scientific Notation (Codes **L0** and **L1**).

Bytes –	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
	Sp	Sp	0/1	.	0-9	0-9	0-9	0-9	0-9	0-9	E	+/-	0	0-9	V/A		Cr	Lf
Two ASCII spaces																		
Output Value Numeric:		0.000000 to 1.999999																
Output Value Exponent:		±(0 to 9)																
Legend(s):		(In this case code L0 was programmed.)																
Terminator(s):		(Code K1 programmed)																

2. Engineering Notation (Codes **L2** and **L3**).

Bytes –	1	2	3	4	5	6	7	8	9	10	11	12	13	14
	Sp	Sp	0/1	0-9 / .	0-9 / .	0-9 / .	0-9	0-9	0-9	0-9	E	+/-	0	0 /3 /6
Two ASCII spaces												EOI		- EOI line set true with last byte
Output Value Numeric: 0.000000 to 199.9999														
Output Value Exponent: ±(10 ⁰ /10 ³ /10 ⁶)														
Legend(s): (In this case L3 was programmed.)														
Terminator(s): (Code K6 programmed.)														

Descriptive Legends.

The following Legends will be fitted into the string after the exponent, if programmed by codes **L0** or **L3**:

Recall	Function	Legend	Meaning	Recall	Legend	Meaning
V0, U0-U5	F1	V	AC Volts	P0-P2	pu	per unit
V0, U0-U5	F3	I	AC Amps	V9	pu	per unit
V1, V4-V8	T0	Hz	Hertz			
V1, V4-V8	T1-T5	Sf	Spot freq. (Hz)			

Service Request

The 4200 can asynchronously request service from the controller by putting the **SRQ** line true (low).

SRQ is always generated by the action of switching the 4200 power ON, as the power-up default mode is **Q0**.

A user can program the 4200 to generate SRQs (or not) using command code Q:

- Code **Q0** - SRQ on any of the states in table 5.5
Q1 - SRQ on overload and any FAIL state in table 5.5
Q2 - No SRQs generated

Serial Poll and RQS Status Byte

If programmed for SRQ response, the bus controller will pause in its operation to attend to the service request. It first conducts a serial or parallel poll to determine which device initiated the SRQ. The 4200 does not react to parallel poll, but only to serial poll, during which each device is addressed in turn. The instrument responds to its serial-poll address by releasing a prepared 'RQS Status Byte' on to the bus. The RQS Request Bit (bit b7 of its status byte) is set true (Low) only if the 4200 has generated the SRQ. This validates the remainder of the byte, which describes the causal condition by the state codes listed in Table 5.5.

RQS Status Byte Composition

- bit **b8**: Indicates an option or syntax error when true.
- bit **b7**: The RQS request bit, when true, admits that the 4200 was the SRQ originator. The RQS status byte is not valid unless bit b7 is true.
- bit **b6 true**: Each combination of bits b5-1 represents a single state as listed in Table 5.5
- bit **b6 false**: Bits b5-1 each represent separate functional states within the 4200, and the RQS byte represents several states as listed in Table 5.5

Example with bit b6 false:

RQS status byte 01000001 represents:

- 0 - No option or Syntax error.
1 - This instrument originated the SRQ.
0 - The following bits each represent separate states.
0 - This bit is not used in the 4200.
0 - No High voltage warning.
0 - Auxiliary register not at limit.
0 - Main register not at limit.
1 - Output is ON.

The RQS status byte should not be confused with other status messages (e.g. 'calibrator' or 'software' status, described earlier under 'Recall/Verify') which are called up by the system controller's program.

DIO Line Transmissions

Providing **Q0** or **Q1** has been selected; when the 4200 has a message to transmit over the DIO lines, it sets the SRQ line true and prepares the 'Recall' RQS status byte (**x1100000**) ready for the subsequent serial poll. On receiving the status byte, the controller can address any device required to receive the data as a listener, and address the 4200 as a talker. Then the message is sent via DIO lines to the programmed listener(s).

Fail Messages

The 4200 needs to react quickly to internally-generated **FAIL** messages and is programmed to take rapid protective action. A fault condition may generate a train of such internal messages, which occur too quickly for some controllers to detect.

Such a train may be terminated by a **FAIL 5** message, which is detected by the controller. Thus the receipt of **FAIL 5** by a controller should be taken as a final default condition, and not as indicating the origin of the fault. The **FAIL 5** message can be cleared, if the 4200 has recovered, by pressing the **Safety Reset** key on the instrument front panel. As **FAIL 5** is related to safety, it cannot be reset by remote control.

Table 5.5 lists the possible RQS status bytes which may be transmitted by the 4200. The information in the byte is valid only if bit b7 (request bit) is true.

Legend: 1 = True, 0 = False, X = 1 or 0

bits	b8	b7	b6	b5	b4	b3	b2	b1	
1	1	X	X	X	X	X	X	X	Option or Syntax error
X	1	X	X	X	X	X	X	X	RQS Request-for-service bit

Combination Status Messages

X	1	0	X	X	X	X	1		Output ON
X	1	0	X	X	X	1	X		Main Register limit reached
X	1	0	X	X	1	X	X		Auxiliary Register limit reached
X	1	0	X	1	X	X	X		High Voltage Warning

Individual Status Messages

X	1	1	0	0	0	0	0		Recall message available
X	1	1	0	0	0	0	1		Error 1 Specification not displayable
X	1	1	0	0	0	1	0		Error 2 CAL mode: Output not ON
X	1	1	0	0	0	1	1		Error 3 CAL mode: Incorrect Range/Function
X	1	1	0	0	1	0	0		Error 4 CAL mode: Insufficient store span
X	1	1	0	0	1	0	1		Error 5 Error mode: Overscale output requested
X	1	1	0	0	1	1	0		Error 6 Not used on 4200
X	1	1	0	0	1	1	1		Error 7 100V/1000V: Output has been limited by internal Voltage-Frequency constraints
X	1	1	1	0	0	0	0		Fail 0 Fault condition rectified
X	1	1	1	0	0	0	1		Fail 1 Over-temperature
X	1	1	1	0	0	1	0		Fail 2 Over-voltage
X	1	1	1	0	0	1	1		Fail 3 Analogue control fault
X	1	1	1	0	1	0	0		Fail 4 Precision divider fault
X	1	1	1	0	1	0	1		Fail 5 Safety alarm
X	1	1	1	0	1	1	0		Fail 6 Cal. store sum check non-parity
X	1	1	1	0	1	1	1		Fail 7 400V power supply fault
X	1	1	1	1	0	0	0		Fail 8 38V power supply fault
X	1	1	1	1	0	0	1		Fail 9 15V In-guard power supply fault
X	1	1	1	1	1	0	1		Spot frequency not calibrated
X	1	1	1	1	1	1	0		Overload - Current or Voltage limit
X	1	1	1	1	1	1	1		Power-on

Table 5.5 Status Byte Coding

NOTES: (1) Power-up condition:

D0 F1 G0 H(1kHz) K0* L0* M(10%FR) O0 Q0 R0(10V) S0 T0 W0

*Device clear condition as power-up but K# and L# continue unchanged.

(2) Program string terminator: '=' activates preceding string.

Activation of Commands

Use of Terminator

The 4200 activates single or multiple commands, only on receipt of the recognised terminator. This is the ASCII character '='.

Commands or command strings may be received while the instrument is in Local control, but will not be activated even if a terminator is present, until the instrument is set to remote control. The two 'Clear' messages (**DCL** and **SDC**) will be activated even when in Local control.

Multiple Commands

Activation sequence

The input buffer has a capacity of 128 characters. Commands in a multiple string may be entered in any order, provided correct character syntax is observed. They are extracted from the buffer in received sequence and stored by alpha character into command stores. Any existing commands in the store are over-written and lost.

When a string terminator is received, the commands in the store are validated. Validation ensures that the proposed instrument state (consisting of those changes programmed and those current states not reprogrammed) is valid. Any error results in the string being ignored and a syntax error generated.

New commands are executed in this sequence:

L	Output notation
K	Output terminator format
Q	SRO Mode
W	Remote Calibration Enable
I	User message input
00	OUTPUT OFF
S	Sense
G	Guard
D	Safety Delay override
F	Function
R	Range
A	Full Range/Zero
T	Spot Frequency selection
M	Main Register value (Output)
H	Auxiliary Register value (Frequency)
01	OUTPUT ON
C	Calibrate Mode
P	Specification tolerance
U	Specification limits
V	Recall/Verify
X	Diagnostic information

A programmer may elect to change the sequence by inserting terminators between commands, but the basic constraints of the 4200 will still be imposed. For example, if the function is changed as a single command (e.g. **F3=**) the main program firmware will set **Output OFF** as a result, and it must then be re-programmed ON by the user.

Succession of Multiple Commands

If the input buffer is not full, new commands are accepted to await their turn for processing, and are extracted string by string. The input system design makes it extremely unlikely that the buffer will overflow, unless the 4200 is in Local Control and the command input is excessive. If this does cause the buffer to fill up, the 4200 places a hold on the IEEE bus handshake sequence. The command **IFC** can be used to release the hold, followed by **DCL** to clear the 4200 input buffer; but as a general principle, this situation should be avoided by suitable reprogramming.

Input Errors

Some unwanted commands are ignored. Others enter the input buffer and are rejected later.

'Read' commands

Before addressing the 4200 as a talker, it is essential that it has been programmed by a **P**, **U**, **V** or **X** command. Otherwise it will have no data to transmit.

Universal commands

LLO	(Local Lockout) - ignored, no capability
PPU	(Parallel Poll Unconfigured) - ignored, no capability for parallel poll.
SPE	(Serial Poll) - sets the 4200 to serial poll state, which when addressed responds with the RQS status byte. This byte contains the condition of the request-service bit (bit 7). If the 4200 is requesting service; bit 7 will be true, the other bits describing the service required.
SPD	(Serial Poll Disable) - returns the instrument to serial poll idle state.

Addressed commands

PPC	(Parallel Poll configure) - ignored, no capability
GET	(Group Execute Trigger) - ignored, no capability
TCT	(Take Control) - ignored, no capability
GTL	(Go To Local) - instrument returns to Manual Control. The controller regains remote control by addressing the 4200 as a listener with REN line true.

Clear Commands (DCL and SDC)

When the 4200 receives either of the two ‘Clear’ messages, (**DCL** is universal and **SDC** is addressed to a selected device) it will default to the predetermined state defined below. During the time taken to default, the IEEE interface handshake is held. These commands are effective even in ‘Local’ control.

A?	Not Active (see M code)
F1	AC volts
RØ	Autorange 10VAC default
M(value)	Where value is 10%FR(1V)
TØ	Cancel Spot Frequency
H(value)	Where value is 1kHz
GØ	Local guard
SØ	Local sense
OØ	OUTPUT OFF state
QØ	SRQ on all specified states
DØ	Safety delay active
WØ	Calibration disabled
C?	Not active – disabled by WØ
P?	Not active
U?	Not active
V?	Not active
X?	Not active
K*	Unchanged
L*	Unchanged

The frequency values held in ‘Store’ volatile memory locations F1-F5 are reset to the default state described on page 3-7.

Operational Sequence Guidelines

Most interface communication tasks require sequences of coded messages to be sent over the interface. Many controllers assign a single programming instruction to a complete sequence, so it is advisable to study the available controller capabilities carefully before attempting to program a system. Because the IEEE Std 488 (1978) allows a certain latitude in bus protocol, considerable differences may be found between programming instructions and operating sequences from one make of controller to another. Consequently, the following sequences are recommendations only.

Data Transfer

UNL	Inhibits all current listeners
LAD₁ LAD_n	Each address sent enables a specific device to receive future data bytes.
TAD	More than one address may be sent if multiple listeners desired. The address sent enables a specific device to send data. The 4200 must be already programmed to prepare data.
DAB₁ DAB_n	Data bytes sent by currently-enabled talkers to all currently-enabled listeners.
UNT	Disables the talker on receipt of the last character

UNL	=	unlisten
LAD	=	listen address of specific device
TAD	=	talk address of specific device
DAB	=	data bytes
UNT	=	untalk

Serial Poll

UNL	Inhibits all current listeners
SPE	Puts interface into serial poll mode during which all devices send status instead of data when addressed.
TAD_n	Enables a specific device to send status. Within this loop, devices should be sequentially enabled.
SBN or SBA }	Status byte sent by enabled device: If SBN, loop should be repeated. If SBA sent, the enabled device is identified as having sent SRQ and will automatically remove it.
SPD	Disables serial poll mode.
UNT	Disable last talker.

SPE	=	Serial poll enable
SPD	=	Serial poll disable
SBN	=	Status byte negative where bit 7 = 0
SBA	=	Status byte affirmative where bit 7 = 1

Untalk

It is highly desirable that a sequence which causes a device to be addressed as a talker should be terminated by an ‘untalk’ command.

SECTION 6 SPECIFICATIONS

General

POWER SUPPLY

Voltage	:	100/120/220/240V $\pm 10\%$
Line Frequency	:	48Hz to 62Hz
Consumption	:	400 VA normal 650 VA full power
Fuses 220/240V	:	3.15A
100/120V	:	6.25A

MECHANICAL

Dimensions	:	Height 178mm (7") Width 455mm (17.9") Depth 564mm (22.2")
Weight	:	35Kg (77lbs)

SAFETY	:	The 4200 has been designed to meet BSI 4743, IEC 384 and UL 1244 specifications
---------------	---	---

PEAK TERMINAL VOLTAGES

Guard to Ground	:	920V
Lo to Guard	:	920V
Lo to Ground	:	920V
Hi to Guard	:	1556V
Hi to Ground	:	1556V
Rear panel Digital Inputs –		
to Hi	:	1556V
to Lo	:	920V
to Guard	:	920V
to Ground	:	OV to +5V

N.B.

Digital Common is internally connected to Ground

ENVIRONMENTAL CONDITIONS

Operating temperature:	0°C to +50°C
------------------------	--------------

CAUTION. Above 30°C on 1kV Range: maximum output power available only intermittently.

Storage Temperature:	–40°C to +70°C
----------------------	----------------

Maximum Relative Humidity:	75% @ 40°C Non-Condensing
----------------------------	------------------------------

Warm-up Time: One hour to meet all specifications

OPERATING INDICATIONS

Indication	:	Symbols lit on displays and illuminated keys
------------	---	--

Scale Lengths

Output Display	:	6½ Digits maximum (e.g. 1.999999V)
----------------	---	---------------------------------------

Frequency Display	:	3 Digits plus store location.
-------------------	---	-------------------------------

Mode Display	:	6½ Digits maximum
--------------	---	-------------------

SETTLING TIMES to 100 ppm of Step Size †

10 – 31 Hz	< 10s
32 – 330 Hz	< 3s
< 330 Hz	< 1s

† Exceptions:

For Frequency Range or Output Range changes, Function changes, OFF/ON changes, and Frequency changes between 31 and 32Hz: the settling times are doubled.

Notes:

● In remote operation via the IEEE 488 Interface, hardware switching occurs under the control of 'H' (Frequency) codes. Any transfer (up or down) between the undermentioned frequencies must be regarded as a frequency range change. Settling time should be allowed as for 'Exceptions' above.

31 – 32Hz	33.0 – 33.1kHz
300 – 301Hz	330 – 331kHz
3.00 – 3.01kHz	

● For settling to 10ppm of Step Size, multiply all times by 1.5.

AC Voltage [7] [9]

Scale Lengths: 1mV – 100V Ranges: 9% to 200% of Range,
1000V Range: 9% to 110% of Range.

RANGE	FREQUENCY Hz	STABILITY [2]			SPOT FREQUENCY FULL RANGE ACCURACY RELATIVE TO CALIBRATION STANDARDS $\pm$ (ppm output) [1] 23°C $\pm$ 5°C		SPOT CALIBRATION UNCERTAINTY $\pm$ (ppm + μ V) [3]
		$\pm$ (ppm Output + ppm FS) [4]					
		10 Min	24 Hour	90 Day	90 Days	1 Year	
1.0000mV to 100.0000mV [10]	10 – 31	5 μ V	60 + 5 + 5 μ V	80 + 10 + 5 μ V	100 + 5 μ V	120 + 5 μ V	50 + 1
	32 – 330	5 μ V	30 + 5 + 5 μ V	40 + 10 + 5 μ V	60 + 5 μ V	90 + 5 μ V	50 + 1
	300 – 10k	5 μ V	20 + 5 + 5 μ V	30 + 10 + 5 μ V	50 + 5 μ V	70 + 5 μ V	50 + 1
	10k – 33k	5 μ V	20 + 5 + 5 μ V	30 + 10 + 5 μ V	50 + 5 μ V	70 + 5 μ V	200 + 1
	30k – 100k	5 μ V	30 + 5 + 5 μ V	40 + 10 + 5 μ V	60 + 5 μ V	80 + 5 μ V	500 + 1
	100k – 330k	5 μ V	80 + 10 + 5 μ V	150 + 20 + 5 μ V	200 + 5 μ V	350 + 5 μ V	600 + 1[6]
	300k – 1M	5 μ V	130 + 10 + 5 μ V	300 + 100 + 5 μ V	500 + 5 μ V	0.1% + 5 μ V	800 + 1[6]
1.000000V and 10.00000V	10 – 31	20 + 5	40 + 10	50 + 10	60	80	50
	32 – 330	5 + 2	20 + 5	30 + 10	50	60	20
	300 – 10k	3 + 1.5	15 + 5	20 + 10	40	50	20
	10k – 33k	3 + 1.5	15 + 5	20 + 10	40	50	30
	30k – 100k	3 + 1.5	20 + 5	30 + 10	50	60	50
	100k – 330k	5 + 2	50 + 10	70 + 20	100	150	200
	300k – 1M	7 + 3	120 + 10	300 + 100	500	0.1%	400
100.0000V	10 – 31	20 + 5	40 + 10	50 + 10	60	80	50
	32 – 330	5 + 2	20 + 5	30 + 10	50	60	20
	300 – 10k	3 + 1.5	15 + 5	20 + 10	40	50	20
	10k – 33k	3 + 1.5	15 + 5	20 + 10	40	50	30
	30k – 100k	3 + 1.5	20 + 5	30 + 10	70	80	50
	100k – 200k	10 + 2	50 + 10	70 + 20	150	200	200[6]
1000.000V 750V	45 – 330	10 + 3	50 + 5	70 + 10	80	130	50
	300 – 10k	5 + 2	30 + 5	40 + 10	60	100	60
	10k – 33k	5 + 2	50 + 8	60 + 10	80	120	100
	30k – 100k	10 + 3	80 + 10	120 + 20	150	200	500

- Notes:** [1] – For other than calibrated voltage, add ppm:
 $2 \times (\text{Wideband 'ppm FS'}) \times \left| \frac{\text{Calibrated Voltage} - \text{Output Voltage}}{\text{Output Voltage}} \right|$
 (See Example below). Spec Mode readout assumes that SPOT was calibrated at Full Range.
 [2] – For same conditions between 18°C and 28°C.
 [3] – Includes factory traceability to National Standards and National Standards uncertainty.
 [4] – FS = $2 \times \text{Nominal Range}$.
 [5] – Figures indicate pure THD only, excluding noise, which is included in the main specifications.
 THD is predominantly second harmonic; negligible error on mean-sensing instruments.
 [6] – Estimated, not fully traceable.
 [7] – Assumes typical thermal transfer measurement.
 [9] – Above 100kHz it is advisable to use 4-wire connection. This will reduce the possibility of inaccuracies caused by reactances of external and internal 2-wire connections.
 [10] – Measurements at millivolt levels can often be susceptible to RFI pickup. Generally, care is needed where the measurement bandwidth is greater than 5MHz. Rear output is not recommended for best performance in calibrating high bandwidth, low level instruments.

Spot Frequency Accuracy (Note [1]). Example of Calculation to obtain added tolerance figure if Spot output is not at the calibration point:

Calibration point: 10V Output on 10V Range. Present Output: 5V on 10V Range.
 Spot Frequency: 1kHz. Calibration Interval: 90 days.


For other than calibrated voltage, add ppm: $\frac{2 \times (10) \times |10 - 5|}{(5)} = \frac{20 \times 5}{5} = 20\text{ppm}$

New Tolerance = 40 + 20 = 60ppm (plus the calibration uncertainty).

WIDEBAND ACCURACY RELATIVE TO CALIBRATION STANDARDS		WIDEBAND CALIBRATION UNCERTAINTY ±(ppm + μV) [3]	TEMPERATURE COEFFICIENT ±ppm/°C (8°C-18°C and 28°C-40°C)	TOTAL HARMONIC DISTORTION % [5]	OUTPUT	
±(ppm Output + ppm FS) [4] 23°C ± 5°C					ZERO TO FULL LOAD REGULATION	OUTPUT CURRENT
90 Days	1 Year					
150 + 30 + 5μV 110 + 20 + 5μV 100 + 20 + 5μV 110 + 20 + 5μV 350 + 20 + 5μV 0.1% + 0.01% + 10μV 0.2% + 0.1% + 20μV	170 + 30 + 5μV 120 + 30 + 5μV 110 + 30 + 5μV 120 + 30 + 5μV 380 + 30 + 5μV 0.11% + 0.01% + 10μV 0.3% + 0.1% + 20μV	50 + 1 50 + 1 50 + 1 200 + 1 500 + 1 600 + 1[6] 800 + 1[6]	5 5 5 5 5 20 50	0.1 0.04 0.04 0.04 0.1 0.3 1.0	Output Resistance: 30Ω at all Frequencies	-
120 + 20 80 + 10 70 + 10 70 + 10 120 + 20 400 + 100 0.2% + 0.04%	140 + 30 90 + 20 80 + 20 80 + 20 150 + 20 500 + 100 0.3% + 0.04%	50 40 40 50 80 300 600	3 3 3 3 3 10 50	0.1 0.04 0.04 0.04 0.1 0.3 1.0	Typically 0.001%FS to 33kHz increasing to 0.2%FS at 1MHz	1V range – 25mA 10V range – 60mA
120 + 20 80 + 10 70 + 10 80 + 10 150 + 20 450 + 100	140 + 30 90 + 20 80 + 20 90 + 20 160 + 20 550 + 100	50 40 40 50 80 300[6]	3 3 3 3 5 20	0.1 0.04 0.04 0.04 0.2 0.3	Typically 0.001%FS to 33kHz increasing to 0.01%FS at 200kHz	120mA
120 + 25 100 + 25 150 + 25 850 + 50	180 + 25 140 + 25 180 + 25 0.1% + 50	50 60 100 500	5 5 5 7	0.2 0.1 0.1 0.5	Typically 0.001%FS to 33kHz increasing to 0.005%FS at 100kHz	< 1kHz – 15mA > 1kHz – 65mA


OTHER SPECIFICATIONS

- Minimum Load Resistance in 4-wire Connection - Maximum Load Capacitance - Frequency Accuracy - Frequency Constraints - Voltage Sensing - Guarding - Common Mode Rejection	Ten times total resistance of I+ and I– leads, Absolute Minimum 20Ω. 1000pF. However, drive limited by output current (see graph on page 6-5). <100ppm; typically <10ppm. Refer to graph on page 6-4. Selectable remote or local sensing on 1V to 1000V ranges Selectable remote or local Guard connection. Max. Guard to Ground voltage 650VRMS (2.5kV flash test). 140dB at DC to 400Hz
---	---



Capacitive Loading Constraints

Volt-Hertz Power Limit versus Capacitance Load (1kV Range)



Option 30 – AC Current ^[7]

Scale Length; 9% to 200% of Range

RANGE	MAXIMUM LOAD RESISTANCE	FREQUENCY Hz	STABILITY [2] ±(ppm Output + ppm FS) [4]			SPOT FREQUENCY ACCURACY AT FULL RANGE RELATIVE TO CALIBRATION STANDARDS ±(ppm Output) [1] 23°C ± 5°C	
			10 Min	24 Hour	90 Day	90 Days	1 Year
100.0000μA	15kΩ	10 – 1k 1k – 5k	30 + 10 50 + 20	50 + 20 70 + 30	70 + 30 100 + 40	150 200 [8]	250 300 [8]
1.000000mA	1.5kΩ	10 – 1k 1k – 5k	30 + 10	50 + 20	70 + 30	120	220
10.00000mA	150Ω	10 – 1k 1k – 5k	30 + 10	50 + 20	70 + 30	120	220
100.0000mA	15Ω	10 – 1k 1k – 5k	30 + 10	50 + 20	70 + 30	120	220
1.000000A	1.5Ω	10 – 1k 1k – 5k	30 + 10 50 + 20	50 + 20 70 + 30	70 + 30 100 + 40	150 200 [8]	250 300 [8]

Notes: [1] – For other than calibrated current, add ppm:

$$2 \times (\text{Wideband 'ppm FS'} \times | \text{Calibrated Current} - \text{Output Current} | / (\text{Output Current}))$$

 Spec Mode readout assumes that SPOT was calibrated at Full Range.
 For example of calculation, refer to page 6-2.

[2] – For same conditions between 18°C and 28°C.

[3] – Includes factory traceability to National Standards and National Standards uncertainty.

[4] – FS = 2 × Nominal Range.

[5] – Figures indicate pure THD only, excluding noise, which is included in the main specifications.
 THD is predominantly second harmonic; negligible error on mean-sensing instruments.

[7] – Assumes typical thermal transfer measurement.

[8] – Assumes similar load time constant to that at calibration.

WIDEBAND ACCURACY RELATIVE TO CALIBRATION STANDARDS ± (ppm Output + ppm FS) [4] 23°C ± 5°C 90 Days 1 Year		SPOT AND WIDEBAND CALIBRATION UNCERTAINTY ± (ppm) [3]	TEMPERATURE COEFFICIENT ± ppm/°C (8°C-18°C and 28°C-40°C)	TOTAL HARMONIC DISTORTION % [5]	TYPICAL OUTPUT IMPEDANCE	OUTPUT COMPLIANCE
400 + 50 550 + 80 [8]	500 + 80 650 + 100 [8]	200 500	10 20	0.2 0.5	100MΩ *	All Ranges: 3V RMS max. 1mH max. L or CR R time const. < 1μsec.
220 + 50 350 + 50	350 + 80 450 + 80	100	10	0.2	30MΩ	
220 + 50 350 + 50	350 + 80 450 + 80	100	10	0.2	3MΩ	
220 + 50 350 + 50	350 + 80 450 + 80	100	10	0.2	300kΩ	
400 + 50 550 + 80 [8]	500 + 80 650 + 100 [8]	100 200	20 25	0.2 1.0	30kΩ **	

*: Typical effective output capacitance = 200pF
**: Typical effective output capacitance = 0.5μF

} Negligible on other Ranges.

OTHER SPECIFICATIONS

<100ppm; typically 10ppm.	Frequency Accuracy
10nF	Maximum Load Capacitance
1mH, <μ1μsec	Maximum Load Inductance

SECTION 7 SPECIFICATION VERIFICATION

Introduction

The factory calibration of the 4200 ensures traceable accuracy to national standards. Figures of performance are quoted in the specifications of Section 6, related to time since calibration.

This section deals with user-verification of the 4200 performance to specification.

Choice of Verification Method

The wide dynamic range of the 4200 makes it necessary to employ different verification methods for different groups of output and frequency ranges.

For instance: The most common method of verifying AC Voltage outputs is to check against an accurate DC Voltage Standard via a Thermal Transfer. However, available thermal transfer standards are not suitable for direct verification of the millivolt ranges, because their transfer elements are insufficiently sensitive.

Naturally, the range, accuracy and traceability of users' standards governs the degree to which the performance of any new equipment can be verified. This is especially true for the 4200, in view of the range of the parameters to be checked.

This section describes a recommended method of verifying each of the parameters listed below. Where appropriate, alternative methods are described in Appendices to the section.

Parameters to be Verified, with Recommended Methods

The following list of parameters is grouped according to the type of equipment suitable for verification.

1. Voltage Ranges (1V to 1000V)

- a. Full Range values are verified at LF and HF by direct thermal transfer against a DC Voltage Standard.
- and
- b. Instrument Linearity is verified at 1V, 10V and 19.99999V on the 10V range at LF, using the same method.

2. Millivolt Ranges (1mV to 100mV).

Full Range values are verified as follows:

- a. **At LF:**
Commercially available Inductive Voltage Divider, and standardized DVM Transfer. (Such 'IVD's are normally only suitable for LF verification, up to about 5kHz).
- and
- b. **at HF:**
A 100% to 10% of Range Transfer method, after verifying 10V range HF linearity and 1V HF Full Range value. A DVM is standardized and corrected for linearity error, then used as a transfer standard. The method is described later in this section.

An alternative method is described at Appendix 2 for users in possession of a Wideband (to 100kHz) Inductive Voltage Divider (WIVD)

3. Current Ranges (1mA to 1A).

- a. 10mA, 100mA and 1A Full Range values are checked using a Thermal Transfer Standard fitted with standard shunts at LF and HF, against a DC Current Standard.
- and
- b. The 1mA Full Range value can be checked using the same method, provided that low-current shunts for the thermal transfer standard are available.

Alternatively, if calibrated AC current shunts are available, the Current Ranges can be verified by voltage measurement, using an AC DVM, as described in Appendix 3.

Fixed or Adjustable Voltage Standard?

Many users who are able to verify AC Voltage and Current to the accuracy required for the 4200, will also have access to an adjustable DC Voltage Standard as Reference. In these cases their 4200 can be verified at cardinal values. For users with fixed DC Voltage Standards only, the 4200 can be verified at non-cardinal values directly or by using the 4200 'Error Mode'. In both cases users will need to calculate the effects of their own Standards' uncertainty, so calculations for total tolerance limits are given in Appendix 4.

Summary of Equipment Requirements

This summary relates to the recommended method of verifying the 4200. Alternative methods, with the required equipment, are described in appendices.

AC VOLTAGE (1V – 1000V Full Range Values and 10V Range Linearity)

An Adjustable DC Voltage Source of suitable accuracy.

Example:

Datron 4000 or 4000A Autocal Standard.

An AC/DC Thermal Transfer Standard capable of operating over the range 1V to 1100V RMS.

AC MILLIVOLTS (1mV – 100mV Full Range Values)

at LF;

A commercially-available Inductive Voltage Divider tapped at 10:1, 100:1 and 1000:1 of suitable accuracy and frequency response.

at HF;

The 4200 under test with the correction figure for 10% of its 10V Range at HF.

The DC Voltage Source used for 1V – 1000V ranges

and at both LF and HF;

The AC/DC Thermal Transfer used for 1V – 1000V ranges.

A DVM of suitable accuracy and frequency response.

Example:

Datron 1081 or similar.

AC CURRENT (1mA – 1A Full Range Values)

A DC Current Source of suitable accuracy and an AC/DC Thermal Transfer together with a set of Calibrated Thermal Transfer Current Shunts of suitable accuracy.

For the alternative method at Appendix 3, a set of calibrated AC Current Shunts of suitable value and accuracy.

Summary of Verification Procedures

1. Full Range Voltage (1V – 1000V Ranges)

Adjustable DC Standard

The 4200 is connected up and set to output a Full Range voltage at the required frequency (or Spot Frequency). The Thermal Transfer is nulled against the 4200 Full Range voltage. The DC Standard is adjusted to null with the Thermal Transfer, and its output voltage recorded. Its uncertainty is also recorded, and the Tolerance Limits calculated. The 4200 is verified if the DC voltage is within the tolerance limits.

Details of the procedure are on page 7-5.

Fixed DC Standard

The Thermal Transfer is nulled against the DC Standard, and its fixed voltage is recorded on the Report Sheet. The 4200 **OUTPUT** display is set to this voltage, the **Spec** Mode tolerance is recorded, and the **Tolerance Limits** are calculated. The 4200 output voltage is adjusted to null with the Thermal Transfer, and its displayed voltage is recorded and checked against the tolerance limits.

See Appendix 1 for the procedure.

2. Linearity (Performed on 10V Range)

Should be checked at 1V, 10V and 19.99999V in turn, or at user's Reference standard voltages close to the above values. Similar techniques are used as for Full Range voltages. For each check the results are recorded.

See page 7-5 or Appendix 1 for the procedure.

3. Full Range Voltage (1mV – 100mV Ranges)

Method 1

At **LF**, the 1V Full Range value is first verified using thermal transfer, then this voltage is divided via the standard IVD to standardize an AC DVM at the millivolt Full Range value. The 4200 millivolt range is then verified at this standardized value by DVM measurement.

See page 7-6 for the procedure.

At **HF**, the 4200 is set to the 10V Range. Outputs are measured at 10V at 1V using thermal transfer, and a linearity correction factor is calculated for the 1V output.

The 1V Range is selected with output set to 100mV at HF. The output setting is changed by the correction factor and the output is used to standardize the AC DVM.

The 100mV Range is selected at HF Full Range, and the output measured on the DVM. The 100mV Full Range value verifies if the DVM reading is the corrected value, plus or minus the specified tolerances.

The DVM is standardized again at 10mV on the 100mV Range, and used to verify the 10mV Full Range in the same way. The process is repeated to verify the 1mV Range.

See page 7-7 for the procedure.

Method 2

At both LF and HF, the 1V Full Range value is first verified using thermal transfer, then this voltage is divided via the wideband IVD to standardize an AC DVM at the millivolt Full Range value. The 4200 millivolt range is then verified at this standardized value by DVM measurement.

See Appendix 2 for the procedure.

4. Full Range Current (Using Standard Shunts)

The Thermal Transfer Current Shunt is fitted to the Shunt Input of the Thermal Transfer Standard and the 4200 set to output a Full Range current into the shunt at the required frequency (or Spot Frequency). The output current is split between the shunt and the transfer element. This is compared with the output from a Standard DC Current Source.

See Page 7-8 or Appendix 1 for the procedure.

Alternative Method

The 4200 is connected up and set to output a Full Range current into the calibrated AC Current Shunt at the required frequency (or Spot Frequency). The 4200 Current output develops a voltage across the shunt which is measured by the AC DVM, with care taken not to load the shunt.

The procedure is detailed in Appendix 3.

Specification Verification Procedures

Preparation

Before attempting any verification ensure the following steps are carried out.

1. Turn on the instrument to be checked and allow minimum of 2 hours to warm-up in the specified environment.

2. Ensure familiarity with normal operation as described in this Handbook.

3. Cancel any MODE Keys, ensure OUTPUT OFF and check that 'cal' is not present on the MODE display. (If 'cal' is present, turn the Calibration Keyswitch on the Rear Panel to its RUN position.
4. Self-Test: select Test to carry out the test routine described in Section 4. Terminate the test routine.

5. Consult the manufacturer's handbooks before connecting and operating any equipment in the measurement system.

6. Interconnections and Guarding: Refer to Section 4 page 4-2.

7. Select 24hr, 90dy or 1yr on the CALIBRATION INTERVAL Switch. Refer to Section 4 page 13.

Index of Recommended Procedures (using adjustable DC Voltage Standard)

Voltage Ranges (1V to 1000V)

- a. Full Range Values7-5
- b. Instrument Linearity (10V Range)7-5

Millivolt Ranges (1mV to 100mV)

- a. LF7-6
- b. HF7-7

Current Ranges (1mA to 1A)7-8

Report Sheet RS17-9

Alternative Procedures

As Recommended but using Fixed DC Voltage Source (with Report Sheet RS2)	Appendix 1
Millivolt Checks using Wideband IVD	2
Current Checks using Calibrated AC Shunts	3
Total Tolerance Limit Calculations	4
Uncertainty and Traceability	5
General Procedural Information	6
Harmonic Distortion Measurement	7

AC Voltage Verification Procedure

(Using Adjustable DC Voltage Calibration Standard)

Record Results on Report Sheet RS1 (page 7-9)

Full Range Checks (1V–1000V)



WARNING

THE TERMINALS MARKED WITH THE ⚡ SYMBOL CARRY THE OUTPUT OF THE 4200. THESE TERMINALS AND ANY OTHER CONNECTIONS TO THE LOAD UNDER TEST COULD CARRY LETHAL VOLTAGES. UNDER NO CIRCUMSTANCES SHOULD USERS TOUCH ANY OF THE FRONT (OR REAR) PANEL TERMINALS UNLESS THEY ARE FIRST SATISFIED THAT NO DANGEROUS VOLTAGE IS PRESENT.

- With **OUTPUT OFF**, connect the DC Voltage Standard to the Thermal Transfer DC input. Use 4-wire connection and Remote Sense if available.
- With **OUTPUT OFF**, connect the 4200 to the Thermal Transfer AC input. Use 4-wire connection and Remote Sense.
- Configure the Thermal Transfer for AC measurement at the required voltage.
- Set the 4200 **OUTPUT Range**, **Voltage** and **Frequency** (see RS1).
- Set 4200 **OUTPUT ON**, and null the Thermal Transfer to the 4200 **AC OUTPUT**.
- Configure the Thermal Transfer for DC nulling.

g. Configure the DC Voltage Standard at the required voltage, set its **OUTPUT ON** and adjust its output voltage to null the Thermal Transfer. Record its output voltage on RS1.

h. Repeat (c) to (g) for all 4200 outputs on RS1 Tables 1(a) and 1(b).

j. Sum the Verification setup uncertainties and record in the **Us** column as voltage deviations. (Refer to Appendix 5).

For Total Tolerance Limit Calculations Refer to Appendix 4 page 7-A4-1, para 1.

k. Calculate the lower and Upper Total Tolerance Limits. Use Calculation A if the 4200 was last calibrated by Datron. Use Calculation B if the 420 was last calibrated against the standards being used for verification.

l. Each 4200 Full Range output is verified if the DC Voltage outputs recorded in (g) are at or between the corresponding Total Tolerance Limits.

Linearity (10V Range)


m. If the 10V Range verified correctly, repeat operations (c) to (g) for RS1 Table 1(c).

n. If the 1V and 10V Ranges verified, proceed to AC Millivolt verification and AC Current verification.


Millivolts (LF) Verification Procedure

(Using verified 4200 1V Range, Inductive Voltage Divider (IVD) and AC DVM)

Record results on Report Sheet RS1, table 2(a) (Page 7-10).



Standardization of DVM Millivolt Ranges



Verification of 4200 LF Millivolt Ranges

- a. With **OUTPUT OFF**, connect the 4200, IVD and DVM for Standardization. Set the IVD ratio to 1:10, the AC DVM to measure 100mV.
 - b. Set 4200 to 1V Range, 1kHz, and adjust for corrected 1.000000V output.
 - c. Set 4200 **OUTPUT ON** and note the DVM reading as **V1**.
 - d. Set 4200 **OUTPUT OFF**, and reconnect the test circuit for Verification.
 - e. Set the 4200 **OUTPUT RANGE** to 100mV and adjust the **OUTPUT Display** to 100.0000mV.
 - f. Set 4200 **OUTPUT ON** and adjust the **OUTPUT** $\uparrow/\downarrow$ keys for a DVM reading of **V1**.
 - g. Record the 4200 **OUTPUT Display** setting in the last column of RS1 Table 2(a).
 - h. Repeat (a) to (g), but setting the 4200, IVD ratio and DVM as required to verify the 10mV and 1mV Full Range outputs; still using the corrected 1V Full Range output in (b). Record the results on RS1 Table 2(a).
 - j. Sum the Verification setup uncertainties and record in the **Us** column as voltage deviations. (Refer to Appendix 5).
- Total Tolerance Limit Calculations** Refer to Appendix 4 page 7-A4-1, para 1.
- k. Calculate the Lower and Upper Total Tolerance Limits:
Use Calculation **A** if the 4200 was last calibrated by Datron.
Use Calculation **B** if the 4200 was last calibrated against the standards being used for verification.
 - l. The 4200 mV Full Ranges are verified if each of the 4200 **OUTPUT Display** settings recorded at (g) are at or between the corresponding **Total Tolerance Limits**.


Millivolts (HF) Verification Procedure

(Using verified 4200 1V and 10V Ranges, 10% Range Correction Factor and AC DVM)

Record results on Report Sheet RS1, Table 2(b) (Page 7-10).

Full Range Checks (1mV – 100mV at 1MHz)

Standardization of DVM 100mV Range (on 1V Range only, use 4-wire connection in Remote Sense)



Verification of 4200 HF 100mV Range



N.B. These verification checks are not fully traceable.

- Ensure that the 4200 has been verified at 10V and 1V HF (1MHz) Full Range, and that the actual values are registered on the Report Sheet RS1 as 'User's Standard Value for Null'.
- Verify the 10V Range at 1V 1MHz using the Thermal Transfer as on page 7-5. Note the Output value.
- Divide the actual output at 10V [V1] by the actual output at 1V [V2], then divide the result by 10. This gives the '10% of Range Correction Factor', C, within the following limits:

$$0.99953 < C = \frac{V1}{10 \times V2} < 1.00047$$

This factor subsequently corrects a DVM measurement at 10% of one range, to standardize the DVM for verification of the next millivolt range down.

- With OUTPUT OFF, connect the DVM to the 4200 terminals as shown above, but using 4-wire connections in Remote Sense.
- Set the 4200 for an output of 100mV at 1MHz on the 1V Range. Set the DVM to measure 100mV.
- Set 4200 OUTPUT ON and note the DVM reading. Multiply the reading by 'C', and note the result as Vc. (If the DVM being used is a Datron Autocal instrument, the Maths function can do this automatically).

- Set 4200 OUTPUT OFF, reconnect as 2-wire, (the 4200 will automatically default to 2-wire and internal sensing on the millivolt Ranges). Select 100mV Range at 1MHz , and set OUTPUT display to 100mV.
- Set the 4200 OUTPUT ON and adjust the OUTPUT $\uparrow\downarrow$ keys for a reading of Vc on the DVM.
- Record the 4200 Output Display setting in the last column of RS1 Table 2(b).
- Repeat (e) to (j), but standardizing the DVM at 10mV on the 100mV range, and checking 10mV on the 10mV range.
- Repeat (e) to (j), but standardizing the DVM at 1mV on the 10mV range, and checking 1mV on the 1mV range.
- Sum the Verification setup uncertainties and record in the Us column as voltage deviations. (Refer to Appendix 5).

For Total Tolerance Limit Calculations

Refer to Appendix 4 page 7-A4-1 para 1.


- Calculate the Lower and Upper Total Tolerance Limits:
Use Calculation A if the 4200 was last calibrated by Datron.
Use Calculation B if the 4200 was last calibrated against the standards being used for verification.
- Each 4200mV Full Range is verified if the 4200 OUTPUT Display settings recorded in RS1 Table 2(b) are at or between the corresponding Total Tolerance Limits.

Current Verification Procedure

(Using Thermal Transfer, Current Shunts and DC Current Standard)

Record results on Report Sheet RS1, Table 3 (Page 7-10)

Full Range Checks (1mA – 1A)



- With 4200 **OUTPUT OFF**, set the Function to I, **OUTPUT RANGE** to 10m, **OUTPUT Display** to 10.00000mA at a Frequency of 300Hz.
 - Configure the Thermal Transfer for 10mA Current measurement and connect the appropriate shunt.
 - With **OUTPUT OFF**, connect the 4200 I+ and I- terminals across the Shunt.
 - Set 4200 **OUTPUT ON**, and null the Thermal Transfer to the 4200 AC **OUTPUT**. Set 4200 **OUTPUT OFF**.
 - With **OUTPUT OFF**, configure the DC Current Standard for an output of 10mA, and connect across the Transfer Shunt.
 - Set the DC Standard **OUTPUT ON** and adjust its output current to null the Thermal Transfer. Record its output current on RS1 Table 3(a).
 - Set 4200 Frequency to 5kHz, and repeat (c) to (f).
 - Repeat (a) to (g), but for 4200 100mA and 1A Full Range outputs.
 - If the Thermal Transfer has been adequately calibrated for 1mA transfers, repeat (a) to (g) for 4200 1mA Full Range outputs, recording the DC Standard output currents in RS1 table 3(b).
 - Sum the Verification setup uncertainties and record in the **Us** column as current deviations. (Refer to Appendix 5).
- ### For Total Tolerance Limit Calculations
- Refer to Appendix 4 page 7-A4-1 Para 1
- Calculate the Lower and Upper Total Tolerance Limits.
Use Calculation **A** if the 4200 was last calibrated by Datron
Use Calculation **B** if the 4200 was last calibrated against the standards being used for verification.
 - Each 4200 Full Range output verifies if the DC Current outputs recorded in (f) are at or between the corresponding Total Tolerance Limits.

Verification Report Sheet. RS1

Model 4200

RS1 – For Users with Adjustable DC Voltage Standards.

Serial Number Calibration Interval 90 days Specification Accuracy

Date..... Checked by Company/Dept.....

Note – On receipt of the instrument it is recommended to check at the frequencies shown below.

1. AC VOLTAGE (Using Adjustable DC Voltage Standard via Thermal Transfer)

a. 1V to 1000V Ranges.

4200 OUTPUT RANGE/ FREQUENCY	4200 Nominal OUTPUT Voltage	Wideband Relative Accuracy Tolerance Limits		Datron Cal. Std. Uncert'y ±Ud (Abs)	User's Cal. Std. Uncert'y. ±Us (Abs)	Wideband Calculated Total Tolerance Limits		User's DC Standard value for Null
		Lower(Lr)	Upper(Ur)			Lower	Upper	
1V 1kHz	1.000000V	.999910	1.000090	0.000040V				
1V 1MHz	1.000000V	.996000	1.004000	0.000600V				
10V 1kHz	10.00000V	9.99910	10.00090	0.00040V				
10V 1MHz	10.00000V	9.96000	10.04000	0.00600V				
100V 1kHz	100.0000V	99.9910	100.0090	0.0040V				
100V 100kHz	100.0000V	99.9810	100.0190	0.0080V				
1000V 1kHz	1000.000V	999.850	1000.150	0.060V				
1000V 30kHz	1000.000V	999.800	1000.200	0.100V				

b. 700V at 100kHz.

1000V 100kHz	700.000V	699.305	700.695	0.350V				
--------------	----------	---------	---------	--------	--	--	--	--

c. Linearity (Performed on 10V Range)

10V 1kHz	1.00000V	0.99973	1.00027	0.00004V				
10V 1kHz	10.00000V	9.99910	10.00090	0.00040V				
10V 1kHz	19.99999V	19.99839	20.00159	0.00080V				

2. AC MILLIVOLTS 1mV to 100mV Ranges.

a. LF 1kHz (Using Verified 1V Full Range, Inductive Voltage Divider and AC DVM)

4200 OUTPUT RANGE	4200 Nominal OUTPUT Voltage	Wideband Relative Accuracy Tolerance Limits Lower(Lr) Upper(Ur)		Datron Cal. Std. Uncert'y. ±Ud (Abs)	User's Cal. Std. Uncert'y. ±Us (Abs)	Wideband Calculated Total Tolerance Limits Lower Upper		4200 OUTPUT Display Setting
100mV	100.0000mV	99.9810	100.0190	0.0060mV				
10mV	10.0000mV	9.9936	10.0064	0.0015mV				
1mV	1.0000mV	.9949	1.0051	0.0011mV				

b. HF 1MHz (Using Verified 1V and 10V Full Range, 10% Range Correction and AC DVM)

100mV	100.0000mV	99.5950	100.4050	0.0810mV				
10mV	10.0000mV	9.9550	10.0450	0.0091mV				
1mV	1.0000mV	.9910	1.0090	0.0015mV				

a. 10mA to 1A Ranges. (Using Thermal Transfer, Current Shunts and DC Current Standard)

4200 OUTPUT RANGE/ FREQUENCY	Transfer Shunt Value	Wideband Relative Accuracy Tolerance Limits Lower(Lr) Upper(Ur)		Datron Cal. Std. Uncert'y. ±Ud (Abs)	User's Cal. Std. Uncert'y. ±Us (Abs)	Wideband Calculated Total Tolerance Limits Lower Upper		User's DC Standard value for Null
10mA 300Hz	9.99580	10.00420	0.00100mA					
10mA 5kHz	9.99450	10.00550	0.00100mA					
100mA 300Hz	99.9580	100.0420	0.0100mA					
100mA 5kHz	99.9450	100.0550	0.0100mA					
1A 300Hz	.999400	1.000600	0.000100A					
1A 5kHz	.999092	1.000908	0.000200A					

b. 1mA Range. (If Thermal Transfer is calibrated at this level)

1mA 300Hz	.999580	1.000420	.000100mA					
1mA 5kHz	.999450	1.000550	.000100mA					

AC Voltage Verification Procedure

(Using Fixed Voltage DC Calibration Standard)

Record results on Report Sheet RS2 (Page 7-A1-5).

Full Range Checks (1V – 1000V)



WARNING

THE TERMINALS MARKED WITH THE ⚡ SYMBOL CARRY THE OUTPUT OF THE 4200. THESE TERMINALS AND ANY OTHER CONNECTIONS TO THE LOAD UNDER TEST COULD CARRY LETHAL VOLTAGES. UNDER NO CIRCUMSTANCES SHOULD USERS TOUCH ANY OF THE FRONT (OR REAR) PANEL TERMINALS UNLESS THEY ARE FIRST SATISFIED THAT NO DANGEROUS VOLTAGE IS PRESENT.

- With **OUTPUT OFF**, connect the DC Voltage Standard to the Thermal Transfer DC input. Use 4-wire connection and Remote Sense if available.
- With **OUTPUT OFF**, connect the 4200 to the Thermal Transfer AC input. Use 4-wire connection and Remote Sense.
- Configure the Thermal Transfer for DC measurement at the required voltage.
- Set the DC Voltage Standard to the required voltage, **OUTPUT ON**, and null the Thermal Transfer to its output.
Record its output voltage on RS2 Table 1(a) as '4200 Required OUTPUT Voltage'.
- Configure the Thermal Transfer for AC measurement at the required voltage.
- Set 4200 **OUTPUT ON**, and adjust its **OUTPUT** Display reading to null on the Thermal Transfer.
- Record the '4200 OUTPUT Display Reading for Null' on RS2 Table 1(a).

- Ensure that the 4200 **CALIBRATION INTERVAL** switch is set to 90dy. Press the 4200 **Spec** key and record the **MODE** Display reading in ppm as ' $\pm U_r$ ppm'. Press the **Spec** key again to cancel.
- Obtain the Datron Calibration Uncertainty from Section 6 for the 4200 output, and record as ' $\pm U_d$ ppm'.
- Repeat (c) to (j) for required voltages close to all 4200 outputs on RS2 Tables 1(a) and 1(b).
- Sum the Verification setup uncertainties and record as ' $\pm U_s$ ppm'.
(Refer to Appendix 5).

Total Tolerance Limit Calculations

See Appendix 4 page 7-A4-1 Para 2.

- Calculate the Lower and Upper Total Tolerance Limits.
Use Calculations **A** and **C** if the 4200 was last calibrated by Datron.
Use Calculations **B** and **C** if the 4200 was last calibrated against the standards being used for verification.
- Each 4200 Full Range is verified if the AC Voltage outputs recorded in (h) are at or between the corresponding Total Tolerance Limits.

Linearity

(10V Range)

- If the 10V Range verified correctly, repeat the procedure for RS2 Table 1(c).
- If the 1V Range verified correctly, proceed to AC Millivolt verification and AC Current (option 30) verification.

Millivolt (LF) Verification Procedure

(Using Verified 4200 IV Range, Inductive Voltage Divider (IVD) and AC DVM)

Record results on Report Sheet RS2, Table 2(a) (Page 7-A1-6)

Full Range Checks (1mV – 100mV)

This procedure uses the same equipment, following the same steps as on page 7-6.

However, because the 1V Range was verified at the User's Standard voltage, standardization of the DVM and verification of Full Range values takes place at sub-multiples of that voltage.

Millivolts (HF) Verification Procedure

(Using verified 4200 1V and 10V Ranges, 10% Range Correction Factor and AC DVM)

Record results on Report Sheet RS2, Table 2(b) (Page 7-A1-6).

Full Range Checks (1mV – 100mV at 1MHz)

This procedure uses the same equipment, following the same steps as on page 7-7.


However, because the 1V and 10V Ranges were verified at the User's Standard voltages, calculation of the correction factor, standardization of the DVM and verification of Full Range values takes place at sub-multiples of those voltages.

Current Verification Procedure

(Using Thermal Transfer, Current Shunts and DC Current Standard)

Record Results on Report Sheet RS2, Table 3 (Page 7-A1-6).

Full Range Checks (1mA – 1A)



- a. With 4200 OUTPUT OFF, set Function to I, OUTPUT Range to 10m, OUTPUT Display to the required current at a Frequency of 300Hz.
- b. Configure the Thermal Transfer for 10mA Current measurement and connect the appropriate shunt.
- c. With the DC Current Standard OUTPUT **OFF**, ensure that it is set to the required current, and connect its output terminals across the shunt.
- d. Set the DC Current Standard OUTPUT **ON**, and null the Thermal Transfer to its DC output current. Set its OUTPUT **OFF** and disconnect from the shunt. Record its output value as '4200 Required OUTPUT Current'.
- e. With OUTPUT **OFF**, connect the 4200 I+ and I- terminals across the Shunt.
- f. Set the 4200 AC Current OUTPUT **ON** and adjust its keys to null the Thermal Transfer. Record its output current on RS2 Table 3(a) as '4200 OUTPUT Display Reading for Null'. Set 4200 OUTPUT **OFF**.
- g. Ensure that the 4200 CALIBRATION INTERVAL switch is set to **90dy**. Press the 4200 **Spec** key and record the MODE Display reading in ppm as ' $\pm U_r$ ppm'. Press the **Spec** key again to cancel.
- h. Set 4200 Frequency to 5kHz; repeat (f) and (g), then disconnect the 4200 terminals from the shunt.
- j. Obtain the Datron Calibration Uncertainty from Section 6 for the 4200 output, and record as ' $\pm U_d$ ppm'.
- k. Sum the Verification setup uncertainties and record as ' $\pm U_s$ ppm'. (Refer to Appendix 5).
- l. Repeat (a) to (k), but for 4200 LF and HF outputs, and DC Current Standard outputs close to 100mA and 1A Full Range.
- m. If the Thermal Transfer has been adequately calibrated for 1mA transfers, repeat (a) to (k) for DC and AC outputs close to 1mA Full Range, recording the 4200 output currents in RS3 table 3(b).

For Total Tolerance Limit Calculations

See Appendix 4 page 7-A4-1 Para 2.

- n. Calculate the Lower and Upper Total Tolerance Limits:
Use Calculations **A** and **C** if the 4200 was last calibrated by Datron.
Use Calculations **B** and **C** if the 4200 was last calibrated against the standards being used for verification.
- p. Each 4200 Full Range verifies if the AC Current outputs recorded in (f) are at or between the corresponding Total Tolerance Limits.

Model 4200 Verification Report Sheet

RS2 – For Users with Fixed DC Voltage Standards. (Output Values other than Full Range)

Serial Number Calibration Interval 90 days Specification Accuracy

Date Checked by Company/Dept.....

Note – On receipt of the instrument it is recommended to check at the frequencies shown below.

1. AC VOLTAGE (Using Fixed DC Voltage Standard via Thermal Transfer)

a. 1v to 1000V Ranges.

4200 OUTPUT RANGE/ FREQUENCY	4200 Required OUTPUT Voltage	4200 Spec Mode Readout (±Ur ppm)	Datron Cal. Std. Uncert'y. (±Ud ppm)	User's Cal. Std. Uncert'y. (±Us ppm)	Wideband Calculated Total Tolerance Limits		4200 OUTPUT Display Reading for Null
					–Lim	+Lim	
1V 1kHz							
1V 1MHz							
10V 1kHz							
10V 1MHz							
100V 1kHz							
100V 100kHz							
1000V 1kHz							
1000V 30kHz							

b. 700V at 100kHz.

700V 100kHz							
-------------	--	--	--	--	--	--	--

c. Linearity (Performed on 10V Range)

1V 1kHz							
10V 1kHz							
19.99999V 1kHz							

2. AC MILLIVOLTS 1mV to 100mV Ranges.

a. LF 1kHz (Using Verified 1V Full Range, Inductive Voltage Divider and AC DVM)

4200 OUTPUT RANGE	4200 Required OUTPUT Voltage	4200 Spec Mode Readout ($\pm U_r$ ppm)	Datron Cal. Std. Uncert'y. ($\pm U_d$ ppm)	User's Cal. Std. Uncert'y. ($\pm U_s$ ppm)	Wideband Calculated Total Tolerance Limits		4200 OUTPUT Display Setting
					-Lim	+Lim	
100mV							
10mV							
1mV							

b. HF 1MHz (Using Verified 1V and 10V Full Range, 10% Range Correction and AC DVM)

100mV							
10mV							
1mV							

3. AC CURRENT

a. 10mA to 1A Ranges. (Using Thermal Transfer, Current Shunts and DC Current Standard)

4200 OUTPUT RANGE/ FREQUENCY	Transfer Shunt Value	4200 Required OUTPUT Current	Wideband Relative Accuracy $\pm U_r$ (ppm)	Datron Cal. Std. Uncert'y. $\pm U_d$ (ppm)	User's Cal. Std. Uncert'y. $\pm U_s$ (ppm)	Wideband Calculated Total Tolerance Limits		4200 OUTPUT Display Reading for Null
						Lower	Upper	
10mA 300Hz								
10mA 5kHz								
100mA 300Hz								
100mA 5kHz								
1A 300Hz								
1A 5kHz								


b. 1mA Range. (If Thermal Transfer is calibrated at this level)

1mA 300Hz								
1mA 5kHz								

Millivolts Verification Procedure

(Using verified 4200 1V Range, Wideband Inductive Voltage Divider (WIVD) and AC DVM). Record results on report Sheet RS3, (Page 7-A2-2)

Full Range Checks (1mV – 100mV), LF (1kHz) and HF (100kHz).



Standardization of DVM Millivolt Ranges



Verification of 4200 LF Millivolt Ranges

- a. With **OUTPUT OFF**, connect the 4200, WIVD and DVM for Standardization. Set the IVD ratio to 1:1000, the AC DVM to measure 1mV.
- b. Set 4200 to 1V Range, 1kHz, and adjust for corrected 1.000000V output.
- c. Set 4200 **OUTPUT ON** and note the DVM reading as **V1**.
- d. Set 4200 **OUTPUT OFF**, and reconnect the test circuit for Verification.
- e. Set the 4200 **OUTPUT RANGE** to 1mV and adjust the **OUTPUT Display** to 1.0000mV.
- f. Set 4200 **OUTPUT ON** and adjust the **OUTPUT keys** for a DVM reading of **V1**.
- g. Record the 4200 **OUTPUT Display** setting in the last column of RS3.
- h. Repeat (a) to (g), but setting the 4200 frequency to 100kHz.
- j. Set the IVD ratio and DVM as required to verify the 10mV and 100mV Full Range outputs; still using the corrected 1V Full Range output in (b). Record the results on RS3.
- k. Sum the Verification setup uncertainties and record in the **Us** column as voltage deviations (Refer to Appendix 5).

Total Tolerance Limit Calculations

Refer to Appendix 4 page 7-A4-1, para 1.

- l. Calculate the Lower and Upper Total Tolerance Limits:
Use Calculation **A** if the 4200 was last calibrated by Datron.
Use Calculation **B** if the 4200 was last calibrated against the standards being used for verification.
- m. Each 4200 mV Full Range verifies if the 4200 **OUTPUT Display** readings recorded in (g) are at or between the corresponding Total Tolerance Limits.

Millivolts (LF & HF) Verification Report Sheet

RS3 – For Users with Adjustable DC Voltage Standards.
(Using Verified 1V Full Range, Wideband Inductive Voltage Divider and AC DVM)

Serial Number Calibration Interval 90 days Specification Accuracy

Date Checked by Company/Dept.....

Note – On receipt of the instrument it is recommended to check at the frequencies shown below.

Full Range Outputs 1mV to 100mV Ranges.

4200 OUTPUT RANGE/ FREQUENCY		4200 Nominal OUTPUT Voltage	Wideband Relative Accuracy Tolerance Limits Lower(Lr) Upper(Ur)		Datron Cal. Std. Uncert'y. ±Ud (Abs)	User's Cal. Std. Uncert'y. ±Us (Abs)	Wideband Calculated Total Tolerance Limits Lower Upper		4200 OUTPUT Display Setting
1mV	1kHz	1.0000mV	.9949	1.0051	0.0011mV				
1mV	100kHz	1.0000mV	.9946	1.0054	0.0015mV				
10mV	1kHz	10.0000mV	9.9936	10.0064	0.0015mV				
10mV	100kHz	10.0000mV	9.9911	10.0089	0.0060mV				
100mV	1kHz	100.0000mV	99.9810	100.0190	0.0060mV				
100mV	100kHz	100.0000mV	99.9560	100.0440	0.0510mV				


AC Current Verification Procedure

(Using verified 4200 1V Range, Calibrated Standard AC Shunts and AC DVM).
Record results on Report Sheet RS4 (Page 7-A3-2).

Full Range Checks (100 μ A –1A)



Standardization of DVM 1V Range



Verification of 4200 Current Ranges

N.B. The effects of shunt loading by the DVM must be accounted for when calculating the results.
(Typical DVM input impedance: 1M Ω m in parallel with 150pF.)

- With **OUTPUT OFF**, connect the 4200 and DVM for Standardization. Select 1V Range on the AC DVM.
- Set 4200 to 1V Range, 300Hz; and adjust for corrected 1.000000V output.
- Set 4200 **OUTPUT ON** and note the DVM reading as **V1**.
- Set 4200 **OUTPUT OFF**, and set the 4200 **OUTPUT RANGE** to 100 μ A; adjust the **OUTPUT Display** to 100.0000 μ A.
- Reconnect the test circuit for Verification, using the appropriate Calibrated Standard Shunt.
- Set 4200 **OUTPUT ON** and note the DVM reading as **V2** (see NB above).
- Calculate **V3** as follows:
$$\mathbf{V3 = 1.000000V + (V2 - V1)}$$

Record **V3** as 'Measured Shunt Voltage' on RS4.

- Divide **V3** by the shunt resistance to convert to current. Record as 'Calculated Current' on RS4.
- Repeat (a) to (h), but for all 4200 300Hz Current outputs on RS4, using appropriate shunts.
- Repeat (a) to (h) for all 4200 5kHz Current outputs on RS4.
- Sum the Verification setup uncertainties and record in the **Us** column as current deviations (Refer to Appendix 5).

For Total Tolerance Limit Calculations

Refer to Appendix 4 page 7-A4-1 Para 1.

- Calculate the Lower and Upper Total Tolerance Limits:
Use Calculation **A** if the 4200 was last calibrated by Datron.
Use Calculation **B** if the 4200 was last calibrated against the standards being used for verification.
- Each 4200 Current Full Range output verifies if the Current outputs recorded in (h) are at or between the corresponding Total Tolerance Limits.

AC Current Verification Report Sheet

RS4 – For Users with Adjustable DC Voltage Standards.
(Using verified 1V Full Range, Calibrated Standard AC Shunts and AC DVM)

Serial Number Calibration Interval 90 days Specification Accuracy

Date Checked by Company/Dept.....

Note – On receipt of the instrument it is recommended to check at the frequencies shown below.

Full Range Outputs 100µA to 1A Ranges.

4200 OUTPUT RANGE/ FREQUENCY	External Shunt Value	Wideband Relative Accuracy Tolerance Limits		Datron Cal. Std. Uncert'y. ±Ud (Abs)	User's Cal. Std. Uncert'y ±Us (Abs)	Wideband Calculated Total Tolerance Limits		Measured Shunt Voltage	Calculated Current
		Lower(Lr)	Upper(Ur)			Lower	Upper		
100µA 300Hz		99.9300	100.0700	0.0200µA					
100µA 5kHz		99.8792	100.1208	0.0500µA					
1mA 300Hz		.999580	1.000420	.000100mA					
1mA 5kHz		.999450	1.000550	.000100mA					
10mA 300Hz		9.99580	10.00420	0.00100mA					
10mA 5kHz		9.99450	10.00550	0.00100mA					
100mA 300Hz		99.9580	100.0420	0.0100mA					
100mA 5kHz		99.9450	100.0550	0.0100mA					
1A 300Hz		.999400	1.000600	0.000100A					
1A 5kHz		.999092	1.000908	0.000200A					

Total Tolerance Limit Calculations

This appendix lists the calculations necessary to determine the Total Tolerance Limits for each of the verification procedures.

Reference to the appropriate calculation is given in each procedure.

1. AC Volts, Millivolts and Current Ranges when an **Adjustable** DC Voltage or Current Source is used as the Standard.

The abbreviations used for these calculations are:

- Lr** = Lower Wideband Relative-Accuracy Tolerance Limit;
Ur = Upper Wideband Relative-Accuracy Tolerance Limit;
Ud = **Ud (Abs)** = Datron's Calibration Uncertainty expressed as a voltage or current;
Us = **Us (Abs)** = User's Calibration Standard Uncertainty expressed as a voltage or current.

A. On Receipt from Datron:

For each 4200 OUTPUT Value/Frequency selection calculate the Total Tolerance Limits as follows:

$$\begin{aligned}\text{Lower Total Limit} &= \text{Lr} - \text{Ud} - \text{Us} \\ \text{Upper Total Limit} &= \text{Ur} + \text{Ud} + \text{Us}\end{aligned}$$

Enter the results as Lower and Upper Total Limits respectively.

B. Following User Calibration:

For each 4200 OUTPUT Value/Frequency selection calculate the Total Tolerance Limits as follows:

$$\begin{aligned}\text{Lower Total Limit} &= \text{Lr} - \text{Us} \\ \text{Upper Total Limit} &= \text{Ur} + \text{Us}\end{aligned}$$

Enter the results as Lower and Upper Total Limits respectively.

2. AC Volts, Millivolts and Current Ranges when a **Fixed** DC voltage or Current Source is used as the Standard.

The abbreviations used for these calculations are:

- Ur** = **Ur ppm** = 4200 Spec. Mode Readout;
Ud = **Ud ppm** = Datron's Calibration Uncertainty expressed in ppm of the reading;
Us = **Us ppm** = User's Calibration Standard Uncertainty expressed in ppm of the reading;
Ut = Cumulative Uncertainty as calculated, expressed in ppm of the reading.
V = Required 4200 OUTPUT Value of voltage or current.

A. On Receipt from Datron

For each 4200 OUTPUT Value/Frequency selection calculate the Cumulative Uncertainty (**Ut**) from:

$$\text{Ut} = \text{Ur} + \text{Us} \text{ (ppm)}.$$

Calculate the Lower and Upper Total Tolerance Limits as in (C) below.

B. Following Calibration against the same Standard

Calculate the Cumulative Uncertainty (**Ut**) from:

$$\begin{aligned}&\text{(For CALIBRATION INTERVALS 90dy or 1yr)} \\ &\quad \text{Ut} = \text{Ur} + \text{Us} - \text{Ud} \text{ (ppm)}, \\ &\text{(For CALIBRATION INTERVAL 24hr)} \\ &\quad \text{Ut} = \text{Ur} + \text{Us} \text{ (ppm)}.\end{aligned}$$

Calculate the Lower and Upper Total Tolerance Limits as in (C) below.

C. Obtain the Cumulative Uncertainty from (A) or (B) and calculate the limits:


$$\begin{aligned}\text{Lower Limit} &= \text{V} - \frac{(\text{V} \times \text{Ut})}{10^6}; \\ \text{Upper Limit} &= \text{V} + \frac{(\text{V} \times \text{Ut})}{10^6}.\end{aligned}$$

Uncertainty and Traceability


Cumulative Tolerances

If an instrument was correctly calibrated against the factory standard at its uncertainty limit, and then verified against a user's standard, also at its limit; there are two extremes to the range of traceable results which could be obtained. If, for example, both standards' traceable errors were equal and in the same sense, the instrument would appear to verify as absolutely accurate. But if the errors were in opposite sense, it could appear to be inaccurate by the sum of the two limits of uncertainty.

In the following numerical example, a 4200 is verified in the factory at 10V, 1kHz on the 10V Range, and with 0ppm error against a 20ppm-high standard.



It remains correctly calibrated, and could be delivered to one of two users: one user's standard is 20ppm higher than the National Standard, and the other's is 20ppm lower.



Despite the instrument sustaining its original accuracy of +20ppm, and the standards all being within 20ppm of National Standards; the first user would verify the 4200 as having 0ppm error, but the second would obtain an error of +40ppm.

The increased uncertainty is unavoidable unless the same standard is used for each verification. This is clearly not a practical proposition following delivery. But after the first autocalibration against the user's standard, Datron's calibration uncertainty no longer applies.

Verification Uncertainties

Each element in the calibration traceability chain (on the next page) contributes its uncertainty to influence the overall verification tolerance limits. All uncertainties must be accounted for when calculating the total tolerances.

In addition, if two separate systems are used, one for calibration and the other for verification, then the cumulative total tolerance is the sum of those established for each system (as described earlier).

Thus on receipt of the 4200, Datron's uncertainties must be included in the total tolerance limits; but when verifying against the same Standards setup used to calibrate the instrument they are excluded.

Two formulae for calculating the total tolerance limits are given for each procedure, covering the two types of verification occasions mentioned.

Total Tolerance Limit Calculations


The 4200 is verified by comparing its output with the Total Tolerance Limits. These are calculated by summing the appropriate uncertainties from the traceability chain, and expressing the result in upper and lower absolute deviations from the chosen verification value. The 4200 checks out if its measured output is between the limits.

Where possible, the 4200 specification and Datron calibration uncertainties are given in a form suitable for calculation (see Report Sheet RS1). Where this is not possible they can be assembled from the specifications in Section 6, and in some cases can be more easily obtained using **Spec Mode** (Report Sheet RS2 has columns for this purpose).

User's uncertainties need to be assembled and included, expressed in the form appropriate to the calculations.

Whereas Datron's uncertainties are normally included in the calculations only once (on receipt), user's uncertainties must always be included. So it is sensible to provide a permanent record, eg on Report Sheets.


Once the relevant uncertainties have been entered on the Report Sheet, the Total Tolerance Limits can be calculated. The correct calculations are identified in the individual procedures.



General Procedural Information

Thermal Transfer

The Thermal Transfer Standard is connected between the DC Voltage Source and the 4200.



A 4-wire sense connection will reduce inaccuracies due to differences in the output impedances of the DC voltage source and the 4200.

Four points are important:

1. Start with OUTPUT OFF

The 4200 should be connected to the Thermal Transfer Standard only when the 4200 OUTPUT OFF LED is lit. (With Output OFF, the I+, I– Hi and Lo terminals are at high impedance).

2. Sensitivity

Always set the Thermal Transfer Standard to its lowest sensitivity before connecting up. Increase sensitivity when necessary to obtain the required input level.

WARNING

During Performance checks and calibration the full range voltage is present at the Thermal Transfer Standard input terminals. On 1000V checks this voltage is potentially lethal, so EXTREME CAUTION must be observed when making adjustments to the Thermal Transfer Standard sensitivity.

CAUTION

The Thermal Transfer Standard used must be able to withstand peak voltages up to 1600V between its input terminals. Such voltages may be present during the time that the 4200 is ramping from zero to 1100V Full Scale after setting OUTPUT ON.

3. Local/Remote Sense

Remote Sense is available as follows:

- 1V 10V 100V 1000V – Local/Remote Sense
- 1mV 10mV 100mV – Local Sense only
- All Current Ranges – not applicable

Local = Remote Sense LED OFF – 2-Wire Sense
Remote = Remote Sense LED ON – 4-Wire Sense

OUTPUT must be OFF to change Sense connection (except that Remote changes automatically to Local when switching to Millivolt Ranges).

4. Up-ranging – OUTPUT OFF Default

The 4200 cannot enter High-Voltage State ($>75V$) with OUTPUT ON. Consequently, when ranging-up, the operating system allows the up-ranging to occur, but defaults to OUTPUT OFF for two specific cases:

- a. When up-ranging to the 1000V Range,
- b. When up-ranging to the 100V Range to a voltage of 75V or more.

In H-V state an audible warning is provided.

Otherwise, OUTPUT remains ON when changing OUTPUT RANGE.

Other Useful Features

Although not essential to normal verification, the following additional facilities can sometimes simplify procedures:

FREQUENCY Store: Refer to Section 4 page 4-10,

‘Spec’ Mode: Refer to Section 4 page 4-12,

‘Error’ Mode: Refer to Section 4 page 4-14.

General Procedural Information

4200 Specification Formats

The specifications can be found in two forms:

a. Tabular layout as in Section 6.

In Section 6, the stability and relative accuracy specifications alone describe the true performance of the instrument, in a form which can be made traceable to National Standards, merely by adding in the uncertainty of the reference standard used for checking. Datron's calibration uncertainty is shown in a separate column. This must be added, to obtain true traceable accuracy for all instruments which were last calibrated by Datron. For instruments calibrated by other agencies, their calibration uncertainty must be added instead.

b. Specifications stored within the instrument's non-volatile memory.

(see Section 4 page 4-12 to 4-13).

The instrument's non-volatile memory figures can be accessed using 'Spec' Mode. These are compiled specifically for users without verification facilities, so that they can determine the tolerance limits of the 4200 output, without reference to Section 6. The 90 day and 1 year accuracy readout includes Datron's calibration uncertainty, giving traceable accuracies for instruments which were last calibrated by Datron.

24hr CALIBRATION INTERVAL

24 Hours Stability figure only.

90dy CALIBRATION INTERVAL [see Note]

90 Days Wideband Relative Accuracy figure
+ Datron's Calibration Uncertainty.

1yr CALIBRATION INTERVAL [see Note]

1 Year Wideband Relative Accuracy figure
+ Datron's Calibration Uncertainty.

Spec mode provides 90 day and 1 year accuracy figures which are traceable through Datron standards to National Standards, for users who have no calibration or verification facilities.

Note. With Spot F selected the Spot F amplitude accuracy + Datron's uncertainty is displayed.

Verification Conditions

The 24-hour stability specifications are relative to user's reference standards. In all cases validity depends on using the same standard as reference, under the same conditions, including temperature. Also, verification is valid only within 24 hours of calibration or within 24 hours of a previous verification. In the latter case, the specifications are relative to the figures obtained at the earlier verification.

On receipt, the 90-day and 1-year tolerances can be calculated by adding both the user's reference standard uncertainty and Datron's calibration uncertainty to the Relative Accuracy figure (Section 6).

Following User Calibration or a Previous Verification, add only the user's uncertainty to the Relative Accuracy figure.

Where ambient temperatures are outside the Specified range, temperature coefficient correction should be taken into account.

Report Sheets

Please use the printed report sheets as masters to generate duplicate copies, then record the instrument's performance on the duplicates (both on receipt from Datron and for future periodic checks).

The 'Adjustable DC Voltage Standard' report sheet (page 7-9) lists the appropriate wideband relative accuracy limits, and Datron's calibration uncertainty at the verification points. Blank columns are provided for the user's calibration uncertainty, the cumulative tolerance limits, and the DC Voltage Standard's adjusted reading (for comparison with the tolerance).

The 'Fixed DC Voltage Standard' report sheet (Appendix 4, Page 7-A4-5) should be used if the DC Reference Standard cannot be used at the values required for the checks detailed in the tables. In this case the 4200 'Spec Mode' can be accessed to generate its tolerance limits, but these will need to be processed to calculate the true cumulative tolerances.

The appropriate limit calculations are detailed in Appendix 4.

Harmonic Distortion Measurement

The measurement of True Harmonic Distortion is not detailed as part of the verification procedure. However, some users may wish to check this feature from time to time, so one or two points need to be clarified.

The very low noise content of the 4200 output is included in its accuracy specifications, but not in its TOTAL HARMONIC DISTORTION specifications on pages 6-3 and 6-5. The latter relate to true harmonic distortion only.

If the 4200 distortion specification is to be verified, the measurement equipment must be selected with care. Some distortion meters merely suppress the fundamental and measure the remainder over a specific bandwidth. The readings obtained include wideband noise integrated over the full bandwidth, introducing measurement errors which increase the apparent harmonic distortion (particularly at low fundamental levels, where the harmonic envelope rapidly descends into the noise floor).

Measurement of true harmonic distortion only, in any signal, can be a laborious process. To measure the value of each single frequency harmonic, (as would be required to verify the 4200 THD specification), any wideband noise must be filtered out. Very selective bandpass notch filtering is required; this is usually achieved by phase-locking the measurement circuitry to the signal, as performed by a selective signal level meter.

A modern automatic spectrum analyser is more satisfactory. The harmonic amplitudes can be displayed on a screen against a grid, the noise levels can also be seen, or a cursor can be used to set a bandpass notch filter to the harmonic frequency required, to give a direct digital readout. THD measurement is simplified and speeded up by this method.

It is therefore recommended that either a spectrum analyser or selective level meter be employed. Suitable instruments are:

Hewlett-Packard HP 3585 Spectrum Analyser, or
HP3586 Selective Level Meter.

SECTION 8 ROUTINE AUTOCALIBRATION

Users requiring to verify the specification without adjustment to the instrument's calibration status refer to Section 7. For full information on calibration of the 4200 refer to the Calibration and Servicing Handbook, Section 1.


The 4200 Autocal Feature

Using the standard 'Autocal' feature, the 4200 is calibrated entirely from the front panel (or remotely via the IEEE 488 Interface). Because it is not necessary to remove the covers, thermal disturbance is avoided and the 4200 can be put back into service immediately after calibration.

Users wishing to maintain the highest specification (24 Hours) can recalibrate daily, on a regular basis, if desired. The procedures contained in this Section provide the essential information for setting up such routines. It is not necessary to update all ranges, as it is possible to 'wide-band' calibrate one output range or SPOT calibrate at a single frequency.


During the Autocal process, the microprocessor adjusts correction factors which are already stored in non-volatile memories. After adjustment, the updated factors are continuously applied to correct the 4200 output amplitude.

Special keys are used in the Autocal mode. They are illustrated below:



These keys are activated by a simple procedure. On the rear panel there are two switches: the IEEE address switch, and a security keyswitch labelled **RUN/CAL ENABLE**. By setting the address switch to 31 (ADD 1111) for Front Panel calibration and the keyswitch to CAL ENABLE, four of the front panel **MODE** keys are reassigned to calibration functions, permitting access to the correction memories.

The activation procedure is illustrated below:



Once the keys are activated, four modes of calibrating the 4200 become available. They are given the following names:

- 'WIDEBAND', using only the **CAL** key;
- 'SET' using **SET** and **CAL** keys in sequence;
- 'SPOT', with or without **SET**, triggered by **CAL**;
- 'STANDARD' using **STD** and **CAL** keys in sequence.

STD, SET and SPOT have press on/press off action.


The meanings of the names, and the detailed procedures for using the modes, are described overleaf.

'Wideband' Calibration

When **CAL** is pressed without preselecting **SET**, **SPOT** or **STD**; the 4200 makes the assumption: that each **OUTPUT Range** is to be calibrated at the exact Full Range value, at either **LF** or **HF**, or both.

This allows two correction values to be stored for each output range. From their difference, the microprocessor calculates a compensation factor, which affects the corrections applied at all subsequently-selected frequencies on that output range. In this way, the 4200 can be calibrated to meet its 'Wideband' specification.

To ensure that the selected Low and High frequencies have sufficient separation for the compensation to be effective over the full frequency range, calibration is automatically prohibited in an 'excluded' band of frequencies for each output range. Because of the extended frequency range of lower Voltage ranges, and the Voltage/Frequency constraints on higher Voltage ranges, the exclusion band can differ from one output range to another. If an excluded frequency is selected, the calibration is cancelled and **Error 3** is displayed. The following diagram illustrates the mid-frequency exclusions:



SET Calibration

If **WIDEBAND** or **SPOT** Calibration is to be carried out with sources which are not exactly at Full Range, then the **SET** preselection key allows the 4200 to be prepared for calibration at other than its full range values. In this way the 4200 can be calibrated between 20% and 200% of full range, except for 1000V Range (20% to 110% - max. 1100V) and for **SPOT** calibration.

SET can also be used as a means of compensating for known errors in the Measurement System.

SPOT Calibration

For each Output Range, a user may select five frequencies for **SPOT** calibration. The 4200 stores the spot frequencies and their amplitude corrections, in memories which are separate from those used for wideband corrections. Enhanced accuracy is obtained at these spots, as any flatness errors in the wideband correction are eliminated. As shipped, some Spot frequencies may be calibrated, if this service was purchased by the customer.

Procedural Notes

When **SPOT** is pressed the 4200 assumes that the spot frequency is to be changed, and so defaults frequency to 1kHz.

When used with **SET**, **SPOT** calibration can be carried out within 10% of full range value, but when **SPOT** is used without **SET**, the 4200 assumes that the calibration is to be at Full Range.

Spot F achieves highest specification if used at the calibrated value. Accuracy tables are given in Section 6, with an example showing Spot F linearity on page 6-2. For Recall procedures see Section 4, page 4-11.

STANDARD Calibration

CAUTION! This calibration affects all Voltage and Current Ranges!

STD calibration is designed for certain occasions when it is required to adjust the gain of all voltage and current ranges in the same ratio. The facility can be used to avoid a full recalibration of the 4200 when Laboratory References have been re-standardized, or when a 4200 has been moved from one country to another.

The **STD** facility is restricted to the 1V and 10V Ranges, on the 100Hz and 1kHz Frequency Ranges only. The procedure follows the **SET** procedure except that the **STD** key is pressed in place of the **SET** key. Pressing the **CAL** key to trigger the calibration adjusts all Voltage and Current Range, Wideband and Spot F gains in the same ratio.

Calibration Sequence

INTRODUCTION

Because most users will calibrate the 4200 via thermal transfer standards, the calibration procedures assume that this method will be employed. However, details of setting up a thermal transfer standard are not included, as several different models are in use, each with their own methods of connection and procedures.

Instead it is assumed that users will be able to operate their own equipment correctly, according to the manufacturer's instructions. The procedures which follow therefore concentrate on the operation of the 4200 during calibration, accepting that the required thermal transfer will be set up to a DC source of suitable accuracy.

GENERAL PROCEDURE

WARNING! During Performance checks and calibration the Full Range voltage is present at the Thermal Transfer Standard input terminals. On 1000V checks this voltage is potentially lethal, so EXTREME CAUTION must be observed when adjusting the Thermal Transfer Standard sensitivity.

Voltage Calibration using a Thermal Transfer

Select the desired frequency (or Spot frequency), set the 4200 **OUTPUT** display to the Calibration Standard value, and switch the 4200 **OUTPUT ON**. If calibrating a non-nominal voltage value, **SET** needs to be selected. Adjust the 4200 output to obtain a null at the Calibration Standard value, and press the **CAL** key to execute the calibration.

LF Millivolt Calibration

Because 'Flatness' data is passed on to the millivolt ranges from the 1V Range calibration, the 1V range must be calibrated first. A DVM is then standardized at the required millivolt value and frequency, using the calibrated 1V Range and an Inductive Divider (IVD). The desired frequency (or **SPOT** frequency) is selected, the **OUTPUT** display set to Full Range, and incremented or decremented to give the required value on the DVM. If calibrating at a non-nominal value **SET** must be selected. The **CAL** key is pressed to execute the calibration.

HF Millivolt Calibration

From the 10V Range a 10% Range correction is calculated. This is applied at 100mV on the 1V Range to standardize a DVM, which is subsequently used to calibrate the 100mV Full Range. The process is extended to calibrate the 10mV Range from 10% of the 100mV Range, and the 1mV Range from 10% of the 10mV Range.

Current Calibration

(Using Thermal Transfer Standard Current Shunts)

The method employs a DC Current Standard, so that the shunt remains connected for both AC and DC nulling of the Thermal Transfer Standard.

Otherwise the procedure is similar to that for DC Voltage Calibration.

Alternative Current Calibration

(Using Calibrated Standard AC Current Shunts)

This method requires Standard Current Shunts which have been designed to give a flat frequency response. Each current range requires its own specific value of shunt, calibrated to develop either 1V or 100mV Full Range at LF and HF. An AC DVM is standardized to the appropriate voltage, and the Current range is calibrated when the voltage across its shunt is correct. The method is detailed in Appendix 1 to this section.

Standardization

To 'Standardize!' all Ranges: The Voltage procedure is used, but pressing **STD** instead of **SET** on the 1V/10V Range.

CAUTION! Do not 'Standardize' unless it is necessary for the reasons quoted on page 8-2.

GENERAL NOTES

Remote Sense is available as follows:

1V 10V 100V 1000V - Local/Remote Sense

1mV 10mV 100mV - Local Sense only

All current ranges - not applicable

(Local: 2-wire sense Remote: 4-wire sense)

Output must be **OFF** to change sense connection (except that Remote changes automatically to Local when switching to Millivolt Ranges).

Upgrading - OUTPUT OFF Default

The 4200 cannot enter High-Voltage State ($>75V$) with OUTPUT ON. Consequently, when ranging-up, the operating system allows the upgrading to occur, but defaults to OUTPUT OFF for two specific cases:

- a. When upgrading to the 1000V Range,
- b. When upgrading to the 100V Range to a voltage of 75V or more.

Otherwise, OUTPUT remains ON when changing OUTPUT RANGE (refer to Section 4, pages 4-7 and 4-8).

High Frequency Calibrations

Several passes may be required to achieve satisfactory calibration, particularly if the initial errors are large or the calibration takes longer than required by the Transfer System in use. Repeat procedure as required.

1000V Range Calibration Sequence:

LF calibration must be completed first. However HF1/HF2 bands may, if the user requires, be calibrated in reverse order. SET mode must be used for 700V/HF2.

SPOT Memory Erasure

To prevent unwanted calibrations at obsolete spot frequencies, it is possible to 'Uncalibrate' any spot frequency on any range. The procedure is:

Select Zero Output, set Output ON and Press CAL.

When the CAL ENABLE/RUN switch is set to RUN, any selection of that particular Spot F will cause the uncalibrated message 'SFX ----' to be shown on the MODE/FREQUENCY display.

Preparation

Before any calibration is carried out, prepare the 4200 as follows:

1. Turn on the instrument to be checked and allow minimum of 4 hours to warm up in the specified environment.
2. Ensure familiarity with normal operation of the 4200 described in this Handbook.
3. Refer to 'Equipment Requirements' in Section 7; the same equipment and techniques used for verification are also applicable to calibration.
4. Consult the manufacturer's handbooks before connecting and operating the Thermal Transfer Std, DC Voltage Std, Inductive Divider, AC DVM, and Thermal Transfer Standard Current Shunts.
5. Interconnections and Guarding: Refer to Section 4, page 4-2.
6. Cancel any **MODE** keys, ensure **OUTPUT** set to **OFF**.
7. IEEE 488 Address switch:
Set to **ADD 11111** (Address 31) unless the 4200 is to be calibrated via the IEEE 488 interface.
8. **CALIBRATION ENABLE** key switch:
Insert Calibration Key and turn to **ENABLE**.
9. Set the Calibration Interval Switch to **24 hr**.

WARNING

During calibration, the Full Range voltage is present at the Thermal Transfer Standard input terminals. On 1000V checks this voltage is potentially lethal, so EXTREME CAUTION must be observed when making adjustments to the Thermal Transfer Standard sensitivity.

AC Voltage Full Range Calibration (1V – 1000V)

(Using Thermal Transfer Standard and DC Calibration Standard)



Calibrate the 4200 at or close to the calibration points in the table, selecting SET and/or SPOT as required as part of the following procedure:

WARNING:
 **THE TERMINALS MARKED WITH THE SYMBOL CARRY THE OUTPUT OF THE 4200. THESE TERMINALS AND ANY OTHER CONNECTIONS TO THE LOAD UNDER TEST COULD CARRY LETHAL VOLTAGES. UNDER NO CIRCUMSTANCES SHOULD USERS TOUCH ANY OF THE FRONT (OR REAR) PANEL TERMINALS UNLESS THEY ARE FIRST SATISFIED THAT NO DANGEROUS VOLTAGE IS PRESENT.**

1. 4200 & DC Voltage Standard

With OUTPUT OFF, connect to the Thermal Transfer AC and DC inputs, respectively.

2. Thermal Transfer Standard

Configure for DC measurement at the required Calibration Voltage.

3. DC Voltage Calibration Standard

Set to the Cal Voltage, OUTPUT ON.

4. Thermal Transfer Standard

- a. Adjust for Null at the Cal. Voltage.
- b. Configure for AC measurement at the Calibration Voltage.

5. 4200

- a. On AC FUNCTION, select the required OUTPUT RANGE.
- b. Select the required FREQUENCY RANGE (or if a Spot Frequency is to be calibrated: Press SPOT and select F1 – F5).
- c. Use FREQUENCY $\uparrow\downarrow$ keys to display the required Cal. Frequency.

- d. Use OUTPUT $\uparrow\downarrow$ keys to display the required Cal. Voltage (if at Nominal Full Range, merely press the Full Range key).
- e. Set 4200 OUTPUT ON (and if NOT at Nominal Full Range, Select SET).
- f. Use the OUTPUT $\uparrow\downarrow$ keys to adjust the OUTPUT Display reading to obtain a null on the Thermal Transfer.
- g. Execute the calibration by pressing the CAL key (and if calibrating a Spot Frequency, repress the SPOT key to deselect).

Nominal Cal. Points for 1V to 1000V Ranges.


DC Standard OUTPUT Voltage	4200 OUTPUT RANGE/ FREQUENCY		4200 Nominal OUTPUT Voltage	Freq. Band set by 4200
1.000000V	1V	1kHz	1.000000V	LF
1.000000V	1V	1MHz	1.000000V	HF
10.00000V	10V	1kHz	10.00000V	LF
10.00000V	10V	1MHz	10.00000V	HF
100.0000V	100V	1kHz	100.0000V	LF
100.0000V	100V	100kHz	100.0000V	HF
1000.000V	1000V	1kHz	1000.000V	LF
1000.000V	1000V	30kHz	1000.000V	HF1

700V at 100kHz:
‘SET’ Calibration **must** be employed.


700.000V	1000V	100kHz	700.000V	HF2
----------	-------	--------	----------	-----

Millivolts (LF) Full Range Calibration (1mV – 100mV)

(Using calibrated 4200 1V Range, Inductive Voltage Divider (IVD) and AC DVM)



Standardization of DVM Millivolt Ranges



Calibration of 4200 LF Millivolt Ranges

Calibrate the 4200 at or close to the calibration points in the table, selecting SET and/or SPOT as required as part of the following procedure:

Note:

It is assumed that for a **SPOT** calibration, the 1V Range has already been Spot calibrated at the required calibration point.

1. 4200, IVD and AC DVM

With OUTPUT OFF, connect the circuit for Standardization.

2. IVD

Set ratio as required for the Millivolt Range to be calibrated.

3. AC DVM

Configure for measurement at the required Calibration Point.

4. 4200

- On AC FUNCTION, select 1V RANGE.
- Select the required Frequency Range (or if a Spot Frequency is to be calibrated: Press **SPOT** and select **F1 – F5**).
- Use FREQUENCY $\uparrow\downarrow$ keys to display the required Cal. Frequency.
- Use OUTPUT $\uparrow\downarrow$ keys to display the required IVD input voltage (if at Nominal Full Range, merely press the **Full Range** key).

- Set OUTPUT **ON**; note DVM reading as **V1**.
- Set OUTPUT **OFF**, and reconnect the circuit for Calibration.
- Select the required Millivolt OUTPUT RANGE.
- Use OUTPUT $\uparrow\downarrow$ keys to display the Cal. Voltage on the OUTPUT Display (if at Nominal Full Range, merely press the **Full Range** key).
- Set 4200 OUTPUT ON (and if NOT at Nominal Full Range, Select SET).
- Use the $\uparrow\downarrow$ keys to adjust the OUTPUT Display reading to obtain **V1** on the DVM.
- Execute the calibration by pressing the **CAL** key (and if calibrating a Spot Frequency, repress the **SPOT** key to deselect). Set OUTPUT **OFF**.


Nominal Cal. Points for Millivolt Ranges.

IVD Ratio (1V Range to mV Range)	4200 OUTPUT RANGE/ FREQUENCY	4200 Nominal OUTPUT Voltage	Freq. Band set by 4200
10 : 1	100mV 1kHz	100.0000mV	LF
100 : 1	10mV 1kHz	10.0000mV	LF
1000 : 1	1mV 1kHz	1.0000mV	LF

Millivolts (HF) Full Range Calibration (1mV – 100mV)

(Using calibrated 4200 1V and 10V Ranges, 10% Range Correction Factor and AC DVM)

Standardization of
DVM 100mV Range
(on 1V Range only, use
4-wire connection
in Remote Sense)



N.B. These Calibrations are not fully traceable. Calibrate the 4200 at or close to the calibration points in the table, selecting SET and/or SPOT as required as part of the following procedure:

Note:

It is assumed that the 1V and 10V Ranges have been Wideband calibrated (and for SPOT calibration, the 1V Range has already been Spot calibrated) at the required HF calibration points.

1. 4200 and AC DVM

- Measure 10.00000V output on the 10V Range at the HF Cal. Frequency using the Thermal Transfer. Note the reading [V1].
- Measure 1.00000V output on the 10V Range at the HF Cal. Frequency using the Thermal Transfer. Note the reading [V2].
- Divide [V1] by [V2], then divide the result by 10. This gives the 10% Range Correction Factor, 'C':

$$C = \frac{V1}{10 \times V2}$$

This factor subsequently corrects a DVM measurement at 10% of one range, to standardize the DVM for calibration of the next millivolt range down.

- With OUTPUT OFF, connect the circuit for Standardization.

2. 4200

- On AC FUNCTION, select 1V OUTPUT RANGE.
- Select the required FREQUENCY RANGE (or if a Spot Frequency is to be calibrated: Press SPOT and select F1 – F5).
- Use FREQUENCY $\uparrow\downarrow$ keys to display the required Cal. Frequency.
- Using the OUTPUT $\uparrow\downarrow$ keys, adjust the OUTPUT Display to the 100mV Cal. Voltage on the 1V Range.


- Set 4200 OUTPUT ON and note the DVM reading. Multiply the reading by 'C', and note the result as Vc. (If the DVM being used is a Datron Autocal instrument, the Maths function can do this automatically).
- With OUTPUT OFF, connect the circuit for Calibration.
- Set 4200 OUTPUT OFF, select 100mV Range, and again use the OUTPUT $\uparrow\downarrow$ keys to set the OUTPUT Display to the Cal. Voltage. (if at Nominal Full Range, merely press the Full Range key).
- Set 4200 OUTPUT ON (and if NOT at Nominal Full Range Select SET).
- Adjust the OUTPUT $\uparrow\downarrow$ keys for a reading of Vc on the DVM.
- Execute the calibration by pressing the CAL key (and if calibrating a Spot Frequency, re-press the SPOT key to deselect). Set OUTPUT OFF.
- Repeat operations 2 (a) to (k), selecting 10mV on the 100mV Range to standardize the DVM and calibrating the 10mV Range, using the same correction factor 'C'.
- Repeat operations 2 (a) to (k), selecting 1mV on the 10mV Range to standardize the DVM, and calibrating the 1mV Range, using the same correction factor 'C'.

Nominal Cal. Points for HF Millivolt Ranges.

4200 OUTPUT RANGE/ FREQUENCY	4200 Nominal OUTPUT Voltage	Freq. Band set by 4200
100mV 1MHz	100.0000mV	HF
10mV 1MHz	10.0000mV	HF
1mV 1MHz	1.0000mV	HF

Current Full Range Calibration (1mA -1A)

(Using Thermal Transfer, Current Shunts and DC Current Standard)



Calibrate the 4200 at or close to the calibration points in the table, selecting SET and/or SPOT as required as part of the following procedure:

Calibrate 1mA Range only if the Thermal Transfer is adequately calibrated at these levels.

1. Thermal Transfer Standard

Configure for **DC** measurement at the required Cal. Current and connect the appropriate shunt.

2. DC Current Standard

- With **OUTPUT OFF**, connect across the Thermal Transfer shunt, and set to the required Cal. Current.

- Set **OUTPUT ON**.

3. Thermal Transfer Standard

Adjust for null at the Cal. Current.

4. DC Current Standard

- Set **OUTPUT OFF**.

- Disconnect from the shunt.

5. 4200

- With **OUTPUT OFF**, connect the I+ and I- terminals across the Shunt.
- On **I FUNCTION**, select the required **OUTPUT RANGE**.
- Select the required **FREQUENCY RANGE** (or if a Spot Frequency is to be calibrated: Press **SPOT** and select **F1 - F5**).
- Use **FREQUENCY** $\uparrow\downarrow$ keys to display the required Cal. Frequency.

- Use **OUTPUT** $\uparrow\downarrow$ keys to display the required Cal. Current (if at Nominal Full Range, press the **Full Range** key).

- Set 4200 **OUTPUT ON** (and if **NOT** at Nominal Full Range, Select **SET**).

- Use the **OUTPUT** $\uparrow\downarrow$ keys to adjust the **OUTPUT Display** reading to obtain a null on the Thermal Transfer.


- Execute the calibration by pressing the **CAL** key (and if calibrating a Spot Frequency, repress the **SPOT** key to deselect). Set **OUTPUT OFF**.

Nominal Cal. Points for 1mA to 1A Ranges.


DC Standard OUTPUT Current	4200 OUTPUT RANGE/ FREQUENCY	4200 Nominal OUTPUT Current	Freq. Band set by 4200
1.000000mA	1mA 300Hz	1.000000mA	LF
1.000000mA	1mA 5kHz	1.000000mA	HF
10.000000mA	10mA 300Hz	10.000000mA	LF
10.000000mA	10mA 5kHz	10.000000mA	HF
100.000000mA	100mA 300Hz	100.000000mA	LF
100.000000mA	100mA 5kHz	100.000000mA	HF
1.000000A	1A 300Hz	1.000000A	LF
1.000000A	1A 5kHz	1.000000A	HF

Current Full Range Calibration (100μA-1A)

(Using verified 4200 1V Range, Calibrated Standard AC Shunts and AC DVM)



Standardization of DVM 1V Range



Calibration of 4200 Current Ranges

Calibrate the 4200 at or close to the calibration points in the table, selecting SET and/or SPOT as required as part of the following procedure:

Note:

It is assumed that for a **SPOT** calibration, the 1V Range has already been Spot calibrated at the required calibration point.

1. 4200 and AC DVM

With **OUTPUT OFF**, connect the 4200 and DVM for Standardization. Select 1V Range on the AC DVM.

2. 4200

- a. Set to 1V Range at the Calibration Frequency and adjust for calibrated 1.000000V output.
- b. Set **OUTPUT ON** and note the DVM reading as **V1**.
- c. Set **OUTPUT OFF**, and reconnect the test circuit for Calibration, using the correct shunt for the range to be calibrated.
- d. On **I FUNCTION**, select the required **OUTPUT RANGE**.
- e. Select the required **FREQUENCY RANGE** (or if a Spot Frequency is to be calibrated: Press **SPOT** and select **F1 – F5**).
- f. Use **FREQUENCY** $\uparrow\downarrow$ keys to display the required Cal. Frequency.
- g. Use **OUTPUT** $\uparrow\downarrow$ keys to display the required Cal. Current (if at Nominal Full Range, press the **Full Range** key).

- h. Set 4200 **OUTPUT ON** (and if **NOT** at Nominal Full Range, Select **SET**).
- j. Use the **OUTPUT** $\uparrow\downarrow$ keys to adjust the **OUTPUT** Display reading to obtain a DVM reading of **V1**.
- k. Execute the calibration by pressing the **CAL** key (and if calibrating a Spot Frequency, repress the **SPOT** key to deselect). Set **OUTPUT OFF**.

Nominal Cal. Points for 100μA to 1A Ranges.

4200 OUTPUT RANGE/ FREQUENCY	4200 Nominal OUTPUT Current	Freq. Band set by 4200
100μA 300Hz	100.0000μA	LF
100μA 5kHz	100.0000μA	HF
1mA 300Hz	1.000000mA	LF
1mA 5kHz	1.000000mA	HF
10mA 300Hz	10.000000mA	LF
10mA 5kHz	10.000000mA	HF
100mA 300Hz	100.0000mA	LF
100mA 5kHz	100.0000mA	HF
1A 300Hz	1.000000A	LF
1A 5kHz	1.000000A	HF



SALES AND SERVICE REPRESENTATIVES WORLDWIDE

COUNTRY AND REPRESENTATIVE		Telephone	Telex
AUSTRALIA	The Dindima Group Pty. Ltd P O Box 106, Vermont, Victoria 3133	(3)873445	36819
AUSTRIA	Kontron GmbH & Co, Electronics Department Eisgrubengasse 6, A-2334 Voessendorf	(222)670031	131699
BELGIUM	MCR Electronic Marketing 100 Chaussee de Nivelles, 1420 Braine L'Alleud	(2)3848062	62569
BRAZIL	Commercial Goncalves Loja 01029, Rua Florencio de Abreu 559, Sao Paulo SP	(11)2277082	22104
CHINA	The First Radio Factory of Tianjin No.5 Zhao Jia Chang Street, Hong Qiao Section, Tianjin	Tianjin 2277082	22104
DENMARK	CKI 187 Islevdalvej, 2880 Kobenhavn-Bagsvaerd, DK 2610 Rydovre	(2)944411	35363
EASTERN EUROPE	Data Loop Ltd 'The Coach House', Tower Hill, Dorking, Surrey RH4 2AN, England	(0306)881166	859417
EGYPT & MIDDLE EAST	EPIC 20 Ashmoun St, PO Box 2682, Horria, Heliopolis	(2)661767	2315
EIRE	Calibration Specialists Limited Unit 5, Enterprise Centre, Plassey Park, Castletroy, Limerick	(61)330333	70092
FINLAND	Finn Metric OY PL4, Riihitontuntie 2, SF 02201, ESP00	(0)423911	122018
FRANCE	JOD Electronique 9 Rue Noblet, 92500 Rueil Malmaison, Paris	(1)7329260	201626
GERMANY	Wavetek Electronics GmbH Hans-Pinsel Strasse 9-10, 8013 Haar b. Munchen, W.Germany	(89)461090	5212996
GREECE	American Technical Enterprises PO Box 156, 48 Patission Street, Athens 147	(1)8219470	216046
HONG KONG	Eurotherm (Far East) Ltd 49-51 Wong Chuk Hang Rd, Flat A and B, 19/F Derrick Building, Aberdeen	(5)546391	72449
INDIA	Electronic Enterprises PB No. 6367, Unit 216, Regal Estate, Acharya Donde Marg, Sewri, Bombay 400 015	(22)8827096	1171071
INDONESIA	PT & PD Bah Bolon Trading Co Jalan Tana Abang iv No.17, Jakarta Pusat	(21)343327/ 354973	46164
ISRAEL	Racom Electronics Co. Ltd 7 Kehilat Saloniki St., P.O. Box 21120, Tel-Aviv 61210	(3)491922	33808

COUNTRY AND REPRESENTATIVE		Telephone	Telex
ITALY(1)	Telav International Via Salaria 1313, 00138 Roma	(6)691-9312/ 9376/7058	614381
ITALY(2)	Telav International SRL Viale Leonardo da Vinci 43, 20090 Trezzano sul Naviglio, Milano	(2)4455741	312827
JAPAN	Cornes & Co. 8th Floor Maruzen Building, 3-10 Nihonbashi 2 Chome, Chuo-Ku, Tokyo	(3)2725771	2222987
KOREA	M.S. International Corporation CPO Box 6780, Seoul	(2)7539916	24965
NETHERLANDS	Air Parts, International BV PO Box 255, 12 Kalkovenweg, 2400 AG Alphen a.d. Rijn	(72)29300	39564
NORWAY	Norsk Marconi A/S P O Box 50, Manglerud, N-0612, Oslo 6	(2)680480	77140
NEW ZEALAND	S D Mandeno Electronic Equip Co 10 Woodhall Road, Epsom, AUCKLAND 3	(9)600008	21997
PORTUGAL	Omnitecnica Estrada de Alfragide, 2700 Amadora	(19)905517	13433
PAKISTAN	CMC 22 Fareed Chambers, Abdullah Haroon Road, Karachi-3	(21)516134	25433
SPAIN	REMA Leo Haag S.A. Jose Abascal, 18-28003 Madrid	(1)4423900	42838
SINGAPORE & MALASIA	SEEL 24 Ang Mo Kio Street 65, Singapore 2056	(65)4593555	21901
SOUTH AFRICA	Measuretest Pty. Limited PO Box 6301, Dunswart 1508, Transvaal	(11)8947721/2/3	421482
SWEDEN	Ferner Electronics AB Box 125, 16126 BROMMA	(8)802540	10312
SWITZERLAND	Precitek Electronic AG Bahnhofstrasse 358B, CH-8107, Buchs/Zurich	(1)8442950	56377
TAIWAN	Evergo Corporation 4th Floor, 75 Section, 3 Nan King E. Road, Taipei	(2)5367451	27027
UNITED KINGDOM	Datron Instruments Hurricane Way, Norwich, Norfolk, England	(0603)404824	975173
UNITED STATES & CANADA	Datron Instruments Inc 4125 SW Martin Highway, Stuart, Florida	(305)2830935	230525724

For customers in countries not listed please contact DATRON INSTRUMENTS in the United Kingdom

